



Manuals.plus /

› [Westinghouse](#) /

› [Westinghouse 6306500 Dunmore Two-Light Semi-Flush Ceiling Fixture Instruction Manual](#)

Westinghouse 6306500

Westinghouse 6306500 Dunmore Two-Light Semi-Flush Ceiling Fixture

INSTRUCTION MANUAL

[Overview](#) [Safety](#) [Contents](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. Product Overview

The Westinghouse 6306500 Dunmore Two-Light Indoor Semi-Flush Ceiling Fixture is designed to provide soft, inviting light in various indoor settings. It features an oil rubbed bronze finish and a frosted glass shade, suitable for hallways, foyers, living rooms, dining rooms, or bedrooms.

Key Features:

- Elegant semi-flush mount design.
- Frosted glass shade for diffused light.
- Accommodates two 60-watt maximum, medium-base light bulbs (not included).
- Compact dimensions: 12-5/16 inches high by 14-1/2 inches diameter.
- Includes all necessary installation instructions and mounting hardware.



Figure 1: The Westinghouse Dunmore Two-Light Semi-Flush Ceiling Fixture with an oil rubbed bronze finish and frosted glass shade.

2. Important Safety Information

Read all instructions carefully before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage. All wiring must be in accordance with national and local electrical codes. If you are unsure about wiring, consult a qualified electrician.

- **WARNING:** To avoid electric shock, disconnect power at the circuit breaker or fuse box before installation or servicing.
- Ensure the fixture is properly grounded.
- Do not exceed the maximum wattage specified for the light bulbs.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture.

3. Package Contents

Verify that all components are present before proceeding with installation. If any parts are missing or damaged, contact Westinghouse customer service.

- Mounting Bracket
- Fixture Body with Oil Rubbed Bronze Finish
- Frosted Glass Shade
- Decorative Finial
- Mounting Hardware (screws, wire nuts, etc.)
- Installation Instructions



Figure 2: Detail of the oil rubbed bronze finish and decorative scrollwork on the fixture body.

4. Installation Instructions

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before starting. Refer to local electrical codes for proper wiring procedures.

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's power supply and switch it to the OFF position. Verify power is off using a voltage tester.
2. **Remove Old Fixture:** Carefully remove the existing light fixture, noting the wiring connections.
3. **Attach Mounting Bracket:** Secure the new mounting bracket to the junction box in the ceiling using the provided screws. Ensure it is firmly attached.
4. **Wire Connections:**
 - Connect the bare copper or green ground wire from the fixture to the ground wire from the junction box.
 - Connect the white wire from the fixture to the white (neutral) wire from the junction box.
 - Connect the black wire from the fixture to the black (hot) wire from the junction box.
 - Secure all connections with wire nuts and wrap with electrical tape for added safety.
5. **Mount Fixture Body:** Carefully push the wired fixture body up to the mounting bracket and secure it with the provided screws or nuts.
6. **Install Light Bulbs:** Screw two 60-watt maximum, medium-base (E26) light bulbs into the sockets. LED equivalent bulbs are recommended for energy efficiency.
7. **Attach Glass Shade:** Place the frosted glass shade onto the fixture body and secure it with the decorative finial at the bottom. Do not overtighten.
8. **Restore Power:** Turn the power back on at the circuit breaker. Test the light fixture.



Figure 3: Dimensional drawing showing the fixture's height of 12.31 inches and diameter of 14.5 inches.

5. Operating Instructions

The Westinghouse Dunmore Semi-Flush Ceiling Fixture operates via a standard wall switch connected to your home's electrical system. Ensure appropriate light bulbs are installed for optimal performance.

- **Bulb Type:** Uses two medium-base (E26) bulbs.
- **Maximum Wattage:** Do not exceed 60 watts per bulb.
- **Recommended Bulbs:** For energy efficiency and longevity, consider using Westinghouse 60-watt equivalent LED bulbs.

6. Care and Maintenance

Regular cleaning and proper maintenance will ensure the longevity and appearance of your light fixture.

- **Cleaning:** To clean the fixture, turn off the power and wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- **Glass Shade:** The frosted glass shade can be carefully removed for more thorough cleaning if necessary. Wash with mild soap and water, rinse thoroughly, and dry completely before reattaching.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow old bulbs to cool before removal. Replace with bulbs of the correct base type and wattage.

7. Troubleshooting

If you experience issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Defective bulb.	Check circuit breaker and wall switch. Verify all wire connections are secure (power off). Replace bulb with a new one.
Light flickers.	Loose bulb. Incorrect bulb type or wattage. Loose wire connection.	Tighten bulb securely. Ensure bulbs meet specifications. Check wire connections (power off).
Glass shade is loose.	Finial not tightened sufficiently.	Gently tighten the decorative finial at the bottom of the shade.

If the problem persists after attempting these solutions, consult a qualified electrician or contact Westinghouse customer support.

8. Product Specifications

Feature	Detail
Model Number	6306500
Brand	Westinghouse
Fixture Type	Semi-Flush Mount Ceiling Fixture
Finish	Oil Rubbed Bronze
Shade Material	Frosted Glass
Number of Lights	2
Bulb Base	E26 (Medium)
Max Wattage per Bulb	60 Watts
Voltage	120 Volts
Dimensions (Diameter x Height)	14.5 inches x 12.31 inches
Item Weight	3.96 Pounds
Indoor/Outdoor Usage	Indoor
UPC	024034630651

9. Warranty Information

This Westinghouse light fixture is backed by a 5-year limited manufacturer's warranty against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the official Westinghouse website or contact customer service.

Optional protection plans may be available for extended coverage:

- 3-Year Protection Plan
- 4-Year Protection Plan
- Complete Protect (monthly renewal)

These plans are separate from the manufacturer's warranty and offer additional coverage. Details on these plans can be found at the point of purchase or through the plan provider.

10. Customer Support

For further assistance, technical support, or to inquire about replacement parts, please contact Westinghouse customer service. You can typically find contact information on the Westinghouse official website or on the product packaging.

Online Resources: Visit the official Westinghouse website for FAQs, product registration, and additional support documents.

Model Number: When contacting support, please have your model number (6306500) readily available for quicker service.