

Beyution XRT010

Beyution XRT010 Remote Control User Manual

Model: XRT010

INTRODUCTION

This manual provides instructions for the Beyution XRT010 Remote Control, designed for use with various VIZIO Edge LIT Razor LED LCD HDTV models. This remote control offers direct functionality without requiring programming for compatible VIZIO televisions.

PACKAGE CONTENTS

- 1 x Beyution XRT010 Remote Control

Note: AAA batteries are not included and must be purchased separately.

SETUP

1. Battery Installation

The XRT010 remote control requires two (2) AAA batteries for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

2. Initial Use

The Beyution XRT010 remote control is designed for immediate use with compatible VIZIO HDTV models. No programming or pairing is typically required. Simply install the batteries and point the remote towards your television.

OPERATING INSTRUCTIONS

This section details the functions of the buttons on your XRT010 remote control.



Image: The Beyution XRT010 remote control, a black, ergonomic device with clearly labeled buttons for TV operation.

Remote Control Button Functions

Button	Function
Power ()	Turns the television On or Off.
INPUT	Cycles through available input sources (e.g., HDMI 1, HDMI 2, AV).
CC	Activates or deactivates Closed Captions.
EXIT	Exits current menu or on-screen display.
INFO	Displays information about the current program or input.
MENU	Opens the television's main menu.
GUIDE	Accesses the electronic program guide (if available).
Navigation Arrows (▲ ◀ ▼ ▶)	Navigates through menus and options.
OK	Confirms a selection or enters a menu item.
BACK	Returns to the previous menu or screen.
VOL + / VOL -	Increases or decreases the volume level.
Mute ()	Mutes or unmutes the television audio.
CH ▲ / CH ▼	Changes the television channel up or down.
Number Pad (0-9)	Directly enters channel numbers.
WIDE	Adjusts the screen aspect ratio (functionality may vary by TV model).
Dash (-)	Used for entering sub-channels (e.g., 7-1).
Playback Controls (, , ,)	Control media playback (Rewind, Play/Pause, Stop, Fast Forward).
Record (●)	Initiates recording (requires compatible TV and recording device).

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Solution
---------	----------

Problem	Solution
Remote is not responding.	<ul style="list-style-type: none">◦ Check if the batteries are inserted correctly with the correct polarity.◦ Replace old batteries with new AAA batteries.◦ Ensure there are no obstructions between the remote and the TV's infrared sensor.◦ Point the remote directly at the TV.
Some buttons do not work.	<ul style="list-style-type: none">◦ This remote is designed for specific VIZIO models. Verify your TV model is listed as compatible.◦ Clean the remote control surface, especially around the non-working buttons, to remove any debris.◦ Replace batteries.
TV responds slowly to remote commands.	<ul style="list-style-type: none">◦ Replace batteries with fresh ones.◦ Ensure the remote is within effective range and pointed correctly.

SPECIFICATIONS

- **Model:** XRT010
- **Brand:** Beyution
- **Compatible Devices:** VIZIO HDTVs (Specific models listed in product description)
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** 7 x 2 x 0.7 inches
- **Weight:** 2.12 ounces (without batteries)
- **Special Feature:** Ergonomic design

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or contact Beyution customer service directly. Contact details may be available on the product packaging or the manufacturer's official website.

Please retain your proof of purchase for warranty claims.