

Beyution CT-RC1US-16

Beyution CT-RC1US-16 Replacement Remote Control User Manual

Model: CT-RC1US-16

INTRODUCTION

This manual provides comprehensive instructions for the Beyution CT-RC1US-16 replacement remote control. Designed for ease of use, this infrared remote control is compatible with a wide range of Toshiba TV models, offering a direct replacement without the need for complex programming. Please read this manual carefully to ensure proper operation and longevity of your remote control.

PRODUCT FEATURES

- **Model:** CT-RC1US-16
- **Connectivity:** Infrared (IR)
- **Material:** Durable ABS Plastic
- **Operating Distance:** Up to 10 meters (approximately 33 feet)
- **No Programming Required:** Ready to use with compatible Toshiba TVs upon battery installation.
- **Power Source:** 2 x AAA batteries (not included)

SETUP

1. Battery Installation

To begin using your remote control, you must first install the batteries. The Beyution CT-RC1US-16 requires two (2) AAA batteries.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and lift it off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



For product support
Go to:
www.tv.toshiba.com
Or call:
US & Canada Market 855.527.2411



Image: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

2. Initial Use

The Beyution CT-RC1US-16 remote control is designed for immediate use with compatible Toshiba TV models. No programming or setup is required. Once batteries are installed, point the remote towards your Toshiba TV and begin operation.

OPERATING INSTRUCTIONS

Remote Control Layout





Image: Front view of the Beyution CT-RC1US-16 remote control, highlighting the button layout.

The remote control features a standard layout for easy navigation and control of your Toshiba TV. Below is a description of key button functions:

- **POWER (Red Button):** Turns the TV on or off.
- **INPUT:** Cycles through available input sources (e.g., HDMI 1, AV, Component).
- **SLEEP:** Sets a timer for the TV to automatically turn off.
- **FREEZE:** Pauses the current picture on screen.
- **PIC MODE / PIC SIZE:** Adjusts picture settings and aspect ratio.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **FAV:** Accesses favorite channels.
- **VOL (+/-):** Increases or decreases the volume level.
- **CH (Up/Down Arrows):** Changes channels sequentially.
- **MUTE:** Silences the TV audio.
- **RECALL:** Returns to the previously viewed channel.
- **C.CAPTION:** Toggles closed captions on or off.
- **INFO:** Displays information about the current program or input.
- **Navigation Pad (Up/Down/Left/Right/ENTER):** Navigates menus and confirms selections.

- **MENU:** Opens the TV's main menu.
- **EXIT:** Closes the current menu or on-screen display.
- **BACK / CH RTN:** Returns to the previous menu screen or channel.
- **Playback Controls (EJECT, PAUSE/STEP, PLAY, STOP, SKIP, REW, FF):** Controls media playback functions for connected devices or built-in media players.

MAINTENANCE

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's performance diminishes (e.g., reduced range, inconsistent response). Always replace both batteries simultaneously with new ones of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Solution
Remote is not working.	<ul style="list-style-type: none"> • Ensure batteries are inserted correctly with proper polarity. • Replace old batteries with new AAA batteries. • Check for any obstructions between the remote and the TV's IR sensor. • Verify that the remote control is pointed directly at the TV's IR sensor.
Remote has limited range or intermittent response.	<ul style="list-style-type: none"> • Replace batteries with new ones. • Ensure there are no strong light sources (e.g., direct sunlight, fluorescent lights) interfering with the IR signal. • Reduce the distance between the remote and the TV.
Certain buttons do not respond.	<ul style="list-style-type: none"> • This remote is a replacement and may not support all advanced functions of certain specific TV models. • Ensure the TV is powered on and not in a menu that restricts button functionality.

SPECIFICATIONS

- **Product Dimensions:** 7 x 2 x 0.65 inches
- **Item Weight:** 1.76 ounces

- **Material:** ABS Plastic
- **Color:** Black
- **Batteries:** 2 AAA batteries required (not included)
- **Maximum Supported Devices:** 1 (Television)
- **Connectivity Technology:** Infrared

COMPATIBLE TV MODELS

This Beyution CT-RC1US-16 remote control is compatible with numerous Toshiba TV models, including but not limited to:

- 43L310U, 43L420U, 49L310U, 49L420U, 55L310U, 65L350U
- 19AV600U, 19AV600UZ, 19C100, 19C100U, 19C10U, 19C1D, 19C1DU
- 19L4200, 19L4200U, 19SL400, 19SL400U, 19SL410U, 19SL410X
- 22AV600, 22AV600U, 22AV600UZ, 22C10, 22C100, 22C100U, 22C10U
- 22SL400, 22SL400U, 23L1350U, 23L2300U, 24L4200, 24L4200U
- 24SL410U, 24SL410UM, 26C10, 26C100, 50L420U, 9AV600
- 32C10, 32C110, 32DT1, 32DT1U, 32DT2U, 32E20U, 32FT2U
- 32L1350, 32L1400, 32L4200, 32SL400, 65L350L
- And many other Toshiba TV models.

If your specific TV model is not listed, please refer to the product listing or contact customer support to verify compatibility before purchase.

WARRANTY AND SUPPORT

This Beyution CT-RC1US-16 remote control comes with a **6-month warranty period** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.

For any questions regarding product compatibility, setup, or if you encounter any issues with your remote control, please contact Beyution customer support. We are committed to providing satisfactory solutions and assistance.