

[Manuals.plus](#) /

› [Hotpoint](#) /

› Hotpoint DFP58T94AUK Dishwasher Basket Clip Instruction Manual

Hotpoint DFP58T94AUK

Hotpoint DFP58T94AUK Dishwasher Basket Clip Instruction Manual

Model: DFP58T94AUK

1. INTRODUCTION

This manual provides essential information for the proper installation, use, and maintenance of your Hotpoint DFP58T94AUK Dishwasher Basket Clip. This clip is designed to securely hold small or lightweight items within your dishwasher's basket, preventing them from being dislodged during the wash cycle. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

2. SAFETY INFORMATION

- Keep this product out of reach of children to prevent choking hazards, as it contains small parts.
- Ensure the clip is properly secured before starting the dishwasher cycle to prevent items from becoming loose and potentially damaging the appliance.
- Do not attempt to modify the clip. Use it only for its intended purpose.
- Inspect the clip regularly for any signs of wear or damage. Replace if necessary.

3. SETUP AND INSTALLATION

The Hotpoint DFP58T94AUK clip is designed for easy installation into your dishwasher's basket.

1. **Identify Placement:** Locate a suitable position within your dishwasher basket where the clip can effectively secure items without obstructing spray arms or other moving parts.
2. **Attach the Clip:** The clip features a rectangular opening at one end. Slide this opening onto a wire or bar of the dishwasher basket. Ensure it clicks into place securely.
3. **Secure Items:** Place the item you wish to secure (e.g., a small lid, a lightweight plastic container) between the two prongs of the clip. Gently press the item down until it is held firmly by the clip.



This image displays the Hotpoint DFP58T94AUK dishwasher basket clip. It is a gray, elongated plastic component featuring a rectangular opening at one end for attachment and two flexible prongs along its length, designed to hold items securely within a dishwasher rack.

4. OPERATING INSTRUCTIONS

Once installed, the dishwasher basket clip operates passively to hold items in place during the wash cycle. No active operation is required beyond securing the items.

- Ensure items are fully inserted into the clip's prongs to prevent them from becoming loose.
- Avoid overloading the clip or attempting to secure items that are too large or heavy for its design.
- After the wash cycle, carefully remove the secured items from the clip.

5. MAINTENANCE

The dishwasher basket clip requires minimal maintenance.

- The clip is dishwasher safe and will be cleaned along with your dishes during regular cycles.
- If excessive food residue accumulates, you may hand wash the clip with warm, soapy water.
- Periodically check the clip for any cracks, breaks, or signs of weakening plastic. A damaged clip may not hold items securely and should be replaced.

6. TROUBLESHOOTING

- **Issue: Items are not held securely.**

Solution: Ensure the item is fully inserted between the prongs. Check if the clip itself is firmly attached to the dishwasher basket. The clip might be worn or damaged; consider replacement.

- **Issue: Clip detaches from the basket.**

Solution: Verify that the rectangular opening is correctly engaged with the basket wire. If the clip's attachment mechanism is loose, it may be damaged and require replacement.

- **Issue: Clip appears broken or cracked.**

Solution: Discontinue use immediately and replace the clip to prevent potential damage to your dishwasher or dishes.

7. SPECIFICATIONS

Model Number	DFP58T94AUK
--------------	-------------

Brand	Hotpoint
Material	Durable Plastic
Color	Gray
Intended Use	Securing small items in dishwasher baskets

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or to obtain technical support for your Hotpoint DFP58T94AUK Dishwasher Basket Clip, please refer to the original purchase documentation or visit the official Hotpoint website. You may also contact Hotpoint customer service directly for assistance.

Hotpoint Customer Service: Please refer to your regional Hotpoint website for contact details.

© 2023 Hotpoint. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01LVXR4FF>

More documents and user manuals: <https://manuals.plus/>