**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**RadioShack Moon Walker**

# RadioShack Moon Walker Radio Controlled Kit

INSTRUCTION MANUAL

## 1. Introduction

This manual provides essential instructions for the assembly, operation, and maintenance of your RadioShack Moon Walker Radio Controlled Kit. The Moon Walker is a build-it-yourself kit designed to introduce users to the principles of radio control and electric motors through hands-on construction.

## 2. Safety Information

- **Adult Supervision:** This kit is recommended for ages 10 and up. Adult supervision is advised during assembly and operation, especially when handling small parts and batteries.
- **Battery Safety:** Always use the correct type and number of batteries (6x AAA batteries are required, not included). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove batteries if the device will not be used for an extended period.
- **Small Parts:** The kit contains small parts that could be a choking hazard for young children. Keep out of reach of children under 3 years old.
- **Electrical Components:** Handle electronic components with care. Do not expose to water or extreme temperatures.

## 3. Setup and Assembly

The RadioShack Moon Walker is a self-assembly kit. Detailed, illustrated instructions are included within the product packaging to guide you through each step of the construction process. Please refer to those instructions for specific assembly details.
**Battery Installation:** The Moon Walker requires six (6) AAA batteries for operation (three for the vehicle, three for the remote control). Ensure batteries are inserted with the correct polarity as indicated in the battery compartments.
**Assembly Tips:** Some components may fit together closely. Exercise care and patience during assembly to avoid damaging parts. Follow the included step-by-step guide carefully.



*This image displays the fully assembled RadioShack Moon Walker. It features a transparent blue body with yellow accents, a prominent blue satellite dish antenna on its back, and four sturdy blue wheels. The design suggests a compact, futuristic rover.*

## 4. Operating Instructions

Once assembled and batteries are installed in both the Moon Walker and its remote control, you are ready to operate your vehicle.

- **Power On:** Turn on the power switch on both the Moon Walker and the remote control.
- **Pairing:** The vehicle and remote should automatically pair. If not, refer to the specific pairing instructions in the kit's manual.
- **Controls:** Use the joysticks or buttons on the remote control to maneuver the Moon Walker. Typically, one control manages forward/backward movement, and another controls turning left/right.
- **Operating Environment:** Operate the Moon Walker on flat, clean surfaces indoors for best performance. Avoid water, sand, or rough terrain.
- **Range:** Maintain a reasonable distance between the remote control and the Moon Walker to ensure consistent signal reception.

## 5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the Moon Walker. Do not use harsh chemicals or liquids.
- **Battery Care:** Remove batteries from both the Moon Walker and the remote control if the device will not be used for an extended period to prevent leakage.
- **Storage:** Store the Moon Walker in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. Troubleshooting

- **Moon Walker Not Moving:**
  - Check if batteries are correctly installed and fully charged in both the Moon Walker and the remote control.
  - Ensure both the vehicle and remote control are powered on.
  - Verify that the vehicle and remote are properly paired.
- **Poor Control or Short Range:**

- Replace batteries in both the vehicle and remote control.
- Ensure there are no obstructions or strong interference sources between the remote and the Moon Walker.
- Operate within the recommended range.

- **Parts Not Fitting:** Refer to the detailed assembly instructions provided with the kit. Ensure you are using the correct parts for each step and applying gentle, even pressure.

## 7. Specifications

| Item | Specification |
|---|---|
| **Model** | Moon Walker |
| **Brand** | RadioShack |
| **ASIN** | B01LVXWR34 |
| **Package Dimensions** | 9 x 5.7 x 3.5 inches |
| **Item Weight** | 15.2 ounces |
| **Recommended Age** | 10 years and up |
| **Manufacturer** | radio shack |

## 8. Warranty Information

Specific warranty details for the RadioShack Moon Walker kit are not provided in the available product information. Please refer to the product packaging or contact RadioShack directly for warranty inquiries.

## 9. Customer Support

For further assistance, technical support, or inquiries regarding your RadioShack Moon Walker, please visit the official RadioShack website or contact their customer service department through the contact information provided on their official channels.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B01LVXWR34**

More documents and user manuals: **https://manuals.plus/**