

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOMCOM](#) /

› [HOMCOM 56-inch Electronic 5-Rifle Gun Security Cabinet with Digital Keypad](#)

HOMCOM 842525100823

HOMCOM 56-inch Electronic 5-Rifle Gun Security Cabinet Instruction Manual

Model: 842525100823

1. INTRODUCTION

Thank you for choosing the HOMCOM 56-inch Electronic 5-Rifle Gun Security Cabinet. This manual provides essential information for the safe and proper installation, operation, and maintenance of your new security cabinet. Please read all instructions carefully before use and retain this manual for future reference.

This security cabinet is designed to provide secure storage for up to five rifles, ammunition, and other valuables. It features a robust steel construction, a digital keypad for quick access, and a manual key override for emergency entry. The interior includes a padded rifle rack and a separate lockable compartment for smaller items.



Image 1.1: The HOMCOM 56-inch Electronic 5-Rifle Gun Security Cabinet in a typical home environment.

2. SAFETY INFORMATION

- Always store firearms unloaded and locked.
- Keep keys and digital codes in a secure location, inaccessible to unauthorized individuals, especially children.
- Ensure the cabinet is securely mounted to a wall or floor to prevent tipping and unauthorized removal.
- Do not store flammable materials or hazardous chemicals inside the cabinet.
- Regularly check the cabinet for any signs of damage or tampering.
- This cabinet is not fireproof or waterproof. Take appropriate precautions for fire and water protection if necessary.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly and installation. If any parts are missing or

damaged, contact customer support.

- HOMCOM 56-inch Electronic 5-Rifle Gun Security Cabinet
- Digital Keypad (pre-installed)
- Manual Override Keys (2 sets)
- Mounting Hardware (Lag bolts, washers, wall anchors)
- Padded Rifle Rack (pre-installed)
- Small Internal Lock Box with Key
- Instruction Manual






Image 3.1: Overview of included mounting hardware, keys, and batteries.

4. SETUP AND INSTALLATION

4.1 Unpacking

1. Carefully remove the cabinet from its packaging.
2. Inspect the cabinet for any shipping damage. Report any damage to the retailer immediately.
3. Locate the manual override keys, which are typically secured to the outside of the cabinet or within a small compartment. Do not store these keys inside the cabinet.

4.2 Battery Installation

The digital keypad requires batteries (not included) to operate. Typically, 4 AA batteries are needed.

1. Locate the battery compartment on the back of the digital keypad.
2. Open the compartment and insert the required batteries, ensuring correct polarity (+/-).
3. Close the battery compartment securely.

4.3 Initial Code Setting

Refer to the specific instructions provided with your keypad for setting the initial access code. This usually involves pressing a reset button inside the door or battery compartment, entering a new code, and confirming it.

4.4 Mounting the Cabinet

For optimal security and to prevent tipping, the cabinet must be securely mounted to a wall or floor. The cabinet features pre-drilled holes on the back panel for wall mounting.

HOLD 5 RIFLES

Rifle rack included for holding 5 rifles



Image 4.1: Product dimensions for planning installation space.

1. Choose a suitable location for the cabinet, preferably against a solid wall or structural stud.
2. Mark the drilling points on the wall using the pre-drilled holes on the back of the cabinet as a template.
3. Drill pilot holes into the wall at the marked locations. Use appropriate drill bits for your wall material (wood, drywall, concrete).
4. Align the cabinet with the drilled holes and secure it using the provided lag bolts, washers, and wall anchors. Ensure all bolts are tightened securely.
5. Verify that the cabinet is stable and cannot be easily tipped or removed.

5. OPERATING INSTRUCTIONS

5.1 Opening the Cabinet

The cabinet can be opened using the digital keypad or the manual override keys.

2 WAYS TO OPEN THE DOOR



Keypad Access



2 Manual Override Keys

Image 5.1: Demonstrating keypad access and manual key override.

Using the Digital Keypad:

1. Enter your programmed access code on the keypad.
2. If the code is correct, the keypad will indicate successful entry (e.g., a green light or beep).
3. Within a few seconds, turn the handle clockwise to open the door.

Using the Manual Override Keys:

1. Locate the keyhole cover on the keypad panel.
2. Remove the cover and insert one of the manual override keys.
3. Turn the key clockwise while simultaneously turning the handle clockwise to open the door.



Image 5.2: Detail of the digital keypad and manual key entry point.

5.2 Closing and Locking the Cabinet

1. Close the cabinet door firmly.
2. Turn the handle counter-clockwise to engage the locking bolts. The cabinet will automatically lock.

5.3 Changing the Digital Code

The process for changing the digital code varies by keypad model. Generally, it involves:

1. With the door open, locate the reset button on the inside of the door or battery compartment.
2. Press the reset button. The keypad will typically beep or flash.
3. Enter your new code (usually 3-8 digits) followed by a confirmation key (e.g., '#', 'B', or 'E').
4. Test the new code with the door open before closing it.

5.4 Internal Storage Features

The cabinet is equipped with internal features for organized storage:

- **Padded Rifle Rack:** The interior features a padded rack designed to hold up to five rifles securely, preventing scratches and damage.



Image 5.3: The cabinet interior with space for five rifles.



Image 5.4: Detail of the protective padded rifle rack.

- **Internal Lock Box:** A smaller, separate lockable compartment is located at the top of the cabinet, ideal for storing ammunition, handguns, or other small valuables.

SMALL SAFE INSIDE

For storing your small items such as bullet or cash




Image 5.5: The small internal lock box for additional security.

6. MAINTENANCE

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or electronic components.
- **Battery Replacement:** The keypad will typically indicate a low battery warning (e.g., a specific light or sound). Replace all batteries promptly when this occurs to ensure continued operation. Use the manual override keys if batteries die completely.
- **Mounting Check:** Periodically check the mounting bolts to ensure they remain tight and secure.
- **Lock Mechanism:** If the door mechanism feels stiff, a small amount of graphite lubricant can be applied to the moving parts of the locking bolts. Do not use oil-based lubricants.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keypad does not respond.	Dead or incorrectly installed batteries.	Replace batteries, ensuring correct polarity. Use manual override keys if necessary.
Cabinet will not open with digital code.	Incorrect code entered; batteries low; keypad malfunction.	Re-enter code carefully. Replace batteries. Use manual override keys. Contact customer support if issue persists.
Door is difficult to open or close.	Locking mechanism friction; door misalignment.	Apply graphite lubricant to locking bolts. Check door hinges for alignment. Ensure cabinet is level.
Manual override key does not work.	Key not fully inserted; internal lock mechanism issue.	Ensure key is fully inserted and turned correctly. If a critical piece related to the key override is loose (as reported by some users), contact customer support.

8. SPECIFICATIONS

- Brand:** HOMCOM
- Model Number:** 842525100823
- Material:** Alloy Steel
- Color:** Black
- Product Dimensions:** 13.75"D x 11.75"W x 57"H
- Lock Type:** Digital Lock with Manual Override
- Mounting Type:** Wall Mount (hardware included)
- Special Feature:** Removable Padded Rifle Rack, Internal Lock Box
- Alarm:** Anti-theft (specific alarm features may vary by model)
- Water Resistance Level:** Not Water Resistant

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact HOMCOM customer service directly. Keep your purchase receipt as proof of purchase.

Customer Service Contact: Please visit the official HOMCOM website for the most up-to-date contact information.

