

[Manuals.plus](#) /

> [Globo](#) /

> Globo Randi Wall Lamp User Manual

## Globo 78293

# Globo Randi Wall Lamp User Manual

Model: 78293

Brand: Globo

## 1. INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your Globo Randi Wall Lamp. Please read this manual thoroughly before installation and use to ensure proper function and safety.

The Globo Randi Wall Lamp is a modern LED lighting fixture designed for wall mounting, featuring a white metal body and glass elements, providing warm white light.



Figure 1.1: Close-up view of the Globo Randi Wall Lamp.

## 2. SAFETY INFORMATION

---

### Important Safety Instructions:

- Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning.

- Installation should be performed by a qualified electrician in accordance with local electrical codes.
- Do not modify the lamp in any way.
- Ensure the mounting surface can support the weight of the fixture.
- Keep away from water and moisture unless specified for wet locations (IP44 rating indicates protection against solid objects greater than 1mm and splashing water from any direction).
- Do not look directly into the LED light source.
- Recycle old light bulbs and dispose of broken lamps properly. Refer to local regulations for recycling and disposal.

### 3. PACKAGE CONTENTS

---

Verify that all components are present and undamaged:

- 1 x Globo Randi Wall Lamp fixture
- 1 x LED Bulb

### 4. INSTALLATION INSTRUCTIONS

---

**Tools Required:** Drill, screwdriver, wire strippers, voltage tester.

1. **Preparation:** Turn off power at the main circuit breaker before beginning installation.
2. **Mounting:** Mark the desired mounting location on the wall. Use the fixture's base as a template. Drill pilot holes and insert wall anchors if necessary. Secure the mounting bracket to the wall.
3. **Wiring:** Connect the lamp's wires to the household electrical wires according to local electrical codes (e.g., live to live, neutral to neutral, ground to ground). Ensure all connections are secure.
4. **Fixture Attachment:** Carefully attach the lamp fixture to the mounting bracket, securing it with the provided screws.
5. **Bulb Installation:** Insert the included LED bulb into the lamp socket.
6. **Testing:** Restore power at the main circuit breaker. Turn on the light switch to test the lamp's functionality.



Figure 4.1: The Globo Randi Wall Lamp installed, demonstrating its light distribution.

## 5. OPERATING INSTRUCTIONS

---

The Globo Randi Wall Lamp is operated via a standard wall switch connected to its electrical circuit.

- **Turning On/Off:** Flip the connected wall switch to turn the lamp on or off.
- **Light Direction:** The lamp features adjustable light direction. Gently pivot the light head to direct the light as desired.
- **Dimmable Feature:** This lamp is dimmable. If connected to a compatible dimmer switch (not included), you can adjust the light intensity.



Figure 5.1: Two Globo Randi Wall Lamps illuminating a dining area.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:** Disconnect power before cleaning. Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** The lamp uses an integrated LED bulb. If replacement is ever needed, ensure power is off and consult a qualified electrician.
- **Inspection:** Periodically check for loose connections or damage to the wiring.

## 7. TROUBLESHOOTING

---

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

|                           |                                                              |                                                                                                          |
|---------------------------|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| Lamp does not turn on.    | No power to the circuit, loose wiring, faulty switch.        | Check circuit breaker. Verify wiring connections. Test switch. Consult an electrician if issues persist. |
| Light flickers.           | Loose wiring, incompatible dimmer switch, faulty LED driver. | Check wiring. Ensure dimmer switch is LED compatible. Contact support if flickering continues.           |
| Lamp makes buzzing noise. | Incompatible dimmer switch, loose components.                | Ensure dimmer switch is LED compatible. Check for loose parts.                                           |

## 8. SPECIFICATIONS

---

| Feature                  | Detail            |
|--------------------------|-------------------|
| Brand                    | Globo             |
| Model Number             | 78293             |
| Product Dimensions       | 10 x 7.5 x 7 cm   |
| Item Weight              | 420 grams         |
| Material                 | Metal, Glass      |
| Color (Fixture)          | White             |
| Color (Light)            | Warm White        |
| Style                    | Modern            |
| Light Source Type        | LED               |
| Number of Lights         | 2                 |
| Wattage                  | 3 watts           |
| Voltage                  | 230 Volts         |
| Energy Efficiency Class  | A                 |
| IP Rating                | 44                |
| Dimmable                 | Yes               |
| Included Components      | Lampadina (Bulb)  |
| Switch Installation Type | Wall Mount        |
| First Available Date     | November 24, 2016 |

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact Globo customer service or refer to the product packaging for specific details.

Recycling information for light bulbs and instructions on how to clean and dispose of broken or damaged lamps can be found via local recycling guidelines or relevant environmental agencies.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B01LXFOXP3>

More documents and user manuals: <https://manuals.plus/>