Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine SG_B01LXLCPH5_US

JustFine Replacement Remote Control

Instruction Manual for Samsung Smart LED HDTV Models

1. Introduction and Overview

This manual provides instructions for the JustFine replacement remote control, designed for use with various Samsung Smart LED HDTV models. This remote is a direct replacement and requires no programming for the listed compatible models.

Compatible Samsung TV Models: UN32H5203AFXZA, UN32H5201, UN40H6203AFXZA, UN50H6201AFXZA, UN60H6203AFXZA.





Image: The JustFine replacement remote control, black in color, viewed from an angled top-down perspective, showing its ergonomic shape and central navigation button.

2. Setup

This replacement remote control is pre-programmed and does not require any additional setup or code entry. Simply insert batteries to begin operation.

2.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control.

3. Operating Instructions

Once batteries are installed, the remote control is ready for immediate use with your compatible Samsung Smart LED HDTV. Point the remote directly at your television and press the desired function button.

3.1. Basic Functions

- **Power Button:** Turns the television on or off.
- **Volume Up/Down:** Adjusts the audio level.
- **Channel Up/Down:** Changes television channels.
- **Navigation Pad (Up/Down/Left/Right/Enter):** Used to navigate menus and select options on the screen.
- **Smart Hub/Home Button:** Accesses the Smart Hub or home screen of your Samsung TV.
- **Back/Return Button:** Returns to the previous screen or menu.

Note: Specific button layouts and functions may vary slightly depending on the original remote model it replaces.

4. Maintenance

4.1. Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

4.2. Battery Replacement

Replace batteries when the remote's performance degrades or it stops responding. Always replace both batteries at the same time with new ones of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.

4.3. Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the television's infrared sensor.
  - Make sure you are within the effective range of the television's infrared receiver.
- **Some functions not working:**
  - Verify that your television model is listed as compatible.
  - Some advanced functions specific to original remotes (e.g., voice control, motion control) may not be supported by this replacement remote.

6. Specifications

Feature	Detail
Brand	JustFine
Model Number	SG_B01LXLCPH5_US
Product Dimensions	8 x 2 x 0.5 inches
Item Weight	1.58 ounces

Feature	Detail
Connectivity Technology	Infrared
Compatible Devices	Television (Samsung Smart LED HDTV)
Max Number of Supported Devices	1
Special Feature	Ergonomic

7. Warranty and Support

This product comes with a 30-day quality warranty and a money-back guarantee, ensuring a hassle-free return process if needed.
For any problems or inquiries regarding your JustFine replacement remote control, please contact us via email. Our support team is available to assist you.
Contact Information: Please refer to your purchase documentation or the seller's information on the platform where the product was acquired for specific contact details.

© 2026 JustFine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01LXLCPH5

More documents and user manuals: **https://manuals.plus/**