

[Manuals.plus](#) /

› [NENRENT](#) /

› NENRENT S570 Bluetooth Earbud Instruction Manual

NENRENT S570

NENRENT S570 Bluetooth Earbud User Manual

Model: S570 | Brand: NENRENT

1. INTRODUCTION

Welcome to the NENRENT S570 Bluetooth Earbud user manual. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbud. The NENRENT S570 is a compact, lightweight, and invisible wireless earbud designed for hands-free calls and clear audio playback. It features Bluetooth 4.1 connectivity and multipoint technology, allowing connection to two devices simultaneously.

2. WHAT'S IN THE BOX


Upon unboxing your NENRENT S570 Bluetooth Earbud, you should find the following items:

- 1x S570 Bluetooth Earbud
- 1x USB Charging Cable
- 1x Carrying Case
- 1x User Manual

NENRENT

SECURE AND CLEAR CALLS

Better sound quality



Happy Life and Exercise

Comfort Fit
In-Ear Design, invisible
Longer music playing time

Image: All items included in the NENRENT S570 package.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your NENRENT S570 Earbud:

- **Multifunctional Button:** Used for power on/off, play/pause, answering/ending calls, and redialing.
- **LED Indicator:** Displays status (e.g., charging, pairing).
- **Charging Port:** Connects to the USB charging cable.
- **Eartip:** Provides a comfortable and secure fit in the ear canal.



Image: Labeled components of the NENRENT S570 Earbud.

Video: An official overview of the NENRENT S570 Single Bluetooth Earbud, highlighting its features and design.

4. SETUP

4.1. Charging the Earbud

Before first use, fully charge your NENRENT S570 earbud. The earbud is equipped with a high-performance rechargeable Lithium-poly 60mAh battery.

1. Connect the small end of the provided USB charging cable to the charging port on the earbud.
2. Connect the USB-A end of the cable to a USB power source (e.g., computer USB port, wall adapter).
3. The LED indicator will light up (typically red) to show it is charging.
4. Once fully charged (approximately 1-2 hours), the LED indicator will change color (typically blue) or turn off.

A full charge provides up to 6 hours of call time and 4-6 hours of music playback (at 40-50% volume), with up to 130 hours of standby time.

1 HOUR CHARGING = 6 HOURS PLAYING



Image: Visual representation of charging efficiency.

4.2. Pairing with a Device

The NENRENT S570 uses Bluetooth 4.1 for wireless connectivity and supports multipoint technology, allowing connection to two devices simultaneously within a 10-meter range.

1. Ensure the earbud is turned off.
2. Press and hold the Multifunctional Button for approximately 5 seconds until the LED indicator flashes alternately blue and red. This indicates pairing mode.
3. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and enable Bluetooth.
4. Search for available devices and select "NENRENT S570" from the list.
5. Once successfully paired, the LED indicator will stop flashing and remain solid blue (or turn off, depending on the model).

CONNECT TWO DEVICES SIMULTANEOUSLY



Bluetooth 4.1



Up to 30 Ft

Built-in incoming
call reminder

Support Music Playing



Image: The earbud's ability to connect to two devices concurrently.

5. OPERATING THE EARBUD

5.1. Basic Functions

The multifunctional button controls various operations:

- **Power On:** Press and hold the Multifunctional Button for 3 seconds.
- **Power Off:** Press and hold the Multifunctional Button for 3 seconds.
- **Play/Pause Music:** Single press the Multifunctional Button.
- **Answer/End Call:** Single press the Multifunctional Button during an incoming call.
- **Redial Last Call:** Double press the Multifunctional Button.

5.2. Compatibility

The NENRENT S570 is widely compatible with most Bluetooth-enabled devices, providing clear HD audio for various media:

- iPhone/iPad Series

- Samsung Galaxy S5/S6/S7 Series
- Samsung Galaxy Note 3/4/5/7 Series
- iPod Nano Series
- Laptops & Tablets
- Other Android Smartphones



Wide compatibility

Compatible with most Bluetooth enabled devices, such as Apple iPhone, IPAD, Samsung, HUAWEI, Other Android, etc.,

Image: Broad device compatibility of the NENRENT S570.

5.3. Wearing the Earbud

The NENRENT S570 is designed for universal fit and comfort:

- **Ergonomic Design:** The earbud is designed to fit comfortably in either your right or left ear.
- **Super-Lightweight:** Weighing only 0.48 ounces (13.61g), it ensures comfort during extended wear.
- **Secure Fit:** Guaranteed to be secure and stable during intense exercise such as running, climbing, riding, and other

active sports.



UNIVERSAL FIT

super-lightweight design
and a range of eartips
ensure. a perfect fit
any ear.

Image: The earbud's universal fit in the ear.



Image: Various scenarios where the NENRENT S570 can be used.

6. MAINTENANCE

To ensure the longevity and optimal performance of your NENRENT S570 earbud, follow these maintenance tips:

- **Cleaning:** Regularly wipe the earbud with a soft, dry cloth to remove dust and debris. For the eartip, you may gently remove it and clean with a damp cloth, ensuring it is completely dry before reattaching.
- **Battery Care:** Avoid completely draining the battery frequently. While the earbud has protection, prolonged overcharging or deep discharge can affect battery life. Charge the earbud when the low battery notification is given.
- **Storage:** When not in use, store the earbud in its provided carrying case to protect it from dust, moisture, and physical damage.

7. TROUBLESHOOTING

If you encounter issues with your NENRENT S570 earbud, try the following solutions:

Problem	Possible Cause	Solution
Earbud won't turn on	Low battery	Charge the earbud fully.
Cannot pair with device	Not in pairing mode; Bluetooth off on device; Out of range	Ensure earbud is flashing blue/red. Turn on device Bluetooth. Move device closer (within 10m).
Poor sound quality / Intermittent connection	Weak signal; Obstructions; Improper fit	Move closer to the connected device. Ensure no physical obstructions. Adjust eartip for a snug fit. Avoid placing the connected device in a pocket if interference occurs.
Earbud falls out easily	Improper fit of eartip	Ensure the eartip is correctly attached and provides a secure fit for your ear canal.

8. SPECIFICATIONS

Feature	Detail
Model Name	NENRENT S570
Connectivity Technology	Bluetooth
Bluetooth Version	4.1
Bluetooth Range	10 Meters
Battery Life (Call Time)	Up to 6 hours
Battery Life (Music Playback)	4-6 hours (at 40-50% volume)
Standby Time	Up to 130 hours
Charging Time	1-2 hours
Item Weight	0.48 ounces (13.61 g)
Product Dimensions	0.79 x 0.69 x 0.57 inches
Water Resistance Level	Not Water Resistant
Material	Plastic
Included Components	Earbud, USB Charging Cable, Carrying Case, User Manual

9. WARRANTY AND SUPPORT

The NENRENT S570 Bluetooth Earbud comes with a 1-Year Worry-Free Warranty. For any questions or concerns, 24-hours email contact service is available. Please refer to the contact information provided in your product packaging or on the official NENRENT website for support.

Important Information

Safety Warning: To prevent hearing damage, avoid listening at high volume levels for long periods.

Environmental Awareness: When using the earbud in public or while engaging in activities like walking or running, ensure one ear is free to maintain awareness of your surroundings for safety.

Disposal: Dispose of the product responsibly according to local regulations for electronic waste.

For more products and information, visit the [NENRENT Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question