

[Manuals.plus](#) /

› [Langsdom](#) /

› Langsdom F9 Wired Earbuds User Manual

Langsdom F9

Langsdom F9 Wired Earbuds User Manual

Model: F9

INTRODUCTION

Thank you for choosing Langsdom F9 Wired Earbuds. This manual provides essential information for the proper use and care of your new headphones. Please read it thoroughly before using the product to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Langsdom F9 earbuds are designed for a comfortable listening experience with clear audio and powerful bass. They feature an in-line remote control and microphone for convenient management of music and calls.

Key Features:

- In-ear design for a comfortable, noise-isolating fit.
- High sound quality with enhanced bass.
- Integrated microphone for hands-free communication.
- Remote control for music playback and call management.
- Durable Thermoplastic Elastomer (TPE) cable.

Components:

High Quality Sound



Sensitivity



Metal Bass



Binaural Stereo



High Frequency Range






Image: Exploded view showing the dynamic speaker, filter mesh, 7 micron biology diaphragm, and metal housing of the earbud.

The F9 earbuds incorporate a dynamic speaker, a 7-micron biology diaphragm, and a metal housing for optimal sound reproduction. A filter mesh protects the internal components.



Amazing sound effects

LIVE IN CONCERT



High analysis

SENSE OF MUSICAL SPACE

Image: Illustration of Langsdom F9 earbuds with icons representing high sensitivity, metal bass, binaural stereo, and high frequency range. These earbuds are engineered for high sensitivity, robust metal bass, binaural stereo sound, and an extended high-frequency range, delivering a rich audio experience.

SETUP

Connecting to Your Device:

1. Locate the 3.5mm audio jack on your smartphone, tablet, MP3 player, or other compatible device.
2. Insert the 3.5mm plug of the Langsdom F9 earbuds firmly into the device's audio jack.
3. Ensure the connection is secure for optimal sound transmission.



Image: Close-up of the in-line remote control with a clear microphone and remote button, alongside the 3.5mm audio plug.

Wearing the Earbuds:

- Identify the left (L) and right (R) earbuds.
- Gently insert each earbud into the corresponding ear canal.
- Adjust the earbuds until they fit snugly and comfortably. A proper fit enhances sound quality and noise isolation.

Half in ear design

Ensuring it's always stable and snug in your ear



Image: A woman wearing Langsdom F9 earbuds, illustrating the "half in ear design" for stable and snug fit.

OPERATING INSTRUCTIONS

The Langsdom F9 earbuds feature an in-line remote control for convenient audio and call management.

Remote Control Functions:

- **Play/Pause Music:** Press the remote button once.
- **Next Track:** Press the remote button twice quickly.
- **Previous Track:** Press the remote button three times quickly.
- **Answer/End Call:** Press the remote button once during an incoming call or an active call.
- **Reject Call:** Press and hold the remote button for approximately 2 seconds during an incoming call.

Note: Volume control is typically managed directly on your connected device, as these earbuds do not feature an in-line volume adjustment.

Microphone Usage:

The integrated microphone allows for hands-free calls. Ensure the microphone is positioned clearly, typically near your mouth, for optimal voice pickup. Avoid covering the microphone during calls.

MAINTENANCE

Cleaning:


- Regularly clean the earbuds, especially the ear tips and speaker grilles, to prevent wax buildup and maintain sound quality.
- Use a soft, dry cloth to wipe the exterior of the earbuds and cable.
- For ear tips, you may gently remove them and clean with a mild soap solution, then rinse thoroughly and ensure they are completely dry before reattaching.
- Do not use harsh chemicals or abrasive materials.

Storage:

- When not in use, store your earbuds in the provided protective case to prevent tangling and damage.
- Avoid extreme temperatures and humidity.
- Do not wrap the cable too tightly around the earbuds, as this can cause internal wire damage over time.

F9

Remote Control & Microphone



or



Image: Langsdom F9 earbuds shown alongside their compact, round protective case.

TROUBLESHOOTING

If you encounter issues with your Langsdom F9 earbuds, please refer to the following common solutions:

Problem	Possible Cause / Solution
No sound or low sound from one or both earbuds.	• Ensure the 3.5mm plug is fully inserted into the device's audio jack. • Check the volume level on your connected device. • Test the earbuds with another device to rule out a device-specific issue. • Inspect the cable for any visible damage or kinks. • Clean any debris or earwax from the earbud speaker grilles.

Problem	Possible Cause / Solution
Microphone not working or poor call quality.	• Ensure the microphone is not covered. • Check if your device's settings are configured to use the external microphone. • Test the microphone with another application or device. • Avoid excessive movement of the cable during calls, as this can introduce static.
Earbuds fall out easily.	• Ensure you are wearing the left (L) and right (R) earbuds in the correct ears. • Adjust the angle and depth of insertion for a more secure fit.

SPECIFICATIONS

Feature	Detail
Model Name	F9
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Frequency Response	20000 Hz
Sensitivity	119 dB
Material	Thermoplastic Elastomer (TPE)
Control Type	Remote Control
Special Feature	Built-in Microphone, Noise Isolation
Ear Placement	In Ear
Item Weight	0.9 Ounces
Product Dimensions	5.9 x 1.8 x 4.2 inches
Included Components	Protective Case
Water Resistance Level	Not Water Resistant

WARRANTY INFORMATION

Langsdorn F9 Wired Earbuds are backed by a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Langsdom customer service. Refer to the packaging or the official Langsdom website for the most current contact information.

You can also visit the [Langsdom Store on Amazon](#) for more product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question