Decathlon 8326425

Decathlon Domyos Treadmill Belt Lubricant User Manual

Model: 8326425

1. Product Overview

The Decathlon Domyos Treadmill Belt Lubricant is specifically designed for maintaining the running belt of your treadmill. Regular lubrication is essential to extend the lifetime of your treadmill and ensure smooth, quiet operation. This 150 ml bottle contains 100% silicone formula, which helps to limit wear and reduce noise caused by friction between the belt and the deck.



Image: The Decathlon Domyos Treadmill Belt Lubricant bottle, 150 ml, with a red cap.

2. Safety Information

- **Keep out of reach of children and pets.**This product is for treadmill maintenance only.
- Avoid contact with eyes. In case of contact, rinse thoroughly with water.
- Do not ingest. If swallowed, seek medical attention immediately.
- Use in a well-ventilated area.
- Store in a cool, dry place, away from direct sunlight and heat sources.

- Dispose of the bottle responsibly according to local regulations.

3. Setup

Before applying the lubricant, ensure your treadmill is turned off and unplugged from the power source. This is crucial for safety. Clean any dust or debris from the treadmill belt and deck surface using a clean cloth. Ensure the area around the treadmill is clear to allow for easy access to the belt.



Image: The lubricant bottle with its red cap removed, ready for application.

4. Operating Instructions

Follow these steps to properly lubricate your treadmill belt:



Image: A close-up view of the lubricant bottle's red nozzle, designed for precise application.

1. **Prepare the Treadmill:** Ensure the treadmill is off and unplugged. Carefully lift one side of the running belt to expose the deck underneath.
2. **Apply Lubricant:** Using the bottle's nozzle, apply approximately 5 ml of lubricant in a zigzag pattern under the belt, starting from the front and moving towards the back. The bottle has levels to help you measure the correct amount.
3. **Repeat on Other Side:** Lower the belt and repeat the application process on the other side of the belt, applying another 5 ml of lubricant.
4. **Distribute Lubricant:** Plug in the treadmill and turn it on. Set the speed to a slow pace (e.g., 4 km/h or 2.5 mi/h) and let it run for at least 10 seconds without anyone on it. This will help distribute the lubricant evenly across the deck.
5. **Wipe Excess:** If any lubricant seeps out from the sides of the belt, wipe it off with a clean cloth to prevent slipping hazards.



Image: A visual guide from the product label illustrating the steps for applying lubricant under the treadmill belt and then running the treadmill at a slow speed to distribute it.

Note: The frequency of lubrication depends on your treadmill usage. For moderate use, lubricating every 3-6 months is generally recommended. Consult your treadmill's specific user manual for detailed lubrication intervals.

5. Maintenance

Regular lubrication is the primary maintenance task for your treadmill belt. This product is designed to simplify this process. Beyond lubrication, ensure your treadmill belt tension is correct and the belt is centered. Refer to your treadmill's manual for these adjustments.

6. Troubleshooting

- **Treadmill still noisy after lubrication:** Ensure you applied the correct amount of lubricant evenly. If the noise persists, it might indicate an issue with belt tension, motor, or rollers, which may require professional inspection.
- **Belt feels sticky or slippery:** If sticky, too much lubricant might have been applied, or it wasn't distributed properly. Wipe off excess. If slippery, the belt might be worn, or not enough lubricant was applied. Reapply if necessary.
- **Lubricant not flowing easily:** Ensure the nozzle is clear. Store the bottle at room temperature.

7. Specifications

Attribute	Detail
Brand	Decathlon (Domyos)
Model Number	8326425
Composition	100% Silicone
Capacity	150 ml
Color	Clear/Red (bottle)
Usage	Lubricate and Maintain Treadmills
Item Weight	150 Grams
Package Dimensions	16.7 x 4.3 x 4.1 cm

8. Warranty and Support

For any questions regarding the Decathlon Domyos Treadmill Belt Lubricant, please contact Decathlon customer support. Information regarding product warranty, if applicable, can be found on the product packaging or the official Decathlon website. Always refer to your treadmill's specific manual for maintenance guidelines and warranty information related to the treadmill itself.
For further assistance, visit the official Decathlon website:www.decathlon.com

© 2025 Decathlon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question