

ECHOGEAR EGLL1-BK

ECHOGEAR SlimView TV Wall Mount Instruction Manual

Model: EGLL1-BK
Brand: ECHOGEAR

1. PRODUCT OVERVIEW

The ECHOGEAR SlimView TV Wall Mount provides a secure and minimalist solution for mounting your television. Its low-profile design ensures your TV sits close to the wall, enhancing the aesthetic of your living space. This manual provides detailed instructions for proper installation and use.



The ECHOGEAR SlimView TV Wall Mount, designed for secure and low-profile television installation.

ULTRA-SLIM PROFILE



This mount positions your television just 1.25 inches from the wall, providing a sleek, low-profile appearance.

2. INSTALLATION GUIDE

Follow these steps carefully to ensure a safe and secure installation of your ECHOGEAR SlimView TV Wall Mount.

2.1. Official Installation Video


For a visual guide, please watch the official installation video below:

An official installation video demonstrating the step-by-step process for mounting the ECHOGEAR SlimView TV Wall Mount. This video covers unboxing, attaching TV brackets, assembling and securing the wall plate, and finally hanging the television.

2.2. Package Contents

Before beginning, verify that all components are present in your package:

SO FRESH AND SO CLEAN out the box



The package includes all necessary components for installation: the wall plate, TV brackets, and a comprehensive hardware kit.

2.3. Attaching TV Brackets

Securely attach the vertical TV brackets to the back of your television using the appropriate screws from the hardware kit. Ensure they are aligned with your TV's VESA mounting holes.

EASY 1-2-3 INSTALLATION



Begin installation by securely attaching the vertical TV brackets to the back of your television using the provided hardware.

2.4. Wall Plate Assembly and Mounting

Assemble the wall plate components if necessary, then mark and drill pilot holes on your wall. Secure the wall plate to the wall using the provided lag bolts. This mount is compatible with:

- 16-inch wood studs
- 24-inch wood studs
- Poured concrete walls
- Concrete block walls

INSTALLS EASILY

on many wall types



16" WOOD STUDS



24" WOOD STUDS



POURED CONCRETE



CONCRETE BLOCK

The versatile design of this mount ensures compatibility with various wall types.

2.5. Hanging the Television

Carefully lift your television and hook the TV brackets onto the top edge of the wall plate. Gently lower the TV until the brackets engage with the bottom of the wall plate, securing it in place. Listen for an audible 'click' to confirm the security system is engaged.

2.6. VESA Compatibility

This mount supports the following VESA patterns:

- 200x100
- 200x200
- 300x200
- 300x300
- 400x200
- 500x200
- 400x300

- 400x400
- 500x400
- 600x400

WE'LL MAKE IT FIT



AVAILABLE VESA PATTERNS

200x100 // 200x200 // 300x200
300x300 // 400x200 // 400x300 // 400x400
500x300 // 600x200 // 600x400

This universal mount supports a wide range of VESA patterns, ensuring compatibility with most TV brands from 32 to 80 inches.

3. OPERATION

3.1. Accessing Cables

To access cables behind your television, utilize the quick-release pull strings located at the bottom of the TV brackets. Pulling these strings will disengage the TV from the wall plate, allowing you to tilt the TV forward for cable management without fully removing it from the wall.

NEED A FRESH START?

Pull cords to easily remove TV



The integrated pull-string locking system allows for easy and quick removal of the TV from the mount, providing convenient access to cables.

3.2. Cable Management

For a tidy installation, consider using ECHOGEAR cable management accessories to route and conceal your television's cables.



NEXT LEVEL:
Hide your cords
with EchoGear cable
management

For a clean aesthetic, consider integrating ECHOGEAR cable management solutions to conceal wires behind your mounted television.

4. MAINTENANCE

To ensure the long-term stability and safety of your TV mount, periodic maintenance is recommended:

- **Check Connections:** Annually inspect all screws and bolts securing the mount to the wall and the TV to the mount. Tighten any that may have loosened over time.
- **Clean Surfaces:** Use a soft, dry cloth to clean the mount. Avoid abrasive cleaners or solvents.
- **Inspect for Damage:** Regularly check for any signs of wear, corrosion, or damage to the mount components. If any damage is found, contact ECHOGEAR customer support immediately.

5. TROUBLESHOOTING

If you encounter any issues during or after installation, refer to the following common troubleshooting tips:

- **TV Not Level:** Ensure the wall plate is perfectly level before drilling. Some mounts allow for minor post-installation leveling adjustments. If not, you may need to re-adjust the wall plate.
- **Difficulty Hanging TV:** Ensure the TV brackets are correctly aligned with the wall plate. Two people are recommended for safely lifting and hanging the TV.
- **Cables Difficult to Access:** The low-profile design means limited space behind the TV. Utilize the pull-string release mechanism to tilt the TV forward for better access. Consider using right-angle HDMI adapters if space is extremely tight.
- **Mount Feels Loose:** Immediately remove the TV and re-check all wall and TV connections. Ensure lag bolts are securely fastened into studs or appropriate concrete anchors. Do not re-hang the TV until the mount is completely stable.

If problems persist, please contact ECHOGEAR customer support for assistance.

6. PRODUCT SPECIFICATIONS

Specification	Detail
Brand Name	ECHOGEAR
Item Weight	6.97 pounds
Product Dimensions	2.3 x 10.75 x 17.85 inches
Item Model Number	EGLL1-BK
Color	Original
Material	Alloy Steel
Mounting Type	Wall Mount
Movement Type	Fixed
Maximum Compatible Size	80 Inches
Minimum Compatible Size	32 Inches
Compatible Devices	Television
UPC	793795531421
Date First Available	September 27, 2016

7. WARRANTY AND SUPPORT

ECHOGEAR stands behind the quality of its products. This TV wall mount comes with **5-year warranty**.






For any questions, technical assistance, or warranty claims, please contact our US-based customer support team. Our experts are available 7 days a week to provide assistance.

Customer Support Phone: 1-855-428-2490

You can also refer to the full Installation Manual (PDF) for more detailed information [Download PDF Manual](#)

© 2024 ECHOGEAR. All rights reserved.

Related Documents - EGLL1-BK

	<p>ECHOGEAR EGAV-CMIWP1 In-Wall Power and Cable Management Kit Installation Guide</p> <p>Comprehensive guide for installing the ECHOGEAR EGAV-CMIWP1 in-wall power and cable management kit. Learn how to safely and effectively hide TV wires and power cords for a clean setup.</p>
	<p>ECHOGEAR Mini Grommets EGAV-CMIWM2-B1 EGAV-CMIWM2-W1 Owners Guide & Installation</p> <p>Owners guide and installation instructions for ECHOGEAR Mini Grommets (EGAV-CMIWM2-B1, EGAV-CMIWM2-W1). This kit provides discreet cable management for wall-mounted TVs. Learn how to safely install the grommets for a clean setup.</p>
	<p>Echogear EGOS1 Outlet Shelf Instruction Manual</p> <p>This manual provides instructions for installing the Echogear EGOS1 Outlet Shelf, a device designed to hold electronics up to 10 lbs. It includes safety information, parts lists, and step-by-step assembly guides.</p>
	<p>ECHOGEAR EGN-SG8 8-Port Gigabit Switch Owners Guide</p> <p>Official owners guide for the ECHOGEAR EGN-SG8 8-Port Gigabit Switch. Learn how to position, power up, connect your devices, and understand the LED indicators for optimal network performance.</p>
	

Instructions For Use

Step 1: Mount the TV

1. Mount the TV to the wall using the provided mounting brackets. Ensure the TV is level and secure.

2. Mount the TV to the wall using the provided mounting brackets. Ensure the TV is level and secure.

3. Mount the TV to the wall using the provided mounting brackets. Ensure the TV is level and secure.

[ECHOGEAR TV Wall Mount: Simple 3-Step Installation Guide](#)

A concise guide to installing your ECHOGEAR TV wall mount in three simple steps. Learn how to attach brackets to your TV, mount the plate to the wall, and connect your TV.