

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HORI](#) /

› [HORI Racing Wheel Apex for PlayStation 4/3, and PC PS4 - Apex Instruction Manual](#)

HORI PS4-052U

HORI Racing Wheel Apex Instruction Manual

Model: PS4-052U

INTRODUCTION

The HORI Racing Wheel Apex is designed to provide an authentic racing simulation experience for PlayStation 4, PlayStation 3, and PC. It features a full-size racing wheel and pedals, offering extensive customization options and vibration feedback for immersive gameplay. This manual provides essential information for setup, operation, and maintenance of your Racing Wheel Apex.

WHAT'S INCLUDED

- HORI Racing Wheel Apex Unit
- Pedal Unit
- Mounting Clamp
- Instruction Manual (this document)

SETUP

Follow these steps to set up your HORI Racing Wheel Apex:

1. **Secure the Racing Wheel:** Attach the racing wheel to a stable surface, such as a table or racing wheel stand, using the included sturdy clamps. Ensure it is firmly secured to prevent movement during use.



Image: The main HORI Racing Wheel Apex unit, showing the steering wheel with integrated buttons and paddle shifters, ready for mounting.

2. **Connect the Pedal Unit:** Connect the pedal unit cable to the designated port on the racing wheel unit. Place the pedal unit on the floor in a comfortable position. For added stability, consider placing it against a wall or using anti-slip mats if available.



Image: The HORI Racing Wheel Apex pedal unit, featuring two pedals for acceleration and braking, designed for floor placement.

3. **Connect to Console/PC:** Plug the USB cable from the racing wheel into an available USB port on your PlayStation 4, PlayStation 3, or PC. The device should be automatically recognized.
4. **Firmware Update (PS5 Compatibility):** For optimized performance on select PlayStation 5 titles, download and install the latest firmware update from the official HORI website. Refer to the HORI website for specific instructions and compatibility lists.

OPERATING INSTRUCTIONS

The Racing Wheel Apex offers various features for an enhanced gaming experience:

- **Compatibility:** Officially licensed for PlayStation 4 and PlayStation 3. Also compatible with PC.
- **Turn Ratio Adjustment:** Easily switch between a 270-degree and 180-degree turn ratio on the fly to suit different racing styles and game requirements. Consult the detailed instruction manual (PDF) for specific button combinations to adjust this setting.
- **Programmable & Adjustable Settings:** The wheel is completely programmable, allowing you to fine-tune settings such as dead zone and pedal sensitivity. Refer to the full user manual for detailed instructions on programming and

adjusting these options.

- **Vibration Feedback:** Experience realistic feedback during gameplay through the integrated vibration function.
- **Button Layout:** The wheel features a standard PlayStation button layout, including SHARE, OPTIONS, PS button, and directional pad, along with L1/R1, L2/R2, and paddle shifters.

MAINTENANCE

To ensure the longevity and optimal performance of your Racing Wheel Apex, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the wheel and pedal unit. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Storage:** When not in use, store the unit in a clean, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the cables. Do not pull on the cables to disconnect the unit.

TROUBLESHOOTING

If you encounter issues with your Racing Wheel Apex, try the following solutions:

Problem	Possible Cause / Solution
Wheel not recognized by console/PC	Ensure all cables are securely connected. Try a different USB port. Restart your console/PC. Check for the latest firmware update on the HORI website.
Buttons/controls malfunctioning or unresponsive	Disconnect and reconnect the wheel. Restart the game or console/PC. Verify game settings for controller input. Perform a factory reset on the wheel (refer to the full user manual for instructions).
Pedals sliding during use	Ensure the pedal unit is placed on a non-slip surface. Position the pedal unit against a wall or sturdy object. Consider using additional anti-slip mats or Velcro.

For further assistance, please visit the official HORI support website.

SPECIFICATIONS

- **Model Number:** PS4-052U
- **Compatibility:** PlayStation 4, PlayStation 3, PC (Windows)
- **Turn Ratio:** 270 degrees (adjustable to 180 degrees)
- **Feedback:** Vibration feedback
- **Dimensions (Product):** 11.69 x 11.69 x 13.19 inches
- **Weight (Item):** 7 pounds
- **Release Date:** October 18, 2016

WARRANTY & SUPPORT

The HORI Racing Wheel Apex typically comes with a 90-day warranty from the date of purchase. For detailed warranty information, product support, firmware updates, and troubleshooting guides, please visit the official HORI website:

[Visit the Official HORI Website](#)

Please retain your proof of purchase for warranty claims.

© 2024 HORI. All rights reserved. PlayStation is a registered trademark of Sony Interactive Entertainment Inc.