

## 1byone OEU00-0750

# 1byone Bluetooth Record Player User Manual

Model: OEU00-0750

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your 1byone Bluetooth Record Player. Please read it thoroughly before use and retain it for future reference.

## Key Features:

- Selectable 33, 45, and 78 RPM speed settings, including a 45-RPM adapter.
- Bluetooth connectivity for wireless music playback from smartphones, tablets, and other devices through the turntable's built-in speakers.
- Dynamic, balanced tone arm with soft damping control for gentle record playback.
- RCA output for connecting to external speakers and a headphone jack for private listening.
- Line-in port for connecting external audio sources like MP3 players.
- Portable briefcase-style design with a wooden cabinet and PU leather wrapping for easy storage and transport.

## SAFETY INFORMATION

### Important Safety Instructions:

- This appliance is not intended for use by dependents and children. All use by dependents should be supervised by a responsible, capable adult.
- This product must be used only for the purpose for which it has been developed, and in the manner described in these instructions for use. Any improper use can be dangerous.
- Do not expose the unit to rain or moisture.
- Do not block any ventilation openings.
- Protect the power cord from being walked on or pinched.
- Unplug the unit during lightning storms or when unused for long periods.

## PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- 1byone Bluetooth Record Player
- 45 RPM Adapter
- Power Adapter
- User Manual (this document)

## PRODUCT OVERVIEW

Familiarize yourself with the components of your record player.



Figure 1: The 1byone Bluetooth Record Player in its open position, showcasing the platter, tone arm, and built-in speakers. A vinyl record is placed on the platter, ready for playback.

### Front View (Closed):



Figure 2: The record player in its closed, portable briefcase form, showing the front latches, handle, and speaker grilles.

#### Rear View (Closed):



Figure 3: The rear of the record player, displaying the hinges and a product information label with model and power specifications.

#### Side Panel Controls and Ports:



Figure 4: A detailed view of the right side panel, featuring the power/volume knob, DC input, headphone jack, RCA output (L/R), and Line-in port.



**Headphone jack**  
listen to music



**RCA output**  
connect to external speakers



**3.5mm line in port**  
connect your iPod, MP3 or other Digital Audio Players

Figure 5: Visual representation of the connectivity options: headphone jack for private listening, RCA output for external speakers, and 3.5mm line-in for connecting other audio devices.

## Internal Components:

- **Platter:** The rotating surface where records are placed.
- **Tone Arm:** Holds the cartridge and stylus, which reads the grooves of the record.
- **Stylus (Needle):** The tip of the cartridge that makes contact with the record. (Protected by a cap).
- **Speed Selector Switch:** Allows selection of 33, 45, or 78 RPM playback speeds.
- **Auto Stop ON/OFF Switch:** Controls whether the platter stops automatically at the end of a record.
- **45 RPM Adapter Holder:** A dedicated slot for storing the 45 RPM adapter.
- **Built-in Speakers:** Located on the front panel for direct audio output.

## SETUP

1. **Unpack the Turntable:** Carefully remove the record player and all accessories from the packaging.
2. **Place the Turntable:** Position the unit on a stable, level surface away from direct sunlight, heat sources, or excessive dust.

3. **Connect Power:** Insert the DC plug of the power adapter into the DC IN port on the side of the turntable. Plug the other end of the adapter into a suitable wall outlet.
4. **Remove Stylus Protector:** Before playing a record, gently remove the clear plastic protective cap from the stylus (needle).
5. **Release Tone Arm:** Unlock the tone arm clip to release the tone arm.

## OPERATING INSTRUCTIONS

---

### 1. Playing Vinyl Records:

1. **Power On:** Rotate the ON/OFF/VOLUME knob clockwise until it clicks to turn on the unit. Adjust the volume to a low level.
2. **Select Speed:** Set the speed selector switch (33/45/78 RPM) to match the record you are playing. For 45 RPM records, place the included 45 RPM adapter onto the center spindle.
3. **Place Record:** Carefully place a vinyl record on the turntable platter.
4. **Auto Stop Function:** The AUTO STOP ON/OFF switch controls whether the record stops automatically when finished.
  - If set to **ON**, the record will stop automatically when it reaches the end. (Note: For some records, it may stop prematurely or not stop at all).
  - If set to **OFF**, the record will continue to spin even after the music has ended.
5. **Start Playback:** Gently lift the tone arm using the cueing lever. Position the tone arm over the desired track on the record. Slowly lower the tone arm onto the record using the cueing lever. The music will begin to play.
6. **Adjust Volume:** Rotate the ON/OFF/VOLUME knob to adjust the sound level.
7. **End Playback:** When the record finishes (or you wish to stop), lift the tone arm using the cueing lever and return it to the tone arm rest. Secure it with the tone arm clip. Rotate the ON/OFF/VOLUME knob counter-clockwise until it clicks to turn off the unit.

### 2. Bluetooth Playback:

You can stream music wirelessly from your Bluetooth-enabled devices to the record player's built-in speakers.

1. **Power On:** Turn on the record player using the ON/OFF/VOLUME knob.
2. **Activate Bluetooth:** The unit will automatically enter Bluetooth pairing mode. An indicator light may flash to show it's ready to pair.
3. **Pair Device:** On your smartphone, tablet, or other Bluetooth device, enable Bluetooth and search for "1byone Turntable" (or similar name). Select it to pair.
4. **Play Music:** Once paired, you can play music from your device, and it will sound through the record player's speakers. Adjust volume using both your device and the turntable's volume knob.

### 3. Using the Line-In Port:

Connect external audio devices via the 3.5mm Line-in port.



## Streaming music of iPod, MP3 player, Mobile Phones, etc as a music player

Figure 6: The record player demonstrating a smartphone connected to its 3.5mm Line-in port, allowing external audio playback through the turntable's speakers.

1. **Connect Cable:** Use a 3.5mm audio cable (not included) to connect your external audio device (e.g., MP3 player, phone) to the LINE IN port on the side of the record player.
2. **Power On:** Turn on the record player and your external audio device.
3. **Play Music:** Start playback on your external device. The audio will be routed through the record player's speakers. Adjust volume using both devices.

### 4. Using RCA Output:

Connect the record player to an external amplifier or powered speakers for enhanced sound.

1. **Connect RCA Cables:** Use RCA cables (not included) to connect the L (left) and R (right) RCA OUT ports on the record player to the corresponding audio input ports on your amplifier or powered speakers.
2. **Power On:** Turn on the record player and your external audio system.
3. **Play Music:** Play a record on the turntable. The audio will be output through your connected external system. Adjust volume on your external system.

## 5. Using Headphone Jack:

For private listening, connect headphones to the dedicated jack.

- Connect Headphones:** Plug your headphones (not included) into the HEADPHONE jack on the side of the record player.
- Play Music:** Play a record or stream via Bluetooth/Line-in. The sound will be directed to your headphones, and the built-in speakers will be muted.
- Adjust Volume:** Adjust the volume using the ON/OFF/VOLUME knob.

## MAINTENANCE

- Cleaning the Unit:** Wipe the exterior of the record player with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Cleaning the Stylus:** Use a soft brush (not included) to gently clean the stylus, brushing from back to front. Avoid touching the stylus with your fingers.
- Cleaning Records:** Keep your vinyl records clean to ensure optimal sound quality and prolong stylus life. Use a record cleaning brush and solution (not included) as recommended by record care professionals.
- Stylus Replacement:** The stylus has a limited lifespan. If sound quality deteriorates, the stylus may need replacement. Contact 1byone customer support for replacement options.
- Storage:** When not in use, ensure the tone arm is secured with its clip and the stylus cap is in place. Close the lid to protect the platter and tone arm from dust. Store the unit in a cool, dry place.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected or outlet not working.	Ensure the power adapter is securely plugged into the unit and a working wall outlet. Check if the ON/OFF/VOLUME knob is turned on.
No sound from speakers	Volume too low; headphones connected; RCA output connected to external system.	Increase volume. Disconnect headphones. If using RCA output, ensure external system is powered on and correctly configured.
Record skips	Dirty or scratched record; stylus worn or dirty; turntable not level.	Clean the record. Clean or replace the stylus. Place the turntable on a stable, level surface.
Record plays too fast/slow	Incorrect speed setting.	Adjust the speed selector switch to match the record's RPM (33, 45, or 78).
Auto stop not working correctly	Record type; AUTO STOP switch setting.	Some records may not trigger the auto-stop function reliably. Try setting the AUTO STOP switch to OFF if it stops prematurely.
Bluetooth pairing issues	Device not in pairing mode; device too far; interference.	Ensure the turntable is in Bluetooth mode. Move your device closer. Turn off other Bluetooth devices to reduce interference.

## SPECIFICATIONS

Model Name	Suitcase Turntable
Item Model Number	OEU00-0750
Brand	1byone
Product Dimensions	13.8 x 10 x 5.1 inches
Item Weight	5.7 pounds
Maximum Rotational Speed	78 RPM
Material	Plastic
Color	Turquoise
Compatible Devices	Headphone, MP3 Player, Speaker, Tablet

Note: While the primary material is listed as Plastic, the product features a wooden cabinet with PU leather wrapping for its exterior finish.

## WARRANTY AND SUPPORT

### Warranty Information:


1byone stands by its products. This turntable comes with a 12-month guarantee. If any issues arise, a replacement will be provided. Customer satisfaction is a priority.

### Customer Support:

For technical assistance, warranty claims, or general inquiries, please contact 1byone customer support. Refer to the official 1byone website or product packaging for the most current contact information.

© 2023 1byone. All rights reserved.

## Related Documents

	<p><a href="#">1byone Belt Drive Turntable System Instruction Manual</a></p> <p>This instruction manual provides detailed guidance for the 1byone Belt Drive Turntable System, covering setup, operation, safety precautions, maintenance, troubleshooting, and technical specifications. Learn how to connect, play vinyl records, utilize Bluetooth connectivity, and record audio to your computer.</p>
	<p><a href="#">1byone High Fidelity Belt Drive Turntable: Setup, Operation, and Safety Guide</a></p> <p>Comprehensive instruction manual for the 1byone High Fidelity Belt Drive Turntable. Covers safety precautions, product description, setup, operation (vinyl playback, Bluetooth, AUX-IN), maintenance, troubleshooting, and specifications. Learn how to enjoy your vinyl records with this versatile turntable.</p>
	<p><a href="#">1byone Vintage Turntable: User Manual, Features, and Specifications</a></p> <p>Comprehensive user manual for the 1byone Vintage Turntable. Learn about setup, operation, listening to records, Bluetooth connectivity, troubleshooting, safety instructions, and technical specifications. Includes multilingual support information.</p>



## [1byone High Fidelity Belt Drive Turntable Instruction Manual](#)

Comprehensive instruction manual for the 1byone High Fidelity Belt Drive Turntable (Model 1-AD07US15), covering setup, operation, safety, maintenance, troubleshooting, and specifications.

Documents - 1byone – OEU00-0750

### [\[pdf\] User Manual Quick Start Guide Instructions](#)



O0000 0750 MD 809 20191107 User Manual 1 BY ONE Bluetooth Record Player Belt Drive 3 Speed Portable Vinyl Turntable with Built in Speakers Supports RCA Output Headphone Jack MP3 Mobile Phones Music Playback Turquoise Electronics Photo C1XUkoFyWPL m media amazon images I ||| VINTAGE TURNTABLE 1byone Products Inc. 1230 E Belmont Street, Ontario, CA, USA 91761 Customer Servi ... mentioned below. Article Description: Vintage Turntable Brand Name: 1byone Model Number: OUK00-0750 **OEU00-0750** Governing EU-regulations: RoHS Directive 2011/65/EU WEEE 2012/19/EU Applicable Standard s...

lang:en **score:21** filesize: 5.85 M page\_count: 26 document date: 2020-10-29

### [\[pdf\] User Manual Quick Start Guide Instructions](#)



O0000 0750 MD 809 148x210mm 20210708 vintage turntable Entrada de CA 100 240V 50 60Hz Salida CC 12V 500mA 33 45 78 RPM 0 3W x2 RMS potencia salida 1 8W Version 5 91V4J E8HJL m media amazon images I ||| VINTAGE TURNTABLE 1byone Products Inc. 1230 E Belmont Street, Ontario, CA, USA 91761 Customer Servi ... lations as mentioned below. Article Description: Vintage Turntable Brand Name: 1byone Model Number: **OEU00-0750**, MD-809 Applicable Standard s : EN 55013:2013 EN 61000-3-2:2014 EN 61000-3-3:2013 EN 5502...

lang:en **score:16** filesize: 854.27 K page\_count: 26 document date: 2021-08-02