

[Manuals.plus](#) /

› [Mainstays](#) /

› Mainstays 6-Speed Blender Model MS-BL6-BLK User Manual

Mainstays MS-BL6-BLK

Mainstays 6-Speed Blender User Manual

Model: MS-BL6-BLK

INTRODUCTION

Thank you for purchasing the Mainstays 6-Speed Blender. This appliance is designed for efficient blending of various ingredients, from smoothies to frozen beverages. Please read this manual carefully before use to ensure safe and optimal operation. Keep this manual for future reference.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils out of the container while blending to prevent the possibility of severe injury to persons or damage to the blender.
- Always operate the blender with the lid in place.
- Blades are sharp. Handle with care.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Mainstays 6-Speed Blender:

- **Motor Base:** Contains the 350W motor and control panel.
- **Blender Jar:** 1.5-liter capacity, BPA-free pitcher with measurement markings.
- **Lid:** Secures the contents during blending.
- **Stainless Steel Blade Assembly:** Located at the bottom of the blender jar.
- **Control Panel:** Features buttons for OFF, Pulse, Chop, Mix, Grate, Blend, and Liquefy.





This image displays the Mainstays 6-Speed Blender. It features a black base with a control panel on the front, a clear 1.5-liter capacity pitcher with measurement markings (OZS and CUPS), and a black lid. The control panel includes buttons for OFF, Pulse, Chop, Mix, Grate, Blend, and Liquefy.

SETUP

Before first use, wash all parts except the motor base in warm, soapy water. Rinse thoroughly and dry.

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the stainless steel blade assembly is securely attached to the bottom of the blender jar.
3. Place the blender jar onto the motor base, ensuring it is seated correctly.
4. Add your ingredients to the blender jar. Do not exceed the maximum fill line (1.5L).
5. Securely place the lid on top of the blender jar.
6. Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

Your Mainstays blender offers 6 speeds and a pulse function for versatile blending.

Speed Settings:

- **OFF:** Turns the blender off.
- **Pulse:** Provides short bursts of power for chopping or quick blending. Hold down for desired duration.
- **Chop:** Ideal for coarse chopping of ingredients like nuts or vegetables.
- **Mix:** Suitable for combining ingredients or light blending.
- **Grate:** For grating harder ingredients.
- **Blend:** General blending for sauces, batters, and light smoothies.
- **Liquefy:** Highest speed for creating smooth purees, soups, and frozen beverages.

To operate, select the desired speed by pressing the corresponding button. For continuous operation, press the desired speed button. To stop, press the 'OFF' button. For pulse action, press and hold the 'Pulse' button, releasing it to stop.

CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your blender. The blender jar is dishwasher safe.

1. Always unplug the blender before cleaning.
2. Remove the blender jar from the motor base.
3. Remove the lid and blade assembly.
4. Wash the blender jar, lid, and blade assembly in warm, soapy water or place them in the dishwasher. Handle blades with extreme care as they are sharp.
5. Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
6. Ensure all parts are completely dry before reassembling or storing.
7. For cord storage, wrap the cord around the designated area under the motor base to save space.

TROUBLESHOOTING

If you encounter issues with your blender, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not working; jar not correctly seated.	Ensure plug is firmly in outlet; check outlet with another appliance; ensure blender jar is securely placed on the motor base.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large.	Add more liquid; reduce ingredient quantity; cut ingredients into smaller pieces; use the Pulse function for initial chopping.
Motor smells or overheats.	Overloading the blender; continuous operation for too long.	Reduce ingredient load; allow the blender to cool down for 15-20 minutes before resuming use.
Lid leaks during operation.	Lid not properly secured; jar overfilled.	Ensure lid is firmly pressed onto the jar; do not exceed the maximum fill line.

SPECIFICATIONS

Feature	Detail
Model Number	MS-BL6-BLK (3198879)
Power	350 Watts
Voltage	230 Volts
Capacity	1.5 Liters
Number of Speeds	6 + Pulse Function
Blade Material	Stainless Steel
Jar Material	BPA-free Plastic

Feature	Detail
Color	Black
Dimensions (L x W x H)	25.4 x 18.29 x 32.26 cm
Weight	1.86 kg
Special Features	Cord storage, Dishwasher safe jar

WARRANTY INFORMATION

This Mainstays product is covered by a limited warranty against defects in material and workmanship under normal household use. Specific warranty terms and duration may vary by region. Please retain your proof of purchase for any warranty claims. For detailed warranty information, refer to the warranty card included with your product or contact customer support.

CUSTOMER SUPPORT

For assistance with your Mainstays 6-Speed Blender, including questions about operation, maintenance, or troubleshooting not covered in this manual, please contact our customer support team. Contact information can typically be found on the product packaging or the brand's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

