

Oulm 3595

Oulm 3595 Men's Quartz Watch Instruction Manual

Model: 3595 (HP3377)

INTRODUCTION

Thank you for choosing the Oulm 3595 Men's Quartz Watch. This timepiece features a unique design with three independent quartz movements, allowing for the display of three different time zones simultaneously. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure its longevity and accurate performance.

Key features include:

- Three independent quartz movements for multiple time zone display.
- Analog display with luminous hands.
- Durable alloy case with an organic crystal.
- Comfortable leather strap with a deployment clasp.

PRODUCT OVERVIEW

The Oulm 3595 watch is designed with a distinctive square case housing three separate dials, each controlled by its own crown.



Figure 1: Front View of Oulm 3595 Watch. This image displays the watch face, highlighting the large main dial and two smaller sub-dials, each with its own crown for time adjustment.

Components:

- **Main Dial:** The largest dial, typically used for the primary time zone.
- **Sub-Dials (2):** Two smaller dials for additional time zones.
- **Crowns (3):** Each dial has an independent crown for setting its time.
- **Case:** Square alloy case.
- **Strap:** Leather strap with a deployment clasp.
- **Organic Crystal:** Watch face cover.



Figure 2: Back View of Oulm 3595 Watch. This image shows the stainless steel back of the watch, engraved with the brand name "Oulm," "A Unique Designer," and the model number "3595."

SETUP AND TIME SETTING

Your Oulm 3595 watch requires individual time setting for each of its three dials. Each dial operates independently.

1. **Identify the Crowns:** Each of the three dials (one large, two small) has a corresponding crown located on the side of the watch case.
2. **Pull Out the Crown:** Gently pull out the crown associated with the dial you wish to set. You should feel a slight click.
3. **Set the Time:** Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the desired time.
4. **Push In the Crown:** Once the time is set, push the crown back into its original position. This locks the time and starts the movement.
5. **Repeat for All Dials:** Follow these steps for each of the three dials to set your desired time zones.

Battery Information:

The Oulm 3595 watch requires **3 LR44 batteries**, one for each quartz movement. When the watch stops or runs inaccurately, it is likely time to replace the batteries. Battery replacement should ideally be performed by a qualified watch technician to avoid damage to the watch's internal components.

OPERATING INSTRUCTIONS

Once the time is set on all three dials, your Oulm 3595 watch will continuously display the three chosen time zones. There are no additional operating functions beyond time display.

- The main dial is typically used for your local time.
- The two smaller sub-dials can be set to display times in other cities or regions, useful for travel or international communication.

MAINTENANCE AND CARE

Cleaning:

To maintain the appearance of your watch, wipe the case and crystal with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. If the strap becomes dirty, gently wipe it with a slightly damp cloth and allow it to air dry completely.

Water Resistance:

IMPORTANT: This watch is NOT water resistant.

Avoid all contact with water, including rain, splashes, showering, swimming, or any other water-related activities. Exposure to water can cause severe damage to the internal quartz movements and is not covered under any potential warranty.

Storage:

When not in use, store your watch in a cool, dry place away from direct sunlight and extreme temperatures. Avoid exposing the watch to strong magnetic fields, which can affect the accuracy of the quartz movements.

TROUBLESHOOTING

- **Watch is not running or running inaccurately:**

This is typically an indication of a depleted battery. As the watch uses three separate movements, one or more dials might stop while others continue. Replace the 3 LR44 batteries. If the issue persists after battery replacement, consult a professional watch repair service.

- **Hands are not moving after setting:**

Ensure the crown for that specific dial is fully pushed back into its normal operating position. If the crown is pulled out, the movement will remain stopped.

- **Condensation under the crystal:**

This indicates moisture has entered the watch case. As the watch is not water resistant, this can cause significant damage. Immediately seek professional watch repair to prevent further corrosion.

SPECIFICATIONS



Figure 3: Oulm 3595 Watch Dimensions. This image illustrates the watch being measured with a caliper, providing a visual reference for its size.

Model Name	3595
-------------------	------

Item Model Number	HP3377
Brand	Oulm
Movement Type	Japanese Quartz (3 independent movements)
Display Type	Analog
Case Material	Alloy
Crystal Material	Organic Crystal
Strap Material	Leather / Canvas
Clasp Type	Deployment Clasp
Case Diameter	Approximately 5 Centimeters
Case Thickness	Approximately 14 Millimeters
Band Width	Approximately 5 Centimeters
Band Length	26 Millimeters
Weight	0.14 Kilograms (approx. 4.97 ounces)
Batteries Required	3 x LR44 (per watch)
Water Resistance	NOT Water Resistant

Note on Band Length: The provided specification of "26 Millimeters" for band length appears to be a typographical error and is unusually short for a watch band. A typical men's watch band length is closer to 26 centimeters (260 millimeters). Please measure your wrist for accurate sizing.

WARRANTY AND SUPPORT

Specific warranty information for the Oulm 3595 watch is not provided in the product details. For any warranty claims, technical support, or service inquiries, please contact the retailer from whom you purchased the watch or the manufacturer directly.

Manufacturer: OULM Factory