

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Master Lock](#) /

› Master Lock 4697EURDNKL Combination Travel Padlock TSA Certified, Nickel Instruction Manual

Master Lock 4697EURDNKL

Master Lock 4697EURDNKL Combination Travel Padlock TSA Certified Instruction Manual

INTRODUCTION

This manual provides instructions for the Master Lock 4697EURDNKL Combination Travel Padlock. This TSA-certified lock is designed for securing luggage, backpacks, and other items, allowing Transportation Security Administration (TSA) screeners to inspect and relock your baggage without damage.




Image: The Master Lock 4697EURDNKL padlock attached to the zippers of a purple suitcase, demonstrating its use for travel security. The image also displays the 'TRAVEL SENTRY TSA ACCEPTED' logo, indicating compliance with TSA regulations, and icons representing suitable applications like duffel bags and suitcases.

SETTING YOUR COMBINATION

Your Master Lock 4697EURDNKL padlock is preset to open at 0-0-0-0. Follow these steps to set your personal combination:

1. **Open the Lock:** With the dials set to 0-0-0-0, pull up the shackle to open the lock.
2. **Rotate the Shackle:** Rotate the shackle 90 degrees counter-clockwise (or 1/4 turn) until it aligns with the notch on the lock body.
3. **Press Down the Shackle:** Press the shackle down firmly into the lock body. While holding it down, rotate the shackle another 90 degrees counter-clockwise. The shackle should now be pressed down and rotated 180 degrees from its original open position.
4. **Set Your New Combination:** While the shackle is held down and rotated, turn the dials to your desired personal combination. Ensure the numbers are clearly aligned in the viewing window.

5. **Return the Shackle:** Lift the shackle, then rotate it back 180 degrees clockwise to its original open position. Push the shackle down to lock it.

6. **Test the Combination:** Scramble the dials and then enter your new combination to ensure the lock opens correctly.

Important: Remember your combination. Master Lock does not retain user-set combinations.



Image: A close-up view of the Master Lock 4697EURDNKL padlock, highlighting its four combination dials. The image also features a "Limited Lifetime Warranty" seal, indicating the product's guarantee.

OPERATING THE LOCK

To Open the Lock:

1. Align the dials to your set 4-digit combination.
2. Pull up on the shackle to release it from the lock body.

To Close and Secure the Lock:

1. Insert the shackle back into the lock body.
2. Scramble the dials to a random set of numbers to secure the lock.

The flexible braided steel shackle is designed to fit most luggage zippers and resist abuse from baggage handling equipment.

MAINTENANCE

- Keep the lock clean and free from dirt or debris, especially around the dials and shackle mechanism.
- Periodically apply a small amount of silicone-based lubricant to the shackle and dialing mechanism to ensure smooth operation. Avoid oil-based lubricants as they can attract dirt.
- Store the lock in a dry environment when not in use to prevent corrosion.

TROUBLESHOOTING

Lock Will Not Open with Correct Combination:

- Ensure the numbers are perfectly aligned in the viewing window. Sometimes dials can be slightly off-center.
- Verify that you are using the correct combination. If you recently changed it, try the old combination as well, in case the change was not fully registered.
- Apply slight pressure to the shackle (pulling up or pushing down) while entering the combination, then try to open.

Dials Are Stiff or Hard to Turn:

- Clean the dials with a soft cloth to remove any surface dirt.
- Apply a small amount of silicone lubricant to the gaps around the dials.

Forgot Combination:

Unfortunately, if you have forgotten your combination, there is no master key or reset code for user-set combination locks. The lock will need to be cut or replaced. It is recommended to record your combination in a secure, memorable location.

SPECIFICATIONS

Brand	Master Lock
Model Number	4697EURDNKL
Lock Type	4-digit Combination Lock
Material	Metal body, Vinyl covered flexible braided steel shackle
Color	Nickel
Overall Dimensions (H x W x L)	9.3 x 3.6 x 1.5 cm (approx. 3.66 x 1.42 x 0.59 inches)
Shackle Dimensions (A x B x C)	0.3 x 3.8 x 3.8 cm (approx. 0.12 x 1.5 x 1.5 inches)
Weight	0.09 Kilograms

Special Feature	TSA Certified, Durable
Recommended Uses	Luggage, Backpacks, Sports Bags




Image: Technical diagram illustrating the physical dimensions of the Master Lock 4697EURDNKL padlock. Labels H, W, L denote the overall height, width, and length, while A, B, C specify the shackle's diameter and internal clearances. Corresponding measurements are listed as HxWxL: 9,3 x 3,6 x 1,5 cm and AxBxC: 0,3 x 3,8 x 3,8 cm.

WARRANTY INFORMATION

The Master Lock 4697EURDNKL Combination Travel Padlock is covered by a **Limited Lifetime Warranty**. This warranty provides peace of mind regarding the product's quality and durability. For specific terms and conditions of the warranty, please refer to the official Master Lock website or contact customer support.

CUSTOMER SUPPORT

For further assistance, product inquiries, or warranty claims, please contact Master Lock customer support. You can find contact information and additional resources on the official Master Lock website.

Brand: Master Lock

Official Website: www.masterlock.com



© 2023 Master Lock. All rights reserved.