

Kinto Stainless Unitea One Touch Teapot User Manual

Model: 8336

1. PRODUCT OVERVIEW

The Kinto Stainless Unitea One Touch Teapot is designed for effortless tea brewing and easy maintenance. Its heat-resistant glass body allows you to observe the tea leaves as they unfurl, while the integrated stainless steel strainer in the lid ensures a clear, flavorful brew without loose leaves.



Figure 1: Kinto Stainless Unitea One Touch Teapot (720 ml)

Key Features:

- Integrated stainless-steel lid with strainer for convenient brewing.
- Spacious pot design allows tea leaves to expand fully for enhanced flavor.
- Made of durable heat-resistant glass.
- Microwave and dishwasher safe for easy cleaning.
- Compact and elegant design, suitable for personal use or serving guests.

2. COMPONENTS

The Kinto Unitea One Touch Teapot consists of three main components:

1. **Glass Teapot Body:** The main vessel for brewing and serving tea, made from heat-resistant glass.
2. **Stainless Steel Lid:** Features an integrated fine-mesh strainer.
3. **Silicone Gasket:** A removable silicone ring on the lid that ensures a secure fit and prevents leaks.



Figure 2: Teapot components (glass body and lid with integrated strainer)

3. SETUP

Before first use, and after each use, ensure all components are clean.

1. Unpack all components from the packaging.
2. Wash the glass teapot body, stainless steel lid, and silicone gasket thoroughly with warm water and mild detergent. Rinse completely.
3. Ensure the silicone gasket is properly seated around the stainless steel strainer on the lid.
4. The teapot is now ready for use.

4. OPERATING INSTRUCTIONS

Follow these steps to brew a perfect cup of tea:

1. **Add Tea Leaves:** Place your desired amount of loose tea leaves directly into the clean glass teapot body. The spacious design allows leaves to expand fully.
2. **Add Hot Water:** Carefully pour hot water into the teapot, covering the tea leaves. Ensure the water temperature is appropriate for your type of tea.
3. **Place Lid:** Securely place the stainless steel lid onto the teapot. The integrated strainer will face downwards into the pot.
4. **Steep:** Allow the tea to steep for the recommended time according to your tea type. The transparent glass allows you to monitor the brewing process.
5. **Serve:** Once steeped, simply pour the tea directly from the teapot. The integrated strainer in the lid will filter out the tea leaves, ensuring a clear pour.



Figure 3: Teapot in use with tea leaves steeping

5. MAINTENANCE & CLEANING

Proper care will ensure the longevity of your Kinto Teapot.

Cleaning:

- The Kinto Stainless Unitea One Touch Teapot is both **microwave and dishwasher safe**.
- For best results, especially for the stainless steel lid, hand washing with a soft sponge and mild detergent is recommended to prevent water spots and maintain shine.
- To clean the lid, remove the silicone gasket and wash separately. Ensure no tea leaves are trapped in the strainer mesh.
- Rinse all components thoroughly after washing and allow them to air dry completely before reassembling or storing.



Figure 4: Close-up of the lid and integrated strainer for easy cleaning

Storage:

Store the teapot in a dry place. Ensure all parts are completely dry before storage to prevent odors or residue buildup.

6. SPECIFICATIONS

Attribute	Value
Brand	Kinto
Model Number	8336
Material	Heat-resistant Glass, Stainless Steel
Color	Clear
Capacity	720 Milliliters (24.35 Fl. Oz.)
Item Weight	0.22 Kilograms (7.7 ounces)
Product Dimensions (L x W x H)	3.8 x 4.9 x 5.7 inches (D 7.8 x W 12.5 x H 14.5 cm)
Dishwasher Safe	Yes
Microwave Safe	Yes
Assembly Required	No

7. WARRANTY & SUPPORT

Kinto products are crafted with attention to detail and quality. For information regarding warranty coverage, product support, or replacement parts, please refer to the official Kinto website or contact their customer service directly. Keep your purchase receipt as proof of purchase may be required for warranty claims.

For further assistance, please visit: kinto.co.jp