

UPBRIGHT UpBright DC 12V AC-DC Adapter

UpBright DC 12V AC-DC Adapter Instruction Manual

For Electrohome Archer Vinyl Record Players (Models EANOS300, EANOS300S, EANOS 300)
Brand: UPBRIGHT

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your UpBright DC 12V AC-DC Adapter. This adapter is designed to provide reliable power to compatible Electrohome Archer Vinyl Record Players. Please read these instructions carefully before use and retain them for future reference.

2. IMPORTANT SAFETY INFORMATION

- **Voltage Compatibility:** This adapter provides a **12V DC output**. It is specifically designed for devices requiring 12V DC power. **DO NOT use this adapter with devices requiring 11V AC or any other voltage/current specifications.** Incorrect voltage can damage your device.
- **Indoor Use Only:** This adapter is intended for indoor use in dry locations only. Do not expose to rain, moisture, or extreme temperatures.
- **Ventilation:** Ensure adequate ventilation around the adapter during operation. Do not cover the adapter or place it in an enclosed space that could restrict airflow.
- **Cable Care:** Do not place heavy objects on the power cord or subject it to sharp bends. Inspect the cord for damage before each use.
- **Protection Features:** This adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.
- **Disconnection:** Always unplug the adapter from the wall outlet before cleaning or if it will be unused for an extended period.
- **Children:** Keep the adapter and its cords out of reach of children.

3. PRODUCT OVERVIEW

The UpBright DC 12V AC-DC Adapter converts standard AC wall power to the DC voltage required by your compatible device.



Image 3.1: The UpBright DC 12V AC-DC Adapter, showing the main power block with US plug prongs and the attached DC output cable with its barrel connector.

The adapter consists of a main power block with integrated AC input prongs and an attached DC output cable terminating in a barrel connector.

4. COMPATIBILITY

This UpBright DC 12V AC-DC Adapter is compatible with the following Electrohome Archer Vinyl Record Player models:

- Electrohome Archer EANOS300
- Electrohome Archer EANOS300S
- Electrohome Archer EANOS 300

Important: Always verify the power requirements of your specific device before connecting any power adapter. This adapter provides 12V DC output. Ensure your device requires 12V DC and has a compatible barrel connector.

5. SETUP AND INSTALLATION

Follow these steps to properly connect your UpBright DC 12V AC-DC Adapter:

1. **Verify Device Requirements:** Confirm that your Electrohome Archer Vinyl Record Player requires a 12V DC power input.
2. **Connect to Device:** Insert the barrel connector of the adapter's DC output cable firmly into the power input jack of your Electrohome Archer Vinyl Record Player.



Image 5.1: Close-up view of the DC barrel connector, highlighting its shape for proper insertion into the device's power port.

3. **Connect to Power Outlet:** Plug the adapter's AC prongs into a standard, functional wall power outlet (100-240VAC, 50/60Hz).
4. **Power On:** Once connected, your device should receive power. Refer to your record player's manual for specific power-on procedures.

6. OPERATION

The UpBright DC 12V AC-DC Adapter operates automatically once connected to a power source and a compatible device. It provides continuous power as long as it is plugged in and the device is connected. There are no user-adjustable settings on the adapter itself.

7. MAINTENANCE

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

8. TROUBLESHOOTING

If your device is not receiving power after connecting the adapter, consider the following:

- **No Power to Device:**
 - Ensure the adapter is fully plugged into a functional wall outlet. Test the outlet with another device.
 - Verify that the barrel connector is securely inserted into your record player's power jack.
 - Confirm that your record player is switched on, if it has a power switch.
 - Double-check that your record player requires 12V DC power. Using an adapter with incorrect voltage will prevent operation and may cause damage.
- **Adapter Overheating:**
 - Unplug the adapter immediately.
 - Ensure it is not covered and has adequate ventilation.
 - If overheating persists, discontinue use and contact support.

9. SPECIFICATIONS

Feature	Specification
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	12V DC
Output Current	1.5A - 2A (1500mA - 2000mA)
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Product Dimensions	Approximately 4 x 3 x 2 inches (Adapter block)
Item Weight	Approximately 4 ounces

10. WARRANTY AND SUPPORT

Your UpBright DC 12V AC-DC Adapter comes with the following warranty:

- **Refund Policy:** 30 days refund period.
- **Exchange Policy:** 24 months exchange period.

For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official UpBright website.



THIS PRODUCT COMES WITH A UPBRIGHT®


LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image 10.1: An illustration depicting the UpBright Limited Warranty Certificate, indicating the product's coverage.

For international customers, the product may come with a suitable outlet adapter for your region. Please ensure you use the correct adapter for your country's electrical outlets.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image 10.2: Examples of international outlet adapters (AU, EU, UK) that may be included with the product for international orders.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01M0KVUW4>

More documents and user manuals: <https://manuals.plus/>