

[manuals.plus](#) /

› [Samsonite](#) /

› [Samsonite Freeform Carry-On Luggage Instruction Manual](#)

Samsonite 78255-1908

Samsonite Freeform Carry-On Luggage Instruction Manual

INTRODUCTION

The Samsonite Freeform Carry-On Luggage is a meticulously engineered suitcase designed to optimize the modern traveler's journey. Crafted with precision, this carry-on luggage with wheels epitomizes sophistication and functionality, catering to those seeking effortless travel experiences. A 21-inch spacious interior makes it convenient and practical for packing. At the same time, it is compliant with most carry-on size restrictions for international and domestic travel. With exterior dimensions of 21.25" x 15.25" x 10.0" including the wheels, this carry-on luggage is airline-approved for cabin use. Our hard case suitcase with wheels facilitates fluid movement through bustling concourses and urban environments thanks to four multi-directional oversized dual-spinner wheels. The re-engineered lightweight construction further enhances effortless mobility.



Figure 1: Samsonite Freeform Carry-On Luggage (White)

KEY FEATURES

1. Optimal Size and Capacity

The textured, scratch-resistant exterior of this hardshell carry-on luggage measures 23in x 15in x 10in (with wheels), meeting the cabin size restrictions of most airlines. The interior provides ample packing room with a spacious 20.5" x 14.5" x 10.0" area. It has a total capacity of 34 liters.

Maximize Packing Potential



Figure 2: Luggage dimensions and interior capacity.

2. Enhanced Organization

The interior features elastic straps, a divider, and a pouch to ensure belongings remain neatly in place during travel. This thoughtful design helps maintain order and maximize packing potential.



Figure 3: Interior view with divider and cross ribbons for organization.

3. Effortless Mobility

Equipped with four oversized, multi-directional spinner wheels, the luggage glides smoothly in all directions, providing effortless maneuverability through airports and other environments. The re-engineered lightweight hard case, weighing 6.5 lbs, further contributes to ease of movement.



Figure 4: Oversized 360° dual spinner wheels for smooth travel.

4. Integrated TSA-Approved Lock

A built-in TSA-approved combination lock secures your belongings without the need for keys. This feature allows TSA agents to inspect your luggage without damaging the lock, ensuring peace of mind throughout your journey.




Figure 5: Detail of the TSA-Approved combination lock.

5. Expandable Storage

The luggage features an expansion zipper, allowing you to increase packing capacity by an extra inch when needed. This is particularly useful for accommodating souvenirs or extra items acquired during your trip.

Expandable Storage Capacity



Figure 6: Visual representation of the expandable storage feature.


SETUP: SETTING THE COMBINATION LOCK

Your Samsonite Freeform luggage comes with a built-in TSA-approved combination lock. The factory default code is 0-0-0. To set your personal combination, follow these steps:

1. Ensure the lock is set to the default code (0-0-0) or your current known code.
2. Locate the small reset button (often recessed) next to the dials. Use a pen or a pointed object to press and hold this button.
3. While holding the reset button, rotate the dials to your desired three-digit combination.
4. Release the reset button. Your new combination is now set.
5. Test your new combination by scrambling the dials and then entering your new code to open the lock.

Important: Do not change the combination if you don't know the current code, as you risk not being able to open the luggage again.

COMBINATION LOCK INSTRUCTIONS



1. Press the button (indicated by the red arrow)
2. Set the desired code by rotating the numbers to the correct combination
3. Pull the lock to open it
4. Finally, rotate the button back to reset the combination

Important: Do not change the combination if you don't know the current code, as you risk not being able to open the luggage again.

Figure 7: Visual instructions for setting the combination lock.

Video 1: Detailed instructions on how to set and change the TSA lock code.

OPERATING INSTRUCTIONS

Using the Retractable Handle

The luggage features an adjustable ergonomic handle for comfortable maneuvering. To extend or retract the handle, press the button located on the top of the handle and pull up or push down to your desired height. Release the button to lock it in place.



Figure 8: Adjustable ergonomic handle for comfortable use.

Utilizing Spinner Wheels

The four oversized dual-spinner wheels allow for 360-degree rotation, enabling the luggage to be pushed or pulled in any direction with minimal effort. This design reduces strain on your arm and shoulder.

Expanding Luggage Capacity

To expand the luggage, locate the secondary zipper running along the perimeter of the suitcase. Unzip this zipper to release the expandable section, providing additional packing space. Zip it back up to return to the original size.



Video 2: Demonstration of the Samsonite Freeform's expandable feature and spinner wheels.

CARE AND MAINTENANCE

- **Cleaning the Exterior:** For general cleaning, wipe the hardshell exterior with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents that could damage the finish.
- **Cleaning the Interior:** The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing the luggage.

- **Wheel Maintenance:** Periodically check the spinner wheels for any debris (hair, lint, etc.) that might hinder smooth operation. Clean as necessary.
- **Zipper Care:** Keep zippers free from dirt and debris. If zippers become stiff, a small amount of silicone spray or wax can help them glide smoothly.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Lock Not Opening:** Ensure you are entering the correct 3-digit combination. If you have forgotten your combination, refer to the "Setting the Combination Lock" section for reset instructions.
- **Stuck Retractable Handle:** If the handle is difficult to extend or retract, check for any obstructions in the handle mechanism. Ensure the release button is fully depressed when operating.
- **Wheels Not Rolling Smoothly:** Inspect the wheels for trapped debris (hair, lint) and remove it. If the issue persists, the wheel mechanism might require professional inspection.
- **Zipper Malfunction:** If a zipper is stuck, try gently moving the slider back and forth. Ensure no fabric is caught in the zipper teeth. Avoid forcing the zipper, as this can cause damage.

SPECIFICATIONS

Product Dimensions	10 x 15.25 x 21.25 inches
Item Weight	6.5 pounds
Department	Unisex-Adult
Manufacturer	Samsonite Corporation
ASIN	B01M0LQOIL
Item Model Number	78255-1908
Capacity	34 Liters

WARRANTY INFORMATION

The Samsonite Freeform Carry-On Luggage is backed by a 10-year limited warranty, ensuring reliability and durability. This warranty covers manufacturing defects in materials and workmanship. For detailed terms and conditions, please refer to the official Samsonite website or contact customer support.

Optional protection plans are also available for purchase:

- 3-Year Protection Plan
- 4-Year Protection Plan
- Asurion Complete Protect (monthly billing)

CUSTOMER SUPPORT

For further assistance, product inquiries, or warranty claims, please visit the official Samsonite website or contact their customer service department.

Samsonite Official Website: www.samsonite.com

