

[manuals.plus](#) /› [Xoopar](#) /› [Xoopar HUG Booster Power Bank XP61052.20A User Manual](#)

Xoopar XP61052.20A

Xoopar HUG Booster Power Bank XP61052.20A User Manual

Model: XP61052.20A

INTRODUCTION

Thank you for choosing the Xoopar HUG Booster Power Bank. This ultra-thin, portable 500mAh power bank is designed to provide an emergency charge for your mobile devices, offering up to 20% additional battery life for most smartphones. Its compact design with an integrated keychain makes it an ideal companion for on-the-go charging. This manual provides essential information for the safe and efficient use of your device.

Key Features:

- 500mAh mobile booster with multi-cable functionality.
- Includes MFi Lightning and Micro USB charging cables.
- Provides up to 20% charge for compatible phones.
- Designed to charge your mobile phone first, then the HUG power bank via the same USB connector.
- Features a keyring hole and pocket-sized portability.

SETUP

Before first use, it is recommended to fully charge your Xoopar HUG Booster Power Bank.

Identifying Components

CABLE AND POWER IN YOUR POCKET



Image: The Xoopar HUG Booster Power Bank in orange, showcasing its compact design with integrated charging cables for both Apple Lightning and Micro USB devices. The image highlights its portability and dual functionality.



Image: A detailed view of the Xoopar HUG Booster Power Bank, displaying both its front and back. The image clearly shows the integrated Micro USB and Lightning connectors, along with the model number (XP61047) and electrical specifications (IN: 5V / 500mAh, OUT: 5V / 500mAh, 1.85Wh).




Image: An exploded view diagram of the Xoopar HUG Power Bank, illustrating the built-in USB cable and how the interchangeable Micro USB and Lightning adapters can be inserted. This highlights the versatile charging options.

OPERATING INSTRUCTIONS

Charging Your Mobile Device

1. Identify the correct charging cable for your device (Lightning for Apple, Micro USB for Android/other compatible devices).
2. Carefully pull out the integrated cable from the Xoopar HUG.
3. Connect the appropriate adapter (Lightning or Micro USB) to your mobile device.
4. Plug the other end of the integrated cable into your mobile device. The power bank will automatically begin charging your device.



Image: The Xoopar HUG Power Bank connected to an iPhone, actively charging the device. The phone screen shows a low battery indicator, demonstrating the power bank's function in a real-world scenario.

Recharging the Xoopar HUG Power Bank

The Xoopar HUG is designed to be recharged conveniently. It features a pass-through charging mechanism, meaning you can charge your phone and the power bank simultaneously using a single USB port.

1. Ensure your mobile device is connected to the Xoopar HUG (if you wish to charge both).
2. Locate the built-in USB connector on the Xoopar HUG.
3. Plug this USB connector into any standard USB power source, such as a computer's USB port, a wall adapter, or a car charger.
4. The power bank will first prioritize charging your connected mobile device, then proceed to recharge itself.



Image: The Xoopar HUG Power Bank acting as a bridge, connecting an iPhone to a laptop's USB port. This illustrates the pass-through charging capability, allowing both devices to be charged simultaneously.



Image: The Xoopar HUG Power Bank, attached to a keychain, connected to both an iPhone and a laptop. This demonstrates its portability and convenience for charging devices while on the go or at a workstation.

MAINTENANCE

Proper care ensures the longevity and optimal performance of your power bank.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, fully charge the power bank at least once every three months if not in regular use. Avoid completely draining the battery for extended periods.
- **Handling:** Do not drop, disassemble, or attempt to repair the device yourself. This can void the warranty and cause damage.

TROUBLESHOOTING

If you encounter issues with your Xoopar HUG Booster Power Bank, please refer to the following common solutions:

- **Device not charging:**

- Ensure the power bank itself is charged.
- Verify that the cable connections are secure and the correct adapter is used for your device.
- Try connecting the power bank to a different USB power source to recharge it.

- **Slow charging:**

- Ensure the USB power source you are using (e.g., computer port, wall adapter) provides sufficient output. A dedicated wall adapter typically charges faster than a computer USB port.
- Check if the cables are fully inserted and not damaged.

- **Power bank not recharging:**

- Try a different USB power source and cable to recharge the power bank.
- Ensure the built-in USB connector is fully inserted into the power source.

If these steps do not resolve the issue, please contact Xoopar customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Xoopar
Model	XP61052.20A
Model Name	BOY MINI XBOY81001
Battery Capacity	500 Milliamp Hours (mAh)
Battery Cell Composition	Lithium Ion
Voltage	5 Volts
Compatible Devices	Android, Apple, Windows
Connector Type	Micro USB (with MFi Lightning adapter)
Power Source	Battery-driven
Product Dimensions	0.03 x 8.5 x 13 cm
Item Weight	0.09 Kilograms
Model Year	2016

WARRANTY AND SUPPORT

The Xoopar HUG Booster Power Bank XP61052.20A comes with a standard manufacturer's warranty. Please refer to the packaging or the official Xoopar website for specific warranty terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact Xoopar customer service through their official website or the contact information provided with your product packaging.

