Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LS-ROPE-WW-009

Generic 9-Foot LED Rope Light Warm White 3500K User Manual

1. Introduction

This manual provides instructions for the Generic 9-Foot LED Rope Light in Warm White 3500K. This product is designed for accent lighting and can be used in various indoor and outdoor applications. Please read this manual thoroughly before installation and use to ensure safe and optimal performance.

2. Safety Information

Observe the following safety precautions to reduce the risk of fire, electric shock, or injury:

- Read all instructions before installation and use.
- Ensure the power source matches the specified voltage (120V AC).
- Do not submerge the rope light in water, despite its water-resistant rating.
- Avoid piercing, cutting, or damaging the rope light casing, except at designated cut points.
- Do not connect the rope light to another rope light system unless specified as compatible.
- Unplug the rope light from the power source before performing any maintenance or installation.
- Keep out of reach of children.

3. Package Contents

- 1 x 9-Foot LED Rope Light (Warm White 3500K)

4. Setup

The LED Rope Light is designed for plug-and-play installation, making setup straightforward.

1. **Unpack:** Carefully remove the rope light from its packaging.
2. **Placement:** Determine the desired location for your rope light. This product is suitable for outdoor usage, as well as indoor applications like cove lighting, contour lighting, and accent lighting.
3. **Customization (Optional):** The rope light is cuttable every meter to customize its length. If shortening, ensure that any cut ends are properly sealed with appropriate end caps and sealant (not included) to maintain water resistance and safety.
4. **Secure:** Use appropriate mounting clips or ties (not included) to secure the rope light in place along your desired path.

5. **Connect:** Plug the corded rope light into a standard 120V AC power outlet.



Image showing the flexible, clear tubing of the LED rope light with individual warm white LEDs illuminated inside, coiled on a dark surface.

5. Operating Instructions

Once properly installed and connected to a power source, the LED rope light will illuminate.

- **Power On/Off:** The rope light is controlled by the power switch on the connected outlet or an external switch if wired into a system.
- **Dimming:** This rope light is dimmable with most CFL/LED low voltage electronic dimmers. Ensure your dimmer is compatible with LED lighting.
- **Control Method:** The product specifications indicate an 'App' control method. If an app is available, refer to its specific instructions for pairing and control.

6. Maintenance

Proper maintenance ensures the longevity and performance of your LED rope light.

- **Cleaning:** Gently wipe the rope light with a soft, dry, or slightly damp cloth. Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the casing.
- **Inspection:** Periodically inspect the entire length of the rope light for any signs of damage, such as cracks in the casing, exposed wires, or loose connections. If damage is found, discontinue use immediately and replace the unit.
- **Storage:** If storing the rope light, coil it loosely to prevent kinking or damage to the internal wiring. Store in a cool, dry place.

7. Troubleshooting

If you encounter issues with your LED rope light, refer to the following common problems and solutions:

Light does not turn on:

- **Check Power Connection:** Ensure the rope light is securely plugged into a functional 120V AC outlet.
- **Test Outlet:** Plug another device into the same outlet to confirm it is receiving power.
- **Inspect Cord:** Check the power cord for any visible damage.

Lights are dim or flickering:

- **Dimmer Compatibility:** If using a dimmer, ensure it is compatible with LED lighting and is rated for the rope light's wattage.
- **Loose Connections:** Check all connections for tightness.
- **Voltage Drop:** Ensure the power source is providing stable voltage.

If these steps do not resolve the issue, contact customer support.

8. Specifications

Feature	Detail
Model Number	LS-ROPE-WW-009
Brand	Generic
Color	Warm White 3500K
Light Color	White
Light Source Type	LED
Number of Light Sources	108
LED Spacing	1-inch
Item Length	9 feet (108 inches)
Item Dimensions (L x W x H)	108 x 0.5 x 0.5 inches
Item Weight	3 pounds
Power Source	AC

Feature	Detail
Voltage	120 volts AC
Wattage	6.9 watts
Indoor/Outdoor Usage	Outdoor
Water Resistance Level	Water Resistant
Special Feature	Corded
Control Method	App
Connectivity Protocol	Wired
Material Type	Metal

9. Warranty and Support

Specific warranty information is not provided with this product. Please refer to your retailer's return policy or contact the manufacturer for details regarding any applicable warranty.
For technical support, troubleshooting assistance, or further inquiries, please contact your point of purchase or the manufacturer directly.

© 2023 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M0YJ00J

More documents and user manuals: **https://manuals.plus/**