

Polaroid POLSTBP

Polaroid Snap Touch Instant Print Digital Camera User Manual

Model: POLSTBP

- [Features](#)
- [Setup](#)
- [Operation](#)
- [Introduction](#)
- [Maintenance](#)
- [What's in the Box](#)
- [Troubleshooting](#)
- [Key](#)
- [Specifications](#)
- [Support](#)
- [Warranty &](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Polaroid Snap Touch Instant Print Digital Camera. Please read this manual thoroughly before operating the device and retain it for future reference.

The Polaroid Snap Touch camera combines digital photography with instant printing, allowing you to capture and print vibrant 2x3 inch photos directly from the device. It features a touchscreen display for easy navigation and editing, along with video recording capabilities.

2. WHAT'S IN THE BOX

Upon unpacking, ensure all items listed below are present:

- Polaroid Snap Touch Instant Print Digital Camera
- Polaroid ZINK Photo Paper (10-Pack)
- Micro USB Cable
- Wrist Strap
- User Guide (this document)

If any items are missing or damaged, please contact customer support.

3. KEY FEATURES

- **13 Megapixel Camera:** Captures high-resolution still images.
- **1080p/720p HD Video Recording:** Records high-definition video.
- **LCD Touchscreen Display:** For framing shots, navigating menus, and editing photos.

- **ZINK Zero Ink Printing Technology:** Produces 2x3 inch full-color, smudge-proof, water-resistant, and tear-resistant prints without ink cartridges.
- **Built-in Rechargeable Lithium-Ion Battery:** Provides portable power for the camera and printer functions.
- **Built-in Flash:** For improved low-light photography.
- **Built-in Selfie Mirror:** Assists in framing self-portraits.
- **Auto-Timer:** Allows for delayed photo capture.
- **Multiple Picture Modes:** Includes vibrant color, black and white, vintage, and options with Polaroid borders.
- **MicroSD Card Slot:** Supports up to 128GB for saving photos and videos.
- **Bluetooth Connectivity:** Enables connection to the Polaroid mobile app for enhanced editing and sharing.

4. SETUP

4.1 Charging the Battery

1. Connect the Micro USB cable to the camera's charging port.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Allow approximately 2-3 hours for a full charge.
4. Once fully charged, the indicator light will change or turn off, depending on the model.

4.2 Inserting ZINK Photo Paper

1. Open the paper tray door on the side of the camera.
2. Insert a pack of Polaroid ZINK Photo Paper (10-pack) into the tray. Ensure the blue calibration sheet is at the bottom of the stack, facing down.
3. Close the paper tray door securely.



Image: Polaroid Snap Touch camera shown alongside a pack of ZINK photo paper, illustrating the paper loading process.

4.3 Inserting a MicroSD Card (Optional)

1. Locate the MicroSD card slot on the camera.
2. Gently insert a MicroSD card (up to 128GB, sold separately) into the slot until it clicks into place.
3. To remove, push the card in slightly until it springs out.

5. OPERATION

5.1 Powering On/Off

- To power on, press and hold the power button located on the top of the camera.
- To power off, press and hold the power button again until the device shuts down.



Image: Rear view of the Polaroid Snap Touch camera, highlighting the LCD touchscreen and the power button on the top right.

5.2 Taking Photos

1. Frame your shot using the LCD touchscreen display.
2. Adjust settings (e.g., picture mode, flash) via the touchscreen menu.
3. Press the shutter button on the top of the camera to capture the image.



Image: A person holding the Polaroid Snap Touch camera, demonstrating how to frame and take a photo.

5.3 Printing Photos

- After taking a photo, you will be prompted to print or save. Select "Print" on the touchscreen.
- Alternatively, you can select a saved photo from the gallery and choose the print option.
- The camera will automatically print the photo using the loaded ZINK paper.



Image: Front view of the Polaroid Snap Touch camera, showing a freshly printed photo sliding out from the side slot.

5.4 Recording Videos

- Switch to video mode via the touchscreen menu.
- Press the shutter button to start recording. Press again to stop.
- Videos are saved to the MicroSD card.

5.5 Using the Polaroid Mobile App

- Download the free Polaroid app from your device's app store (iOS and Android compatible).
- Enable Bluetooth on your smartphone and pair it with the Polaroid Snap Touch camera.
- Use the app to transfer photos, apply filters, add borders, and other editing features before printing.

6. MAINTENANCE

6.1 Cleaning the Camera

- Use a soft, dry, lint-free cloth to clean the camera body and touchscreen.
- For the lens, use a lens cleaning cloth and solution specifically designed for camera lenses.
- Avoid using harsh chemicals or abrasive materials.

6.2 Battery Care

- Charge the battery fully before first use.
- Avoid extreme temperatures, which can affect battery life.
- If storing the camera for an extended period, charge the battery to about 50% and store in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your Polaroid Snap Touch camera, please refer to the following common solutions:

- **Camera not turning on:** Ensure the battery is fully charged. Try connecting to a power source.

- **Photos not printing:** Check if ZINK photo paper is loaded correctly and if there is enough paper. Ensure the blue calibration sheet is at the bottom.
- **Poor print quality:** Ensure the ZINK paper is not expired or damaged. Clean the print head if necessary (refer to specific instructions in the full user guide if available).
- **Camera freezing:** Try restarting the camera by holding the power button. If the issue persists, remove and reinsert the MicroSD card (if applicable).
- **Bluetooth connectivity issues:** Ensure Bluetooth is enabled on both devices and they are within range. Try unpairing and re-pairing the devices.

For further assistance, please contact Polaroid customer support.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	0.98 x 4.72 x 2.95 inches
Item Weight	13.4 ounces
Model Number	POLSTBP
Batteries	1 Lithium Ion batteries required (included)
Manufacturer	Polaroid
Brand	Polaroid
Film Format Type	Instant
Max Shutter Speed	Not specified (nicht bekannt Seconds)
MicroSD Card Support	Up to 128GB
Photo Resolution	13 Megapixels
Video Resolution	1080p/720p HD

9. WARRANTY AND SUPPORT

The Polaroid Snap Touch Instant Print Digital Camera is covered by a manufacturer's warranty when purchased from authorized dealers. Products from unauthorized re-sellers may not be covered.

For detailed warranty information, product registration, or technical support, please visit the official Polaroid website or contact their customer service department. A list of authorized distributors is available on the manufacturer's website.

Online Support: [Visit the Polaroid Store on Amazon](#)

10. PRODUCT VIDEOS







Polaroid Snap Touch Instant Print Digital Camera Overview

Your browser does not support the video tag.

Video: This video provides an overview of the Polaroid Snap Touch Instant Print Digital Camera, demonstrating its key features and functionality, including instant printing and digital capture.



Related Documents - POLSTBP

	<p>Polaroid Go Generation 2 Instant Camera User Manual</p> <p>Comprehensive user manual for the Polaroid Go Generation 2 instant camera. Learn how to get started, take photos, use special features like the selfie mirror and self-timer, troubleshoot common issues, and find technical specifications and safety information.</p>
	<p>Polaroid Now+ Instant Camera Quick Start Guide and Features</p> <p>Get started with your Polaroid Now+ instant camera. This guide covers setup, app connection, film insertion, creative tools, and basic operation for instant photography.</p>
	<p>Polaroid Lab Quick Start Guide: Setup and Usage Instructions</p> <p>Learn how to set up and use your Polaroid Lab instant photo printer with this comprehensive quick start guide. Includes charging, app connection, film insertion, and photo development steps.</p>
	<p>Polaroid Now Instant Camera Generation 2 User Manual</p> <p>Comprehensive user manual for the Polaroid Now Instant Camera Generation 2, covering setup, operation, tips for great photos, troubleshooting, technical specifications, and safety information.</p>
	<p>Polaroid Go Instant Camera: Quick Start Guide and Features</p> <p>Learn how to use your Polaroid Go instant camera with this concise, SEO-optimized guide. Covers setup, taking photos, and essential features.</p>
	<p>Polaroid POP Instant Print Digital Camera Quick Start Guide</p> <p>Get started quickly with your Polaroid POP Instant Print Digital Camera. This guide covers setup, basic operations, features, and warranty information.</p>