



[Manuals.plus](#) /

> [Summer Infant](#) /

> User Manual: Replacement Battery for Summer Infant Wide View & Clear Sight Baby Monitors

## Summer Infant 43224-21909

# Instruction Manual: Replacement Battery for Summer Infant Baby Monitors

Model: 43224-21909

## INTRODUCTION

---

This manual provides essential information for the proper installation, use, and maintenance of your new replacement battery for Summer Infant Wide View (#29000, #29000A) and Clear Sight (#29040, #29030) Parent Handheld Baby Monitors. This battery is designed to replace Summer part number 29030-10, restoring the portability and functionality of your monitor.

## SAFETY INFORMATION

---

Please read and understand all safety warnings before using the battery.

- **WARNING: DO NOT BURN OR PUNCTURE BATTERIES.** Improper disposal or damage can lead to fire, explosion, or chemical burns.
- Always charge the battery for a minimum of 16 hours prior to its first use to ensure optimal performance and longevity.
- Do not expose the battery to extreme temperatures, direct sunlight, or water.
- Keep the battery out of reach of children and pets.
- If the battery shows signs of damage, swelling, or leakage, discontinue use immediately and dispose of it properly according to local regulations.

## SETUP

---

Follow these steps to install the replacement battery into your Summer Infant baby monitor:

1. Ensure your baby monitor is powered off and disconnected from any power source.
2. Locate the battery compartment on the back of your parent handheld monitor. Refer to your monitor's original user manual for specific instructions on opening the compartment.
3. Carefully remove the old battery, if present, by disconnecting its connector from the monitor's port.

4. Align the connector of the new battery with the port inside the battery compartment. Gently push until it clicks into place, ensuring a secure connection.
5. Place the battery into the compartment, ensuring the 'THIS SIDE UP' label (if present on the battery) faces the correct direction.
6. Close the battery compartment cover securely.
7. Connect your monitor to its power adapter and charge the new battery for a minimum of 16 hours before its first use.



This image displays the Desay Ni-MH battery, which is green and rectangular, featuring a white label with product specifications and warnings. A red and black wire extends from one end, terminating in a white connector. The label indicates 'THIS SIDE UP'.

## OPERATING

---

Once installed and fully charged, your monitor's battery will provide portable power. The battery life will vary depending on usage, such as continuous video streaming, screen brightness, and audio activity. For optimal battery life, consider the following:

- After the initial 16-hour charge, subsequent charges can be shorter, typically 8-12 hours for a full charge.
- To conserve battery power, reduce screen brightness or turn off the video display when not actively monitoring.
- Always recharge the battery when the monitor indicates low battery to prevent deep discharge, which can shorten battery lifespan.

## MAINTENANCE

---

Proper maintenance can extend the life of your battery:

- Avoid leaving the battery completely discharged for extended periods.
- Store the monitor and battery in a cool, dry place when not in use.
- Do not attempt to open or modify the battery pack.
- Clean the battery contacts periodically with a dry cloth to ensure good connection.

## TROUBLESHOOTING

---

If you experience issues with your battery, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Battery not holding a charge	Initial charge insufficient; battery nearing end of life; improper connection.	Ensure initial 16-hour charge. Re-seat battery connector. If problem persists, battery may need replacement.
Monitor not powering on with battery	Battery not charged; battery not properly installed; faulty battery.	Charge battery fully. Check battery connection. If monitor works with power adapter but not battery, battery may be faulty.
Short battery life	High usage (e.g., continuous video); battery degradation.	Reduce screen brightness or turn off video when not needed. Ensure full charges. Battery capacity naturally decreases over time.

## SPECIFICATIONS

---

- **Voltage:** 3.6V
- **Chemistry:** NiMH (Nickel-Metal Hydride)
- **Capacity:** 900mAh
- **Dimensions:** Approximately 2.2 x 1.6 x 0.6 inches
- **Weight:** Approximately 0.16 ounces
- **Compatible with:** Summer Infant Wide View #29000, #29000A & Clear Sight #29040, #29030 Parent Handheld Baby Monitors (Replaces Summer part number 29030-10)

## WARRANTY AND SUPPORT

---

This replacement battery comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or improper installation.

For warranty claims or technical support, please contact the seller or refer to the original Summer Infant monitor's support channels for general monitor operation inquiries. Keep your proof of purchase for warranty validation.