

Hurom HZ

HUROM HZ Slow Juicer Instruction Manual

Model: HZ | Brand: Hurom

1. INTRODUCTION

Thank you for choosing the HUROM HZ Slow Juicer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read all instructions carefully before use and retain this manual for future reference.

The HUROM HZ Slow Juicer utilizes Slow Squeeze Technology, operating at a low speed of 43 revolutions per minute to gently extract juice, preserving nutrients and natural flavors. Its stainless steel finish and quiet 150-watt AC motor ensure a premium juicing experience.



Image: The HUROM HZ Slow Juicer in Silver, demonstrating juice extraction with carrots.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.

- Keep hands and utensils out of the feed chute during operation to prevent injury.
- Ensure all parts are correctly assembled before turning on the appliance.
- Unplug the juicer from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only.

3. PACKAGE CONTENTS

Verify that all components are present and in good condition upon unpacking.

Inside the Box



Twin Wing Auger



Juice & Pulp Container



Hopper & Chamber



Spinning Brush



Juicer Body



Pusher



Drying Rack



Tofu Press



Squeezer



Manual and Recipe Book



Large & Small Cleaning Brush



Fine, Coarse, and Ice Cream Strainer

Image: An overview of the HUROM HZ Slow Juicer and its included accessories.

- Juicer Body (Motor Base)
- Chamber Set (Hopper & Chamber)
- Twin Wing Auger
- Fine Strainer
- Coarse Strainer
- Ice Cream Strainer (for sorbets)
- Spinning Brush
- Juice Container
- Pulp Container
- Pusher
- Cleaning Brush (Large & Small)
- Drying Rack
- Tofu Press
- Instruction Manual and Recipe Book

4. ASSEMBLY

Follow these steps to correctly assemble your HUROM HZ Slow Juicer:

1. Place the motor base on a stable, flat surface.
2. Align the chamber set with the motor base and rotate clockwise until it locks into place.
3. Insert the spinning brush into the chamber.
4. Place your desired strainer (fine, coarse, or ice cream) inside the spinning brush.
5. Insert the twin wing auger into the center of the strainer.
6. Attach the hopper to the top of the chamber, ensuring it clicks securely.
7. Position the juice container under the juice spout and the pulp container under the pulp outlet.

Your browser does not support the video tag.

Video: Demonstrates the step-by-step assembly process of the Hurom Juicer.

5. OPERATING INSTRUCTIONS

Prepare your ingredients by washing them thoroughly. For optimal results, cut larger fruits and vegetables into pieces that fit easily into the feed chute. The HZ model features a pulp control lever for customized juice consistency.

1. Ensure the juicer is properly assembled and plugged into a grounded electrical outlet.
2. Place the juice container and pulp container in their respective positions.
3. Turn the power switch to the 'ON' position.

4. Slowly feed ingredients into the hopper. Use the pusher only if necessary to guide ingredients.
5. Adjust the pulp control lever on the juice spout to achieve your desired pulp level.
6. For continuous juicing, ensure the juice cap is open. Close it to mix juices within the chamber before dispensing.
7. If ingredients become jammed, switch to 'REV' (reverse) for a few seconds, then back to 'ON'.
8. After juicing, turn the power switch to 'OFF' and unplug the appliance.





Image: The HUROM HZ Slow Juicer from the side, highlighting the juice spout and pulp outlet.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your juicer. All removable parts are dishwasher safe.

1. Turn off and unplug the juicer immediately after use.
2. Disassemble the juicer by reversing the assembly steps.
3. Rinse all removable parts under running water to remove any large pulp residue.
4. Use the provided cleaning brushes to thoroughly scrub the strainer and other components, paying attention to small crevices.
5. Wash all parts with warm, soapy water.
6. Rinse thoroughly and allow to air dry on the drying rack, or wipe with a clean cloth.
7. Wipe the motor base with a damp cloth. Never immerse the motor base in water.
8. Reassemble the juicer once all parts are completely dry.

Your browser does not support the video tag.

Video: Provides a detailed guide on how to clean your Hurom Juicer components.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly.	Ensure power cord is securely plugged in; reassemble all parts, ensuring they click into place.

Problem	Possible Cause	Solution
Motor stops during operation.	Overload due to hard ingredients or too much produce.	Press 'REV' button for 2-3 seconds, then 'ON'. If it doesn't restart, disassemble, clean, and reassemble.
Excessive pulp in juice.	Coarse strainer used; pulp control lever setting.	Use the fine strainer; adjust the pulp control lever to a lower setting.
Juicer vibrates excessively or makes unusual noise.	Improper assembly; foreign object inside.	Disassemble and reassemble carefully; check for any foreign objects and remove them.

8. SPECIFICATIONS

Brand: Hurom

Model Name: HUROM HZ Slow Juicer

Model Number: HZ

Color: Silver

Product Dimensions: 8.1"D x 9.3"W x 16"H

Item Weight: 11.9 pounds

Maximum Power: 150 Watts

Voltage: 230 Volts

Capacity: 16.9 Fluid Ounces (Chamber)

Power Source: Corded Electric

Blade Material: Stainless Steel

Special Feature: Pulp Control

UPC: 888253000387

ASIN: B01M16OH2X

9. WARRANTY AND SUPPORT

The HUROM HZ Slow Juicer comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, replacement parts, or further assistance, please visit the official Hurom America website or contact their customer service.

Hurom America Store: [Visit the Hurom Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question