Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Finether T002359

Finether Aluminum Folding Hand Truck Dolly

Model: T002359

1. Introduction

This manual provides comprehensive instructions for the safe and effective use of your Finether Aluminum Folding Hand Truck Dolly. Designed for portability and convenience, this multi-purpose trolley is ideal for transporting various items, including luggage, boxes, and office supplies. Please read this manual thoroughly before operation to ensure proper handling and to maximize the lifespan of your product.



Image 1.1: The Finether Aluminum Folding Hand Truck Dolly in its upright, ready-to-use position, with two bungee cords included.

2. Safety Information

- **Weight Capacity:** Do not exceed the maximum load capacity of 154 lbs (70 kg). Overloading can cause damage to the hand truck and may lead to injury.
- **Load Distribution:** Always distribute the load evenly on the nose plate. Secure items with the included bungee cords or other appropriate restraints to prevent shifting or falling during transport.
- **Stability:** Ensure the hand truck is stable before moving. Avoid sudden movements or turns, especially on uneven surfaces.
- **Handle Use:** Use the telescoping handle properly. Ensure it is locked at the desired height before use. Do not use the handle to lift the hand truck with heavy loads.
- **Stairs and Ramps:** Exercise extreme caution when navigating stairs or ramps. Always pull the hand truck down stairs and push it up ramps, maintaining control of the load.
- **Children:** Keep children away from the hand truck during operation and storage. This product is not a toy.
- **Maintenance:** Regularly inspect the hand truck for any signs of wear, damage, or loose parts. Do not use if damaged.

3. Product Components and Features

The Finether Hand Truck Dolly is constructed with durable materials and designed for ease of use. Key components and features include:

- **Aluminum Alloy Frame:** Provides a lightweight yet sturdy structure, resistant to corrosion and rust.
- **Die-Cast Aluminum Nose Plate:** A robust platform for carrying loads, designed for durability.
- **Telescoping Handle:** Adjustable to two heights (35.43 in and 39.37 in) for comfortable use by different individuals and for varying load sizes. Features an ergonomic grip.
- **Quiet-Rolling Solid Rubber Wheels:** 4.92-inch diameter wheels with a rough-textured tread for smooth movement without streaking or damaging floors.
- **Secured Riveted Joints:** Enhances the overall stability of the frame.
- **Bungee Cords:** Two free bungee cords are included to help secure loads.




Image 3.1: Diagram illustrating the ergonomic handle, aluminum alloy frame, secured riveted joints, non-slip die-cast aluminum nose plate, quiet-rolling rubber wheels, and bungee cords.



Image 3.2: A visual comparison highlighting the superior features of the Finether hand truck's solid rubber casters, including larger diameter, solid rubber material, wear-resistant tread, and quiet rolling.

4. Operating Instructions

4.1. Opening the Hand Truck

1. Hold the handle firmly. Press the lock release bar upwards to extend the handle to your desired height (35.43 in or 39.37 in) until it locks into place.
2. Step on the nose plate with one foot to unfold it completely. Ensure the nose plate is fully extended and stable before placing any load.

4.2. Loading and Transporting

1. Place the item(s) to be transported onto the nose plate. Ensure the weight is centered and within the 154 lbs capacity.
2. Use the provided bungee cords to secure the load to the hand truck frame. Wrap the cords around the item(s) and hook them securely to the frame.

3. Tilt the hand truck backward by pulling the handle towards you until the load is balanced on the wheels.
4. Carefully push or pull the hand truck to your destination. Maintain a firm grip on the handle and be aware of your surroundings.



Image 4.1: A person demonstrating the ease of transporting two cases with the Finether Hand Truck Dolly, highlighting its 154 lbs capacity.



Image 4.2: Collage showing the Finether Hand Truck Dolly being used in various scenarios, including moving a crate, transporting plants, for outdoor activities, and at a market.

4.3. Folding the Hand Truck for Storage

1. Ensure the hand truck is unloaded.
2. Step on the nose plate and tilt the handle towards you to begin folding the nose plate and wheels inward.
3. Press the lock release bar upwards to collapse the extended handle fully.
4. Once fully folded, the hand truck will be compact for easy storage or transport.



Image 4.3: Step-by-step visual guide for both opening and folding the Finether Hand Truck Dolly, showing the handle extension and nose plate movement.



Image 4.4: The Finether Hand Truck Dolly folded down to a compact size, easily fitting into a car trunk for convenient storage and transport.

5. Maintenance

- **Cleaning:** Wipe down the aluminum frame and plastic components with a damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lubrication:** Periodically check the moving parts, such as the telescoping handle mechanism and wheel axles. Apply a small amount of silicone-based lubricant if movement becomes stiff.
- **Inspection:** Before each use, inspect the hand truck for any loose screws, damaged wheels, or bent frame components. Ensure all riveted joints are secure.
- **Storage:** Store the folded hand truck in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.

6. Troubleshooting

Problem	Possible Cause	Solution
Handle does not extend or retract smoothly.	Dirt or debris in the telescoping mechanism; lack of lubrication; bent handle components.	Clean the handle mechanism. Apply silicone lubricant. If bent, contact customer support.
Wheels are noisy or do not roll freely.	Debris caught in wheels; worn bearings; lack of lubrication.	Remove any debris. Check for wear. Apply lubricant to axles if accessible.
Hand truck feels unstable or wobbly.	Overloaded; uneven load distribution; loose joints or fasteners.	Reduce load to within capacity. Redistribute load evenly. Inspect and tighten any loose fasteners.
Nose plate does not fold/unfold correctly.	Mechanism obstructed or damaged.	Check for obstructions. Ensure proper technique as per operating instructions. Do not force.

7. Specifications

- **Brand:** Finether
- **Model Number:** T002359
- **Material:** Aluminum Alloy (Frame), Die-Cast Aluminum (Nose Plate), Solid Rubber (Wheels)
- **Color:** Black
- **Load Capacity:** 154 lbs (70 kg)
- **Product Dimensions (Extended):** Approximately 16" L x 14.9" W x 39.4" H (40.6 cm L x 37.8 cm W x 100 cm H)
- **Product Dimensions (Folded):** Approximately 25.2" H (64 cm H) - compact size
- **Item Weight:** Approximately 3.6 lbs (1.63 kg)
- **Wheel Diameter:** 4.92 inches (12.5 cm)
- **Number of Wheels:** 2
- **UPC:** 768390145199

8. Warranty and Support

Finether products are manufactured to high-quality standards. For any questions, concerns, or warranty inquiries regarding your Finether Aluminum Folding Hand Truck Dolly, please contact Finether customer support through the retailer's platform or the official Finether website. Please have your model number (T002359) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01M1J2Q2N

More documents and user manuals: **https://manuals.plus/**