

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Merkury Innovations](#) /

› Merkury Innovations MI-SPB12-101 Rugged Wireless Bluetooth Speaker User Manual

Merkury Innovations MI-SPB12-101

Merkury Innovations MI-SPB12-101 Rugged Wireless Bluetooth Speaker User Manual

INTRODUCTION

Thank you for purchasing the Merkury Innovations MI-SPB12-101 Rugged Wireless Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device. The MI-SPB12-101 is designed for portability and durability, offering wireless audio streaming for various environments.

PACKAGE CONTENTS

- Merkury Innovations MI-SPB12-101 Rugged Wireless Bluetooth Speaker
- USB Charging Cable
- Auxiliary Audio Cable (3.5mm)
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your speaker:



Image Description: A black, rugged wireless Bluetooth speaker, model MI-SPB12-101, is shown with water droplets on its surface. The speaker has a textured, durable casing, suggesting water resistance. The front grille is visible, and the overall design is compact and robust.

- **Power Button:** Turns the speaker on or off.
- **Bluetooth Indicator LED:** Shows Bluetooth connection status.
- **Volume Up/Next Track Button:** Increases volume or skips to the next track.

- **Volume Down/Previous Track Button:** Decreases volume or goes to the previous track.
- **Play/Pause/Call Button:** Controls audio playback and manages phone calls.
- **Charging Port:** For connecting the USB charging cable.
- **Aux-in Port:** For wired audio connection (3.5mm).

SETUP

1. Charging the Speaker

1. Connect the small end of the USB charging cable to the speaker's charging port.
2. Connect the large end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate, typically red, during charging.
4. Once fully charged, the indicator light will change color or turn off (refer to specific LED behavior in the full manual if available). A full charge usually takes 2-3 hours.

Note: For best results, fully charge the speaker before its first use.

2. Powering On/Off

- To power on, press and hold the **Power Button** for approximately 3 seconds. An audible tone or voice prompt will indicate the speaker is on. The Bluetooth indicator LED will flash, indicating it's ready for pairing.
- To power off, press and hold the **Power Button** for approximately 3 seconds. An audible tone or voice prompt will indicate the speaker is turning off.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

1. Ensure the speaker is powered on and the Bluetooth indicator LED is flashing (indicating pairing mode).
2. Enable Bluetooth on your mobile device (smartphone, tablet, computer).
3. Search for Bluetooth devices. The speaker will appear as "**MI-SPB12-101**" or "**Merkury Speaker**".
4. Select the speaker from the list to connect.
5. Once successfully paired, the Bluetooth indicator LED will stop flashing and remain solid, and an audible tone or voice prompt will confirm the connection.
6. The speaker will automatically attempt to reconnect to the last paired device when powered on, if that device's Bluetooth is active and within range.

2. Audio Playback

- **Play/Pause:** Press the **Play/Pause Button** once to play or pause audio.
- **Volume Control:**
 - Press and hold the **Volume Up (+) Button** to increase volume.
 - Press and hold the **Volume Down (-) Button** to decrease volume.
- **Track Navigation:**
 - Press the **Volume Up (+) Button** once to skip to the next track.

- Press the **Volume Down (-) Button** once to go to the previous track.

3. Answering Calls

- When a call comes in, the speaker will ring.
- Press the **Play/Pause/Call Button** once to answer the call.
- Press the **Play/Pause/Call Button** once again to end the call.
- Press and hold the **Play/Pause/Call Button** to reject an incoming call.

4. Wired Connection (AUX Mode)

- Connect one end of the 3.5mm auxiliary audio cable to the speaker's Aux-in port.
- Connect the other end to the headphone jack of your audio device.
- The speaker will automatically switch to AUX mode.
- Control playback and volume directly from your connected audio device.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents. If the speaker gets wet, wipe it dry thoroughly before charging or storing.
- **Storage:** Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight.
- **Battery Care:** To prolong battery life, fully charge the speaker at least once every three months if not in regular use.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect it to a power source using the USB cable.
Cannot pair with Bluetooth device.	Ensure the speaker is in pairing mode (flashing Bluetooth LED). Make sure Bluetooth is enabled on your device and it's within 10 meters (33 feet) of the speaker. Forget the speaker from your device's Bluetooth list and try pairing again. Restart both the speaker and your device.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly paired via Bluetooth or the AUX cable is securely connected. Check if the audio source on your device is playing.
Poor audio quality.	Move the speaker closer to your Bluetooth device to reduce interference. Avoid placing the speaker near other wireless devices. Try a different audio source or file.

SPECIFICATIONS

Feature	Detail
Model Number	MI-SPB12-101
Brand	Merkury Innovations
Connectivity	Wireless (Bluetooth)
Power Source	Electric Cable (<i>Implies rechargeable battery via cable</i>)
Mounting Type	Floor Mount, Table Mount
Special Feature	Wireless
Subwoofer Diameter	12 Inches
Product Dimensions	16.8 x 16 x 8.4 cm
Product Weight	476 g

Note: The listed "Subwoofer Diameter: 12 Inches" may refer to a different product or a misinterpretation of specifications, as the visual appearance of the MI-SPB12-101 speaker suggests a more compact design.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or open flames.
- Do not disassemble, repair, or modify the speaker. This will void the warranty and may cause damage.
- Keep the speaker away from water and liquids, unless specifically rated for water resistance.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- Keep out of reach of children.

WARRANTY AND SUPPORT

Merkury Innovations products are designed with quality and performance in mind. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Merkury Innovations website. For technical support or customer service inquiries, please contact Merkury Innovations directly through their official channels.

Please retain your proof of purchase for warranty claims.