

Kingfisher Kingfisher

Kingfisher 2000W Wall-Mounted Electric Patio Heater Instruction Manual

Model: Kingfisher (2000W Wall-Mounted Electric Patio Heater)

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before assembling, installing, operating, or maintaining this product. Failure to follow these instructions may result in electric shock, fire, property damage, or serious injury.

- **Read all instructions:** Ensure you have read and fully understood this manual before use.
- **Electrical Safety:** This heater operates on 240 Volts. Ensure the power outlet is properly grounded and rated for 2000W. Do not overload the circuit.
- **Outdoor Use Only:** This product is designed for outdoor use and has an IPX4 waterproof rating, protecting against splashing water. Do not immerse in water.
- **Flammable Materials:** Keep the heater at a safe distance from flammable materials such as furniture, curtains, paper, clothing, and chemicals. Maintain a minimum clearance of 1 meter (3 feet) from any combustible surfaces.
- **Hot Surfaces:** The heater becomes very hot during operation. Do not touch the heating element or surrounding surfaces while in use or shortly after. Allow sufficient time for cooling.
- **Supervision:** Do not leave the heater unattended while in operation. Keep children and pets away from the heater.
- **Overheat Protection:** The heater is equipped with overheat protection. If it overheats, it will automatically shut off. Unplug the unit, allow it to cool, and check for any obstructions before restarting.
- **Anti-Tilt Switch:** An anti-tilt switch is integrated for safety. If the heater is not in an upright and stable position, it will not operate.
- **Power Cord:** Do not route the power cord under carpeting or cover it with throw rugs. Position the cord away from high traffic areas to prevent tripping hazards. Do not use if the cord is damaged.
- **Maintenance:** Always disconnect the power supply before cleaning, maintenance, or moving the heater.
- **Modifications:** Do not attempt to repair or modify the heater yourself. Contact qualified service personnel for any repairs.

2. PRODUCT OVERVIEW

The Kingfisher 2000W Wall-Mounted Electric Patio Heater is designed to provide efficient radiant heat for outdoor spaces. Its robust construction and safety features ensure reliable performance.



Image 1: Front view of the Kingfisher 2000W Wall-Mounted Electric Patio Heater, highlighting the radiant heating elements behind the protective grille.

Key Features:

- 2000W heating power.
- Wall-mounted design for space-saving installation.
- 45-degree tiltable heating element for adjustable heat direction.
- Overheat protection for enhanced safety.
- Anti-tilt switch for automatic shut-off if not stable.
- IPX4 waterproof rating, suitable for outdoor environments.

3. SETUP AND INSTALLATION

This heater is designed for wall mounting. Choose a suitable location that is protected from direct rain and wind, and ensures adequate clearance from flammable materials.

Installation Steps:

1. **Choose Location:** Select a sturdy wall surface, such as brick or concrete, capable of supporting the heater's weight (2.4 kg). Ensure the mounting height allows for optimal heat distribution and safe operation, typically at least 1.8 meters (6 feet) from the ground.
2. **Mark Drilling Points:** Hold the mounting bracket (if separate) or the heater itself against the wall at the desired height. Mark the positions for the drilling holes.
3. **Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked positions. Insert wall plugs if necessary.
4. **Secure Mounting Bracket:** Attach the mounting bracket securely to the wall using the provided screws. Ensure it is level and firmly fixed.

5. **Attach Heater:** Mount the heater onto the secured bracket. Follow the specific instructions for your model to ensure it clicks or locks into place.
6. **Adjust Tilt:** The heating element can be tilted up or down by 45 degrees. Adjust the angle to direct heat to your desired area.
7. **Power Connection:** Plug the heater into a suitable 240V outdoor-rated power outlet. Ensure the power cord is not stretched or pinched.



Image 2: The Kingfisher 2000W Wall-Mounted Electric Patio Heater securely installed on an outdoor brick wall, showing its compact design and power cable connection.

4. OPERATING INSTRUCTIONS

Operating the Kingfisher patio heater is straightforward once installed.

1. **Power On:** Ensure the heater is securely mounted and plugged into a suitable power outlet. Turn on the power switch, usually located on the unit or its power cord.
2. **Heat Output:** The heater will immediately begin to emit radiant heat. It has a fixed output of 2000 Watts.
3. **Adjust Angle:** If needed, carefully adjust the tilt of the heating element (up to 45 degrees) to direct the heat to your preferred area. Ensure the heater is off and cool before making adjustments if

possible, or use protective gloves.

4. **Power Off:** To turn off the heater, switch off the power button on the unit or unplug it from the power outlet.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your patio heater. Always disconnect the heater from the power supply before performing any maintenance.

- **Cleaning:** Allow the heater to cool completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or components.
- **Dust Removal:** Periodically check the protective grille and heating elements for dust or debris accumulation. Use a soft brush or compressed air to gently remove any build-up. Do not use water directly on the heating elements.
- **Power Cord Inspection:** Regularly inspect the power cord and plug for any signs of damage, fraying, or overheating. If any damage is found, discontinue use and contact a qualified electrician for repair or replacement.
- **Storage:** If the heater will not be used for an extended period, clean it thoroughly and store it in a dry, protected area, away from moisture and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Kingfisher patio heater, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Anti-tilt switch activated. Overheat protection activated.	Check if the power cord is securely plugged in. Test the outlet with another appliance. Check the circuit breaker. Ensure the heater is on a stable, level surface or securely mounted. Unplug the heater, allow it to cool for 30 minutes, then plug it back in. Check for obstructions.
Heater turns off unexpectedly.	Overheat protection activated. Anti-tilt switch activated.	Unplug the heater, allow it to cool for 30 minutes, then plug it back in. Check for obstructions around the heater. Ensure the heater is stable and upright. Re-mount if necessary.
Reduced heat output.	Dust or debris on heating elements. Voltage fluctuation.	Disconnect power and allow to cool. Gently clean heating elements with a soft brush. Ensure the power supply is stable and meets 240V requirements.

If the problem persists after attempting these solutions, please contact customer support or a qualified technician.

7. SPECIFICATIONS

Brand:	Kingfisher
Model Number:	Kingfisher (2000W Wall-Mounted Electric Patio Heater)
ASIN:	B01M2ZYXCD
Color:	Transparent (element)
Dimensions (L x W x H):	50.5 x 16.5 x 25.2 cm
Weight:	2.4 Kilograms
Voltage:	240 Volts
Heat Output:	2000 Watts
Power Source:	Electric Cord
Heating Method:	Radiant
Mounting Type:	Wall Mount
Indoor/Outdoor Use:	Outdoor
Waterproof Rating:	IPX4
Safety Features:	Overheat Protection, Anti-tilt Switch

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Specific warranty terms may vary by region and retailer.

For technical support, spare parts, or further assistance, please contact the Kingfisher customer service department or your product retailer. Keep your purchase receipt and model information handy when contacting support.