



Manuals.plus /

- › Satisfyer /
- › Satisfyer Double Classic Vibrator Instruction Manual

Satisfyer PARTNER

Satisfyer Double Classic Vibrator Instruction Manual

Model: PARTNER | Brand: Satisfyer

1. INTRODUCTION

Welcome to the instruction manual for your Satisfyer Double Classic Vibrator. This guide provides essential information for the safe and effective use, maintenance, and care of your device. Please read this manual thoroughly before first use and retain it for future reference.



Image: The Satisfyer Double Classic Vibrator, showcasing its ergonomic design.

2. SAFETY INFORMATION

Your safety is paramount. Please observe the following safety guidelines:

2.1 General Safety

- This device is intended for adult use only.
- Do not use the device if it appears damaged, cracked, or defective.
- Discontinue use immediately if you experience any discomfort, irritation, or pain.
- Keep the device out of reach of children and pets.

2.2 Material and Lubricant Safety

- The device is made from body-friendly silicone. Clean thoroughly before and after each use.
- Use only **water-based lubricants** with this device. Oil-based, silicone-based, or petroleum-based lubricants can damage the silicone material and void the warranty.

2.3 Charging Safety

- Use only the magnetic USB charging cable provided with your device.

- Do not leave the device charging unattended for extended periods.
- Ensure the charging contacts on both the device and the cable are dry and clean before charging.

3. PRODUCT OVERVIEW

The Satisfyer Double Classic is a versatile vibrator designed to provide targeted stimulation for both solo and couple use. Its ergonomic shape and powerful vibrations are engineered for enhanced pleasure.



Image: A close-up view of the Satisfyer Double Classic Vibrator.

3.1 Key Features

- **Body-Friendly Silicone:** Made from high-quality, medical-grade silicone for a soft and safe experience.
- **10 Vibration Programs:** Offers a variety of patterns and intensities for diverse sensations.
- **Waterproof (IPX7):** Fully submersible for easy cleaning and use in water.
- **Magnetic USB Charging:** Convenient and secure charging mechanism.
- **Ergonomic Design:** Shaped for comfortable handling and effective stimulation.




Image: Illustrates the body-friendly silicone material of the device.



Image: Demonstrates the device's waterproof (IPX7) capability.

4. SETUP

4.1 Initial Charging

Before using your Satisfyer Double Classic for the first time, ensure it is fully charged.

1. Locate the magnetic charging contacts on your device.
2. Connect the provided magnetic USB charging cable to these contacts. The cable will snap into place.
3. Plug the USB end of the cable into a compatible USB power source (e.g., computer, USB wall adapter).
4. The indicator light on the device will illuminate to show it is charging. It will turn off or change color when fully charged.



Image: The magnetic USB charging cable for the Satisfyer Double Classic.

4.2 Cleaning Before First Use

For hygiene, clean the device before its initial use.

1. Wash the device thoroughly with warm water and a mild, toy-friendly soap or a specialized toy cleaner.
2. Rinse completely under running water.
3. Pat dry with a lint-free cloth or allow to air dry.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and functions of your Satisfyer Double Classic.



Comfortable to Hold and Easy to Use:



Image: The device with its power and program buttons clearly indicated.

5.1 Power On/Off

- To turn on: Press and hold the **circular power button** for approximately 2 seconds. The indicator light will illuminate.
- To turn off: Press and hold the **circular power button** for approximately 2 seconds. The indicator light will turn off.

5.2 Changing Vibration Programs

- While the device is on, press the **smaller program button** (with wave icon) to cycle through the 10 available vibration programs.
- Each press will switch to the next program.

5.3 Usage Guidelines

1. Apply a generous amount of water-based lubricant to the device and the desired areas of the body.
2. Position the device as desired for stimulation. The flexible design allows for various positions for both solo and partner play.
3. Experiment with different vibration programs and pressure to find what is most pleasurable.




Image: Illustrates the device's suitability for partner use.

Your browser does not support the video tag.

Video: Official product video demonstrating the features and usage of the Satisfyer Double Classic Vibrator.

6. MAINTENANCE

6.1 Cleaning

Proper cleaning ensures hygiene and prolongs the life of your device.

1. Always clean your device immediately after each use.
2. Wash with warm water and a mild, toy-friendly soap or a specialized toy cleaner.
3. Rinse thoroughly under running water to remove all soap residue.
4. Pat dry with a lint-free cloth or allow to air dry completely before storage.

6.2 Storage

Store your device correctly to maintain its condition.

- Store the device in a clean, dry, and dust-free environment.
- Keep it away from direct sunlight and extreme temperatures.
- Avoid storing with other toys made of different materials, especially silicone, to prevent material degradation. Store in its original packaging or a dedicated storage pouch.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Device does not turn on	Low battery; Incorrect power button press	Fully charge the device; Press and hold the power button for 2 seconds
Vibrations are weak	Low battery	Recharge the device
Device does not charge	Loose cable connection; Faulty USB source; Dirty contacts	Ensure cable is secure; Try a different USB port/adaptor; Clean charging contacts
Discomfort during use	Insufficient lubricant; Allergic reaction	Apply more water-based lubricant; Discontinue use if discomfort persists and consult a healthcare professional

8. SPECIFICATIONS

- **Model:** PARTNER
- **Material:** Body-friendly Silicone
- **Dimensions (L x W x H):** 3 x 2 x 2 inches
- **Weight:** 0.04 ounces
- **Battery:** 1 Lithium Ion (rechargeable)
- **Waterproof Rating:** IPX7
- **Vibration Programs:** 10
- **Manufacturer:** Satisfyer

9. WARRANTY AND SUPPORT

The Satisfyer Double Classic is backed by a **15-year product guarantee**, reflecting our commitment to quality and durability.



Image: Logo indicating the 15-year product guarantee.

For warranty claims, technical support, or further assistance, please visit the official Satisfyer website or contact their customer service directly. Contact information can typically be found on the product packaging or the official brand website: www.satisfyer.com