JustFine 8541714211

JustFine Replacement Remote Control Instruction Manual

For Sony STR-DH510, STR-DH710, and HTSS370HP Audio/Video AV Receiver Home Theater Systems

Introduction

This manual provides instructions for the JustFine replacement remote control, designed for use with various Sony Audio/Video AV Receiver Home Theater Systems. This remote is pre-programmed and requires no additional setup beyond battery installation.

Compatibility

This replacement remote control is compatible with the following Sony models:

- Sony STR-DH510
- Sony RMAAU071
- Sony 148761111
- Sony STR-DH710
- Sony HTSS370HP

Package Contents

- 1 x JustFine Replacement Remote Control

Note: Batteries and an instruction manual are not included in the package.

Setup: Installing Batteries

To begin using your remote control, you must first install the batteries. This remote requires Alkaline AA

batteries.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two (2) AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control, highlighting the battery compartment cover. The compartment is designed for

easy access to insert or replace batteries.

Operation

This replacement remote control is pre-programmed and ready for immediate use with compatible Sony AV Receiver Home Theater Systems once batteries are installed. No additional programming is required.

Basic Functions:

- **Power On/Off:** Use the power button to turn your AV receiver on or off.
- **Volume Control:** Adjust the audio output level using the volume up and down buttons.
- **Input Selection:** Cycle through different audio/video inputs (e.g., CD, DVD, TV) using the input selector buttons.
- **Navigation:** Use the directional pad and enter button for menu navigation on your connected device.
- **Playback Controls:** Standard playback functions such as Play, Pause, Stop, Fast Forward, and Rewind are available for compatible media.

Refer to your Sony AV Receiver's original manual for specific button functionalities and advanced operations.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

Problem	Solution
Remote is not working.	Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new ones. Point the remote directly at the AV receiver's infrared sensor. Remove any obstructions between the remote and the receiver.
Some buttons are not responding.	Verify that the button functionality is supported by your specific Sony AV receiver model. Clean the remote control, especially around the unresponsive buttons, to remove any debris. Ensure the remote is within the effective operating range (up to 10 meters).
Remote range is poor.	Replace batteries with fresh ones. Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the infrared signal.

Specifications

Brand	JustFine
Model Number	8541714211
Connectivity Technology	Infrared
Compatible Devices	Home Theater Systems (Sony STR-DH510, RMAAU071, 148761111, STR-DH710, HTSS370HP)
Maximum Number of Supported Devices	1
Battery Type	Alkaline AA (2 required, not included)
Maximum Range	10 Meters
Item Weight	0.17 Pounds
Color	Black
Special Feature	Ergonomic

Warranty and Support

This product is sold with a money-back guarantee and a 30-day quality warranty. For any issues or inquiries, please contact the seller directly.
For further assistance, refer to the original manual of your Sony AV Receiver for detailed information on its functions and settings.

© 2026 JustFine. All rights reserved.