

[Manuals.plus](#) /

> [Morphy Richards](#) /

> Morphy Richards OFR 9 Fin 2000W Oil Filled Room Heater User Manual

Morphy Richards MR OFR 9/900+

Morphy Richards OFR 9 Fin 2000W Oil Filled Room Heater User Manual

Model: MR OFR 9/900+

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always plug the heater directly into a wall outlet. Never use with an extension cord or relocatable power tap.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors. This heater is intended for indoor use only.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always unplug heater when not in use.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Ensure the heater is placed on a stable, level surface to prevent tipping.
- Do not cover the heater. Overheating may occur if the heater is covered.

2. PRODUCT OVERVIEW

The Morphy Richards OFR 9 Fin Oil Filled Room Heater is designed to provide efficient and comfortable heating for indoor spaces. Its oil-filled radiator design ensures rapid heat transfer and consistent warmth.

Key Features:

- **9 Fin Oil-Filled Radiator:** Ensures warmth reaches all corners of the room efficiently.
- **2000 Watts Power:** Provides rapid heating for quick comfort.
- **Adjustable Thermostat:** Allows precise control to maintain desired room temperature.
- **Power Selection Knob:** Offers multiple power settings for energy management.
- **Castor Wheels:** Equipped with mounting plates for easy mobility.
- **Back Cover & Humidifier:** Enhances functionality and user experience.
- **Cord Winder:** For convenient storage of the power cord.

Package Contents:

- 1 x Morphy Richards OFR Room Heater
- 1 x Set of Castor Wheels
- 1 x Set of U-Clamps for wheel assembly
- 1 x Warranty Card
- 1 x Instruction Manual



Figure 2.1: Side view of the Morphy Richards OFR 9 Fin Room Heater, showcasing its fins and control panel.



Figure 2.2: Front view of the Morphy Richards OFR 9 Fin Room Heater, highlighting the control panel and brand logo.



Figure 2.3: Diagram illustrating key features: Adjustable Thermostat, Power Selection Knob, 9 Fins, and Caster Wheels for easy mobility.

3. SETUP AND ASSEMBLY

Follow these steps to set up your Morphy Richards OFR Room Heater:

1. **Unpacking:** Carefully remove the heater and all components from the packaging. Retain packaging for future storage or transport.
2. **Attaching Castor Wheels:**
 - Turn the heater upside down on a soft, non-abrasive surface to avoid scratching.
 - Attach the castor wheels to the base of the heater using the provided U-clamps and mounting plates. Ensure they are securely fastened.
 - Carefully turn the heater upright.
3. **Placement:**

- Place the heater on a firm, level surface.
- Ensure there is adequate clearance (at least 3 feet) from walls, furniture, curtains, and other combustible materials.
- This heater is designed for indoor use in rooms such as bedrooms, home offices, or study rooms.

4. Power Connection:

- Ensure the power cord is fully unwound from the cord winder.
- This appliance requires a **16A 3-pin plug** and must be connected to a compatible 16A wall socket. Do not use standard 5A sockets or adapters.
- Plug the heater directly into the wall socket.

**Morphy
Richards**

16A 3-pin plug

Requires a 16A 3-pin socket



Figure 3.1: Illustration of the required 16A 3-pin plug and compatible wall socket for safe operation.

**Morphy
Richards**



Cord winder for convenient storage

Figure 3.2: The integrated cord winder provides convenient storage for the power cable when not in use.

4. OPERATING INSTRUCTIONS

Your Morphy Richards OFR Room Heater is equipped with user-friendly controls for optimal comfort.

Control Panel:

**Morphy
Richards**

Rapid Heating with 2000W Power



Figure 4.1: The control panel features a power indicator light, power selection knob (I, II, III), and an adjustable thermostat knob (MIN to MAX).

Steps for Operation:

1. **Power On:** Ensure the heater is plugged into a suitable 16A socket. The power indicator light will illuminate when the unit is receiving power.
2. **Select Power Setting:** Use the Power Selection Knob to choose your desired heat output:
 - **Setting I:** Low heat output.
 - **Setting II:** Medium heat output.
 - **Setting III:** High heat output (2000 Watts).
3. **Adjust Thermostat:** Turn the Adjustable Thermostat Knob to your desired temperature setting.
 - Turn towards **MAX** for higher temperatures.
 - Turn towards **MIN** for lower temperatures.
 - The heater will cycle on and off to maintain the set temperature.

4. **Power Off:** To turn off the heater, turn the Power Selection Knob to '0' and then unplug the unit from the wall socket.

5. MAINTENANCE AND STORAGE

Regular maintenance ensures the longevity and efficient operation of your heater.

1. Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the internal components.
- Periodically vacuum the air intake and exhaust grilles to remove dust and lint.

2. Storage:

- When not in use, especially during off-season, store the heater in a cool, dry place.
- Wrap the power cord neatly around the integrated cord winder.
- It is recommended to store the heater in its original packaging to protect it from dust and damage.

6. TROUBLESHOOTING

If you encounter any issues with your heater, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|--|--|
| Heater does not turn on. | <ul style="list-style-type: none">• Not plugged in securely.• Wall socket is not active.• Power selection knob is at '0'.• Thermostat set too low.• Overheat protection activated. | <ul style="list-style-type: none">• Ensure plug is fully inserted.• Test the socket with another appliance.• Turn the power selection knob to I, II, or III.• Increase the thermostat setting.• Unplug, let cool for 30 minutes, then restart. |
| Heater is on but not producing enough heat. | <ul style="list-style-type: none">• Power setting is too low.• Thermostat set too low.• Room size exceeds heater capacity.• Air vents are blocked. | <ul style="list-style-type: none">• Increase power setting (e.g., to III).• Increase the thermostat setting towards MAX.• Ensure the heater is appropriate for the room size.• Check and clear any obstructions from air vents. |

| Problem | Possible Cause | Solution |
|-------------------------|---|---|
| Unusual noise or smell. | <ul style="list-style-type: none"> Dust accumulation. Internal component issue. | <ul style="list-style-type: none"> Unplug immediately. Clean the heater as per maintenance instructions. If problem persists, discontinue use and contact customer support. |

If the problem persists after attempting these solutions, please contact Morphy Richards customer support.

7. SPECIFICATIONS

| | |
|---------------------------------------|--|
| Brand | Morphy Richards |
| Model Number | MR OFR 9/900+ |
| Type | Oil Filled Room Heater |
| Number of Fins | 9 |
| Power Consumption | 2000 Watts |
| Special Feature | Electric, Adjustable Thermostat, Power Selection Knob, Castor Wheels |
| Colour | Grey |
| Form Factor | Pedestal |
| Indoor/Outdoor Usage | Indoor |
| Product Dimensions (H x W x D) | 73cm x 54cm x 17.5cm |
| Recommended Uses | Home (Bedroom, Home Office, Study Room) |
| Mounting Type | Floor Mount |
| Burner Type | Radiant |
| Item Weight | 13 kg 500 g |
| Manufacturer | Imported & Marketed by Bajaj Electricals Limited, Morphy Richards |



Figure 7.1: Product dimensions: 73cm Height, 54cm Width, 17.5cm Depth.

8. WARRANTY AND SUPPORT

Your Morphy Richards OFR Room Heater comes with a comprehensive warranty and dedicated customer support.

Warranty Information:

This product is covered by a **1-year warranty** from the date of purchase. Please retain your purchase receipt and warranty card for any claims.

The warranty covers manufacturing defects and malfunctions under normal use conditions. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support:

For service, repairs, or any product-related queries, please contact Morphy Richards customer service. Refer to the contact details provided on your warranty card or visit the official Morphy Richards website for the latest support information.

Manufacturer: Imported & Marketed by Bajaj Electricals Limited, Morphy Richards.

9. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were available in the provided product data to embed in this manual.