



[Manuals.plus](#) /

› [Barrington Billiards](#) /

› Barrington 40" Dartboard Cabinet with LED Light - Instruction Manual

Barrington Billiards LYSB01M621025-SPRTSEQIP

Barrington 40" Dartboard Cabinet with LED Light - Instruction Manual

Model: LYSB01M621025-SPRTSEQIP

[Introduction](#) [Product Overview](#) [Features](#) [What's Included](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Barrington 40" Dartboard Cabinet with LED Light. Please read this manual thoroughly before use to ensure proper setup and to maximize the lifespan of your product.

2. PRODUCT OVERVIEW

The Barrington 40" Dartboard Cabinet with LED Light is designed to enhance your game room, bedroom, bar, or living room. It features a durable dartboard with a self-healing surface and a staple-free bulls-eye, complemented by a removable steel number ring for extended durability. Integrated LED lights illuminate the target area, providing a professional playing environment. The cabinet includes dual easy-wipe cricket scoreboards for convenient scorekeeping. This unit is powered by four AA batteries (not included).



Figure 2.1: Front view of the Barrington 40" Dartboard Cabinet with LED Light. The image displays the dark wood cabinet housing an 18-inch dartboard in the center, flanked by two black cricket scoreboards. Three steel-tip darts are shown on the left scoreboard, and three more on the right. Three small LED lights are visible above the dartboard, illuminating the playing surface. A white marker is placed on the ledge below the dartboard.

3. KEY FEATURES

- Premium 18" self-healing board with a staple-free bulls-eye target.
- Removable steel number ring increases the durability of the dartboard.
- Built-in LED lights to illuminate the target.
- Dual easy-wipe cricket scoreboards on each side of the cabinet.

4. WHAT'S INCLUDED

Your Barrington 40" Dartboard Cabinet package includes the following items:

- Barrington 40" Dartboard Cabinet
- 18" Self-healing Dartboard

- 6 Steel Tip Darts with Flights
- 1 Marker with Eraser
- LED Light (integrated)
- Mounting Hardware (for wall installation)

Note: Four (4) AA batteries are required for the LED lights and are not included.

5. SETUP INSTRUCTIONS

5.1 Unpacking and Inspection

1. Carefully remove all components from the packaging.
2. Inspect all parts for any damage or missing items. Refer to the "What's Included" section for a complete list. Contact customer support if any parts are damaged or missing.
3. Keep packaging materials until assembly is complete in case of return or exchange.

5.2 Battery Installation (for LED Lights)

1. Locate the battery compartment, typically on the top or back of the cabinet.
2. Open the battery compartment cover.
3. Insert four (4) AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

5.3 Wall Mounting

Proper wall mounting is crucial for stability and safety. It is recommended to have assistance during this process.

1. **Choose Location:** Select a sturdy wall location, preferably with wall studs for secure mounting. Ensure adequate space for dart throwing and player movement.
2. **Determine Height:** The center of the dartboard (bulls-eye) should be 5 feet 8 inches (1.73 meters) from the floor. Use this measurement to mark the mounting points for the cabinet.
3. **Drill Pilot Holes:** Using appropriate drill bits for your wall type (wood studs, drywall anchors), drill pilot holes at the marked locations.
4. **Secure Cabinet:** Attach the cabinet to the wall using the provided mounting hardware. Ensure it is level and securely fastened before use.

6. OPERATING INSTRUCTIONS

6.1 Using the Dartboard

- Ensure the dartboard is securely seated within the cabinet.
- Use the included steel tip darts. Aim for the desired segments on the board.
- The self-healing surface is designed to minimize visible holes over time.

6.2 Activating LED Lights

- Locate the power switch for the LED lights, typically on the top of the cabinet.
- Flip the switch to the "ON" position to illuminate the dartboard.
- Flip the switch to the "OFF" position when not in use to conserve battery life.

6.3 Using the Scoreboards

- The cabinet features two easy-wipe cricket scoreboards.
- Use the provided marker to keep track of scores during gameplay.
- After each game or session, use the eraser on the marker or a soft, damp cloth to wipe the scoreboards clean.

7. MAINTENANCE

- **Dartboard Care:** The dartboard has a self-healing surface. To prolong its life, rotate the board periodically to distribute wear evenly across different segments.
- **Scoreboard Cleaning:** Regularly wipe the scoreboards with the provided eraser or a soft, damp cloth. Avoid abrasive cleaners that may damage the surface.
- **Cabinet Cleaning:** Wipe the cabinet surfaces with a soft, dry cloth. Avoid harsh chemicals or excessive moisture.
- **Battery Replacement:** Replace the AA batteries for the LED lights when they dim or cease to function. Ensure proper disposal of old batteries.
- **Dart Maintenance:** Inspect darts regularly for bent tips or damaged flights. Replace as needed for optimal performance.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED Lights not working or dim	<ul style="list-style-type: none"> ◦ Batteries are dead or low. ◦ Batteries inserted incorrectly. ◦ Power switch is off. 	<ul style="list-style-type: none"> ◦ Replace with new AA batteries. ◦ Check battery polarity and reinsert correctly. ◦ Ensure the power switch is in the "ON" position.
Marker not writing clearly on scoreboard	<ul style="list-style-type: none"> ◦ Marker is dry. ◦ Scoreboard surface is dirty. 	<ul style="list-style-type: none"> ◦ Replace marker or ensure cap is always on when not in use. ◦ Clean scoreboard thoroughly with a damp cloth and dry completely before use.
Dartboard showing excessive wear/holes	<ul style="list-style-type: none"> ◦ Lack of rotation. ◦ Darts are dull or damaged. 	<ul style="list-style-type: none"> ◦ Rotate the dartboard regularly to distribute impact. ◦ Sharpen or replace dart tips as needed.
Cabinet feels unstable after mounting	<ul style="list-style-type: none"> ◦ Improper installation. ◦ Loose mounting hardware. 	<ul style="list-style-type: none"> ◦ Re-check mounting instructions and ensure cabinet is secured to wall studs or appropriate anchors. ◦ Tighten all mounting hardware.

9. SPECIFICATIONS

Attribute	Detail
Brand	Barrington Billiards
Model Number	LYSB01M621025-SPRTSEQIP

Attribute	Detail
UPC	756894757475
Material	Steel (Dartboard components), Wood/Laminate (Cabinet)
Color	Brown/Black
Product Dimensions (W x H)	40"W x 24.62"H
Dartboard Diameter	18 inches
Included Components	LED light, 6 darts, 1 marker with eraser
Power Source (LED)	4 AA Batteries (not included)
Item Package Weight	15 Kilograms
Date First Available	October 10, 2016

10. WARRANTY & SUPPORT

For specific warranty information and customer support, please refer to the documentation included with your product or contact Barrington Billiards directly through their official website or customer service channels. Keep your proof of purchase for warranty claims.

Manufacturer: Barrington

Brand: Barrington Billiards