

[Manuals.plus](#) /

› [Spirit Of Gamer](#) /

› Spirit Of Gamer XGP Wired Controller User Manual

Spirit Of Gamer XGP Wired Controller

Spirit Of Gamer XGP Wired Controller User Manual

Model: XGP Wired Controller

1. INTRODUCTION

The Spirit Of Gamer XGP Wired Controller is a versatile gamepad designed for an enhanced gaming experience across multiple platforms. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your controller. It is compatible with PC, Android devices (TV Box or Smartphone), and PlayStation 3 (PS3).

The controller features an ergonomic design, precise controls, and advanced functions like Rapid Fire and vibration feedback to immerse you in your games.

2. PRODUCT OVERVIEW

The XGP controller is equipped with a comprehensive set of controls for optimal performance. It includes 12 digital buttons, two 360° analog sticks, dual triggers, sensitive bumpers, and an octo-directional D-pad for precise movements.



Figure 1: Front view of the XGP Wired Controller, showcasing its button layout, dual analog sticks, D-pad, and central illuminated logo.

Controller Features:

- **12 Digital Buttons:** Standard action buttons for various in-game commands.
- **Two 360° Analog Sticks:** For precise movement and camera control.
- **Dual Triggers and Bumpers:** Located on the top for additional actions.
- **Octo-directional D-Pad:** For accurate directional input.
- **Rapid Fire (Turbo) Function:** Allows for quick, repeated button presses.
- **Vibration Function:** Provides tactile feedback during gameplay.
- **Ergonomic Design:** Textured grip for comfortable extended play sessions.



Figure 2: Side profile of the XGP Wired Controller, illustrating its ergonomic curves and the integrated USB cable.

3. SETUP

Connecting the Controller:

1. Locate an available USB port on your PC, Android device (via OTG adapter, not included for smartphones), or PS3 console.
2. Plug the USB connector of the XGP Wired Controller into the USB port.
3. The controller is designed for Plug and Play functionality. Your system should automatically detect and install the necessary drivers.
4. Once connected, the controller's LED indicators will illuminate, signifying it is ready for use.

The controller features a 1.8-meter (approximately 6 feet) cable for flexible positioning.



Figure 3: The XGP Wired Controller with its USB cable, demonstrating the connection point.

Compatibility Notes:

- **PC:** Compatible with most Windows Direct-Input and X-Input games.
- **Android:** Requires Android version 4.0 or higher and an OTG (On-The-Go) function for smartphones/tablets. An OTG adapter is not included.
- **PS3:** Connect directly to a USB port on your PlayStation 3 console.

4. OPERATING INSTRUCTIONS

Rapid Fire Function (Turbo Mode):

The Rapid Fire function, also known as Turbo mode, allows a designated button to be pressed repeatedly at a high speed with a single hold. This can be advantageous in games requiring rapid input.

- **To Activate:** Press and hold the **TURBO** button, then press the action button you wish to assign Rapid Fire to (e.g., A, B, X, Y). The assigned button will now have Rapid Fire enabled.

- **To Deactivate:** Press and hold the **TURBO** button again, then press the action button that has Rapid Fire enabled. This will disable Rapid Fire for that specific button.

Vibration Function:

The controller features a vibration function that provides tactile feedback during gameplay, enhancing immersion. This function is automatically enabled when supported by the game and platform. No manual activation is typically required.

Dual Mode:

The controller supports dual input modes (Direct-Input and X-Input) for PC compatibility. It automatically switches between these modes based on the game's requirements, ensuring broad compatibility with various PC titles.

5. MAINTENANCE

Proper care and maintenance will extend the life of your XGP Wired Controller.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly to prevent damage.
- **Handling:** Do not drop the controller or subject it to strong impacts. Avoid pulling the cable forcefully when disconnecting.

6. TROUBLESHOOTING

If you encounter issues with your XGP Wired Controller, refer to the following common solutions:

- **Controller Not Recognized:**
 - Ensure the USB cable is securely plugged into both the controller and the device.
 - Try a different USB port on your device.
 - Restart your PC or console.
 - For Android devices, confirm OTG functionality is enabled and the adapter (if used) is working correctly.
- **Buttons Not Responding / Incorrect Input:**
 - Verify that the game you are playing supports gamepads.
 - Check in-game settings to ensure the controller is selected as the input device.
 - Test the controller on another game or platform to isolate the issue.
- **Vibration Not Working:**
 - Ensure the game you are playing supports vibration feedback.
 - Check in-game settings for vibration options and ensure they are enabled.

7. SPECIFICATIONS

Feature	Detail
Brand	Spirit Of Gamer

Feature	Detail
Model	XGP Wired Controller
Compatible Devices	PC (Windows), Android (4.0+ with OTG), PlayStation 3
Controller Type	Joystick / Gamepad
Button Quantity	16 (including digital buttons, triggers, bumpers, D-pad)
Analog Sticks	Two 360° Analog Sticks
Additional Features	Rapid Fire (Turbo), Vibration Function, Ergonomic Design
Power Source	Corded Electric (USB)
Cable Length	1.8 meters (approx. 6 feet)
Item Weight	230 grams (approx. 0.5 lbs)
Manufacturer	Spirit of Gamer
ASIN	B01M7Q8MB4
GTIN	03700104431959

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product at the time of purchase or visit the official Spirit Of Gamer website. Keep your proof of purchase for warranty claims.

If you experience issues not covered in this manual, please contact Spirit Of Gamer customer service for further assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01M7Q8MB4>

More documents and user manuals: <https://manuals.plus/>