

One For All URC 7125

One For All Evolve 2 Universal Remote Control

MODEL: URC 7125

Instruction Manual



1. INTRODUCTION

The One For All Evolve 2 Universal Remote Control (Model URC 7125) is designed to provide seamless control over your Television and Set Top Box devices. This remote offers a reliable and easy-to-use solution, functioning like an original remote control while providing universal compatibility with various brands. It includes dedicated features for Smart TV control and a learning function for personalized customization.

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Evolve 2 remote control.

2. SETUP

2.1. Battery Installation

Before first use, install two AAA batteries into the remote control. Ensure correct polarity (+/-) as indicated inside the battery compartment.

1. Open the battery compartment cover on the back of the remote control.
2. Insert 2 x AAA batteries, aligning them with the positive (+) and negative (-) terminals.
3. Close the battery compartment cover securely.

2.2. Device Setup (3 Easy Steps)

The Evolve 2 remote control is designed for quick and easy setup, typically completed in less than one minute. A quick installation guide is also included with the product packaging.



Image: The retail packaging for the One For All Evolve 2 Universal Remote Control, indicating its compatibility and ease of setup.

1. **Power On Device:** Ensure the device you wish to control (TV or Set Top Box) is powered on.
2. **Enter Setup Mode:** Press and hold the **MAGIC** button on the remote until the LED light flashes twice and then stays lit.
3. **Enter Code:** Enter the 4-digit setup code for your device brand. Refer to the code list provided in the quick installation guide. The LED will flash twice to confirm successful setup. If the LED shows a long flash, the code was incorrect; please try again.

If your device does not respond after entering the code, try the next code listed for your brand. The remote is guaranteed to work with all manufacturer brands.

3. OPERATING THE REMOTE CONTROL

The Evolve 2 remote control provides comprehensive functionality for your TV and Set Top Box. Familiarize yourself with the button layout for optimal use.



Image: A direct front view of the One For All Evolve 2 Universal Remote Control, showcasing its full button layout including number pad, navigation, and media controls.

3.1. Basic Control

- **Power (Red Button):** Turns your device on or off.
- **MODE (TV/STB):** Switches between controlling your Television and your Set Top Box. The corresponding LED

will light up to indicate the active mode.

- **Number Pad (0-9):** Used for direct channel entry.
- **Volume (+/-):** Adjusts the volume level.
- **Channel (Up/Down):** Changes the channel.
- **Mute:** Mutes or unmutes the audio.

3.2. Smart TV and Navigation

- **SMART:** Accesses your Smart TV's home screen or smart features.
- **GUIDE:** Displays the electronic program guide (EPG).
- **INFO:** Shows information about the current program or input.
- **Navigation Ring (Up/Down/Left/Right) & OK:** Used to navigate menus and confirm selections.
- **BACK:** Returns to the previous menu or screen.
- **MENU:** Opens the device's main menu.
- **EXIT:** Exits the current menu or application.

3.3. Learning Function

The Evolve 2 remote features a learning function, allowing you to copy functions directly from your original remote control. This is useful for personalizing the remote or adding functions not covered by the pre-programmed codes.

1. Place the Evolve 2 remote and your original remote on a flat surface, facing each other, about 1-2 inches apart.
2. On the Evolve 2 remote, press and hold the **MAGIC** button until the LED flashes twice and then stays lit.
3. Press the button on the Evolve 2 remote that you wish to program (e.g., a specific function button). The LED will flash rapidly.
4. On your original remote, press the button whose function you want to copy. The Evolve 2 remote's LED will flash twice to confirm successful learning.
5. Repeat steps 3 and 4 for any other buttons you wish to program.
6. To exit learning mode, press the **MAGIC** button. The LED will turn off.



Image: An angled view of the One For All Evolve 2 Universal Remote Control, highlighting its ergonomic design and button layout.

4. MAINTENANCE

4.1. Battery Replacement

When the remote control's performance degrades or the LED indicator becomes dim, it is time to replace the batteries. Always replace both AAA batteries simultaneously with new ones.

4.2. Cleaning

To clean the remote control, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the remote's surface or internal components.

5. TROUBLESHOOTING

If you encounter issues with your One For All Evolve 2 remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote does not respond.	Batteries are dead or incorrectly inserted.	Replace batteries with new ones, ensuring correct polarity.
Remote does not control my device.	Incorrect setup code entered.	Repeat the setup process (Section 2.2) and try a different code for your brand from the provided code list.
Some buttons do not work correctly.	Code may not be fully compatible, or a button was incorrectly learned.	Try another setup code for your brand. Use the learning function (Section 3.3) to copy specific functions from your original remote.
LED flashes continuously.	Remote is in a programming mode.	Press the MAGIC button to exit programming mode.

6. SPECIFICATIONS

- **Model Number:** URC 7125
- **Product Dimensions:** 9.13 x 1.79 x 0.83 inches
- **Item Weight:** 3.17 ounces
- **Batteries Required:** 2 x AAA (not included)
- **Max Number of Supported Devices:** 2 (TV, Set Top Box)
- **Compatible Devices:** Television, Satellite/Cable/DVB-T & DVB-T2 Set Top Boxes
- **Special Feature:** Universal, Learning Function
- **Color:** Black
- **Manufacturer:** One For All

7. WARRANTY AND SUPPORT

One For All products are designed and manufactured to the highest standards. For information regarding warranty coverage and technical support, please refer to the warranty card included with your product or visit the official One For All website. You can find additional resources, FAQs, and contact information for customer service there.

Official Website: www.oneforall.com



