

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Moen](#) /

› [Moen WS84922 Conway Two-Handle Centerset Bathroom Faucet User Manual](#)

Moen WS84922

Moen WS84922 Conway Two-Handle Centerset Bathroom Faucet User Manual

Model: WS84922

INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Moen WS84922 Conway Two-Handle Centerset Bathroom Faucet. This faucet features a chrome finish and a two-handle design, suitable for a 4-inch centerset, three-hole sink configuration. Please read these instructions thoroughly before beginning installation or use to ensure proper function and longevity of your product.

SAFETY INFORMATION

Always turn off the water supply to the faucet before beginning any installation or repair work. Wear appropriate personal protective equipment, such as safety glasses, during installation. If you are unsure about any part of the installation process, consult a qualified plumber.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Moen WS84922 Conway Two-Handle Centerset Bathroom Faucet
- Valve Assembly
- Drain Assembly
- Mounting Hardware
- Installation Instructions (this document)

TOOLS REQUIRED

The following tools are typically required for installation:

- Adjustable Wrench
- Phillips Screwdriver
- Plumber's Putty or Silicone Sealant
- Flashlight (optional)
- Basin Wrench (optional)

SETUP AND INSTALLATION

The Moen WS84922 faucet is designed for easy installation on a 4-inch centerset, three-hole sink. Follow these general steps for installation:

1. **Prepare the Sink:** Ensure the sink surface is clean and free of debris around the faucet holes.
2. **Install the Faucet Body:** Place the faucet body onto the sink, aligning the hot and cold water supply lines with the corresponding holes. Secure the faucet from underneath the sink using the provided mounting hardware.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines to your home's water supply valves. Ensure all connections are tight to prevent leaks.
4. **Install the Drain Assembly:** Follow the specific instructions provided with the drain assembly to install it into the sink drain hole. Apply plumber's putty or silicone sealant as directed to ensure a watertight seal.
5. **Test for Leaks:** Once all connections are made, slowly turn on the main water supply and check for any leaks. Tighten connections as necessary.



Front view of the Moen WS84922 Conway Two-Handle Centerset Bathroom Faucet in Chrome finish.



The Moen WS84922 Conway faucet installed on a bathroom sink, showcasing its appearance in a typical setting.

Spout Reach
4.63"



Height
4.38"

Maximum Deck Thickness - 1"

Drain Included
Supply Lines Not Included


Connection Size - 1/2"

3 Hole Installation

Diagram illustrating the key dimensions of the Moen WS84922 faucet, including spout reach (4.63 inches), height (4.38 inches), maximum deck thickness (1 inch), and connection size (1/2 inch).

Will this faucet fit my sink?

This faucet fits a three hole configuration.



MOEN®

Diagram showing a standard three-hole sink configuration, indicating compatibility for the Moen WS84922 faucet.

OPERATING INSTRUCTIONS

The Moen WS84922 faucet features two handles for controlling water flow and temperature:

- The left handle controls the hot water supply.
- The right handle controls the cold water supply.

Turn the handles counter-clockwise to increase water flow and clockwise to decrease or shut off. This faucet is WaterSense certified, meaning it meets EPA criteria to conserve water with a maximum flow rate of 1.75 gallons per minute without compromising performance.

MAINTENANCE

To maintain the chrome finish and ensure optimal performance of your Moen faucet, follow these guidelines:

- **Cleaning:** Clean the faucet regularly with a soft, damp cloth. For stubborn spots, use a mild soap and water solution. Rinse thoroughly and dry with a soft cloth to prevent water spots.
- **Avoid Abrasives:** Do not use abrasive cleaners, harsh chemicals, or scouring pads, as these can

damage the chrome finish.

- **Aerator Maintenance:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and reattach.

TROUBLESHOOTING

If you encounter issues with your faucet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed supply valve.	Clean aerator; ensure supply valves are fully open.
Leaking from Spout	Worn cartridge; debris in cartridge.	Replace cartridge; clean cartridge.
Leaking at Base	Loose mounting nuts; improper sealant.	Tighten mounting nuts; reapply sealant if necessary.

For issues not listed or if problems persist, please contact Moen customer support.

SPECIFICATIONS

- **Brand:** Moen
- **Model Name:** Conway
- **Part Number:** WS84922
- **Finish Type:** Chrome
- **Material:** Metal
- **Mounting Type:** Deck Mount
- **Number of Handles:** 2
- **Hole Count:** 3
- **Installation Type:** Deck Mounted, 4-inch Centerset
- **Maximum Flow Rate:** 1.75 Gallons Per Minute (GPM)
- **Spout Height:** 4.31 Inches
- **Spout Reach:** 4.64 Inches
- **Item Weight:** 3.94 Pounds
- **Product Dimensions:** 4.63 x 9.11 x 4.38 inches
- **Special Feature:** ADA Compliant, WaterSense Certified
- **UPC:** 026508262535

WARRANTY




The Moen WS84922 Conway Two-Handle Centerset Bathroom Faucet is backed by Moen's Limited Lifetime Warranty. This warranty covers defects in material and manufacturing workmanship for the original consumer purchaser. For full details regarding warranty coverage and claims, please refer to the official Moen warranty documentation or visit the Moen website.


SUPPORT

For further assistance, technical support, or to order replacement parts, please contact Moen customer service or visit their official website:

- **Moen Official Website:** www.moen.com
- **Customer Service:** Refer to the Moen website for current contact information.

Related Documents - WS84922

	<p>Moen Adler Two Handle Lavatory Faucet Illustrated Parts List Detailed illustrated parts list for the Moen Adler Two Handle Lavatory Faucet, providing part numbers, descriptions, and finish options for components like handles, cartridges, and mounting hardware. Includes model numbers 84603 and 84603SRN.</p>
	<p>Moen Traditional Two-Handle 4-Inch Centerset Lavatory Faucet WS84003 Specifications Detailed specifications for the Moen Traditional Two-Handle 4-Inch Centerset Lavatory Faucet (WS84003 series), including features, operation, flow rate, cartridge type, standards, warranty information, and critical installation dimensions.</p>
	<p>Moen Two-Handle Bathroom Sink Faucet Installation and Warranty Guide Comprehensive guide for installing and maintaining Moen two-handle bathroom sink faucets designed for 4-inch center installations. Includes parts identification, step-by-step instructions, consumer information on lead, and lifetime limited warranty details.</p>
	<p>Moen IVER™ Two-Handle 4" Centerset Lavatory Faucet 6815 Series Illustrated Parts Illustrated parts list for the Moen IVER™ Two-Handle 4" Centerset Lavatory Faucet, 6815 Series. Find part numbers and finishes for your Moen faucet.</p>
	<p>Moen IVER™ 6805 Series One-Handle Lavatory Faucet Illustrated Parts Detailed illustrated parts list for the Moen IVER™ 6805 Series One-Handle Lavatory Faucet, including kit numbers, finishes, and part descriptions. Features components A through M with corresponding part numbers and finish options.</p>



[Moen Traditional Centerset Lavatory Faucet Illustrated Parts List](#)

Comprehensive illustrated parts list for the Moen Traditional Centerset Lavatory Faucet, detailing models WS84003, WS84003BRB, and WS84003SRN with part numbers for handles, spout, waste assemblies, and mounting kits.