

[Manuals.plus](#) /

› [Baby Delight](#) /

› Baby Delight Go with Me Venture Portable Chair Instruction Manual BD5030

Baby Delight BD5030

Baby Delight Go with Me Venture Portable Chair Instruction Manual

Model: BD5030

INTRODUCTION

The Baby Delight Go with Me Venture Portable Chair is designed for convenience and versatility, supporting children through multiple growth stages. This manual provides essential information for the safe and proper use, assembly, maintenance, and troubleshooting of your portable chair.

It features a removable 5-point harness for infants, converts for standing support, and can be used as a regular chair for toddlers and older children. The chair includes a removable snack tray and a sun canopy, making it suitable for both indoor and outdoor use.

SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always secure your child with the 5-point harness when using the chair in infant or toddler mode.
- Never leave child unattended.
- Ensure the chair is fully open and locked into position before placing a child in it.
- Do not use the chair on elevated surfaces.
- Maximum weight recommendation: 75 pounds.
- Periodically check all parts for wear, damage, or missing components. Discontinue use if any part is damaged.
- Keep away from open flames and other heat sources.

SETUP AND ASSEMBLY

Unfolding the Chair

1. Remove the chair from its carry bag.

2. Hold the top of the chair and pull the legs outwards until they fully extend and lock into place. Ensure all eight flared legs are stable.
3. Press down on the seat fabric to ensure it is taut and securely seated on the frame.



Image: The Baby Delight Go with Me Venture Portable Chair, shown fully assembled in grey, featuring a sun canopy and snack tray.

Attaching the Snack Tray and Sun Canopy

- **Snack Tray:** Align the tray with the chair's armrests and push down until it clicks securely into place. The tray is removable for cleaning or when not needed.
- **Sun Canopy:** Insert the canopy's support rods into the designated slots on the chair's frame. Adjust the canopy's position as needed to provide shade. The canopy is also removable.

INTRODUCING VENTURE DELUXE PORTABLE CHAIR

REMOVABLE SUN
CANOPY FOR OUTDOOR
ADVENTURES

REMOVABLE TRAY

CUP HOLDER

REMOVABLE
5-POINT HARNESS

LOCKING SYSTEM
FOR STABILITY

8 STRONG, STABLE
FLARED LEGS SYSTEM



TRAVEL &
STORAGE
BAG
INCLUDED



Image: A diagram illustrating the key features of the Venture Portable Chair, such as the removable sun canopy, snack tray with cup holder, 5-point harness, and stable leg system.

OPERATING INSTRUCTIONS

Child Growth Stages

The Venture Portable Chair adapts to three child growth stages:

- **Infant & Toddler (3-6 months):** Use with the 5-point removable harness to keep your stable baby secure and comfortable in a seated position.
- **Standing Support:** As your baby grows, the seat fabric can be unvelcroed to reveal two leg holes, allowing the child to stand with support. This patented design (Patent No. 8,690,236) helps with developmental milestones.
- **Big Kid Mode (up to 75 lbs):** The chair can be used without the harness and snack tray for older children, functioning as a portable seat.

INTRODUCING

VENTURE

DELUXE PORTABLE CHAIR




**INFANT &
TODDLER
3-6 MOS.**



**BIG KID
UP TO
100LBS.**

Image: Visual representation of the chair's versatility, showing an infant/toddler using the chair with harness and a larger child using it as a regular seat.



PATENTED DESIGN

UNIQUE, PATENTED FEATURE THAT ALLOWS BABY TO PRACTICE STANDING (PATENT NO. 8,690,236)

Image: A child utilizing the patented standing feature of the chair, demonstrating how the leg holes allow for supported standing.

Folding the Chair for Storage

To fold the chair, locate the locking mechanisms on the frame, typically near the joints of the legs. Release these locks and gently push the legs inwards and upwards until the chair collapses into a compact form. Place it back into the provided carry bag for easy transport and storage.

MAINTENANCE

Cleaning Instructions

- **Fabric:** The chair's polyester fabric is designed to resist fading and staining. For cleaning, hand wash with mild soap and cold water. Do not bleach. Air dry thoroughly before folding or storing.
- **Frame:** Wipe the metal frame with a damp cloth and mild soap if necessary. Dry completely.
- **Snack Tray:** The snack tray can be wiped clean with a damp cloth or washed with warm, soapy water.

Storage

Store the chair in its carry bag in a cool, dry place away from direct sunlight when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not fully open or lock.	Legs are not fully extended or locking mechanisms are obstructed.	Ensure all legs are pulled outwards until they click into place. Check for any fabric or debris blocking the locking mechanisms.
Snack tray does not attach securely.	Tray not aligned correctly or obstruction.	Realign the tray with the armrests and apply firm, even pressure until it clicks. Check for any foreign objects.
Difficulty folding the chair.	Locking mechanisms are not fully released.	Ensure all locking mechanisms are disengaged before attempting to fold. Do not force the chair to fold.
Harness feels too tight or too loose.	Harness straps require adjustment.	Adjust the shoulder and waist straps to fit your child snugly but comfortably. Refer to the harness adjustment instructions (if provided in a physical manual).

SPECIFICATIONS

Feature	Detail
Model Number	BD5030
Product Dimensions (Open)	22.75"D x 23"W x 24.5"H
Item Weight	4.9 pounds
Maximum Weight Recommendation	75 Pounds
Material Type	100% Polyester Fabric
Care Instructions	Hand Wash
Additional Features	Removable snack tray, sun canopy, carry bag, 5-point harness, patented standing support.
Color	Grey
Portability	Yes

WHERE SAFETY & AESTHETICS ALIGN

TESTED. TRUSTED.

STURDY, STYLISH & COZY

GROWS
WITH YOUR
CHILD

24.5"

22.75"

23"

Image: A visual representation of the chair's dimensions, indicating its height, width, and depth.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Baby Delight directly through their official website. Keep your purchase receipt for any warranty claims.

Contact Information:

- **Brand:** Baby Delight
- **Website:** www.babydelight.com

