

ODYSSEY BRXMK2BP10

Odyssey BRXMK2BP10 Remix MKII Standard Backpack User Manual

Model: BRXMK2BP10

INTRODUCTION

This manual provides comprehensive instructions for the Odyssey BRXMK2BP10 Remix MKII Standard Backpack. Designed for mobile DJs and electronic music enthusiasts, this backpack offers secure and organized transport for controllers, laptops, tablets, and various accessories. Please read this manual thoroughly to ensure proper use and care of your backpack.

FEATURES

The Odyssey BRXMK2BP10 Remix MKII Standard Backpack is engineered with several key features to enhance functionality and protection:

- **Fully Padded Interior:** Provides comprehensive protection for all stored gear against impacts and scratches.
- **Dedicated Laptop Compartment:** Securely holds laptops, keeping them separate from other equipment.
- **Dedicated Digital Tablet Compartment:** Offers a safe and accessible space for tablets.
- **Interior Headphone Pouch:** A specific pouch designed to protect headphones.
- **Multiple Interior Compartments and Padded Pockets:** Allows for organized storage of various accessories, cables, and smaller items.
- **Heavy-Duty Zippers and Zipper Pulls:** Ensures durability and reliable access to compartments.
- **Inconspicuous Exterior Stash Pocket:** A discreet 9" x 5" pocket for quick access items.
- **Padded Back Panel and Shoulder Straps:** Designed for enhanced comfort during extended wear.
- **Ergonomic Handle:** For comfortable hand carrying.

SETUP AND INITIAL USE

Before using your Remix MKII backpack, follow these steps to prepare it for your gear:

1. **Unpack the Backpack:** Remove all packaging materials. Inspect the backpack for any signs of damage.
2. **Adjust Shoulder Straps:** Place the backpack on your back and adjust the padded shoulder straps using the buckles until the backpack sits comfortably and securely. The padded back panel should rest flat against your back.

3. **Familiarize with Compartments:** Open all zippers and identify the various compartments:

- Main compartment for controllers or 10" format DJ mixers.
- Dedicated laptop sleeve.
- Dedicated tablet sleeve.
- Headphone pouch.
- Multiple smaller pockets for cables, hard drives, and other accessories.

4. **Load Your Gear:** Strategically place your equipment, ensuring heavier items are closer to your back for better weight distribution. Utilize the padded dividers and straps to secure items and prevent movement during transit.



Figure 1: Front view of the Odyssey BRXMK2BP10 Remix MKII Standard Backpack, showcasing its sleek design and robust zippers. This view highlights the exterior appearance before loading.





Figure 2: Rear view of the backpack, illustrating the padded back panel and adjustable shoulder straps designed for ergonomic comfort and support during transport.

OPERATION AND USAGE

The Remix MKII backpack is designed for versatile use, allowing you to transport your DJ and electronic gear efficiently.

- **Carrying Options:** Use the padded shoulder straps for backpack-style carrying or the top handle for quick grabs.
- **Securing Gear:** Always ensure all zippers are fully closed before carrying the backpack. Utilize internal straps and padding to prevent gear from shifting.
- **Accessing Compartments:** The main compartment opens wide for easy access to larger items like controllers or mixers. Dedicated sleeves for laptops and tablets are easily accessible.
- **Weight Distribution:** For optimal comfort and to prolong the life of the backpack, distribute weight evenly. Place heavier items closer to the back panel.



Figure 3: The main compartment of the backpack, shown with a Numark PT01 scratch turntable, portable speaker, headphones, and records, demonstrating its capacity for various DJ essentials.



Figure 4: Interior view showcasing a DJ mixer securely placed within the main compartment, held by an adjustable strap, highlighting the protective design for sensitive equipment.



Figure 5: A dedicated padded compartment designed to safely store a laptop, featuring a securing strap to prevent movement during transit.



Figure 6: The interior of the backpack showing mesh pockets for smaller accessories and space for vinyl records, demonstrating versatile

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your Odyssey Remix MKII backpack.

- **Cleaning:** For general cleaning, wipe the exterior with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Spot Cleaning:** For stubborn stains, use a soft brush with mild soap and water, then rinse thoroughly and air dry.
- **Drying:** Always allow the backpack to air dry completely before storing or reusing, especially if it has been exposed to moisture. Do not machine wash or tumble dry.
- **Zipper Care:** Keep zippers clean and free of debris. If zippers become stiff, a small amount of zipper lubricant can be applied.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

This section addresses common concerns you might encounter with your backpack.

- **Problem: Zippers are stiff or stuck.**
Solution: Ensure no fabric is caught in the zipper teeth. Clean any debris from the teeth. Apply a small amount of zipper lubricant or wax to the teeth and gently work the zipper back and forth.
- **Problem: Backpack feels uncomfortable or heavy.**
Solution: Re-evaluate the weight distribution of your gear. Place heavier items closer to your back. Adjust the shoulder straps to ensure the backpack sits high and snug on your back, distributing weight across your shoulders and upper back.
- **Problem: Gear is not fitting securely.**
Solution: Utilize all available padded dividers and internal straps to secure items. If an item is too large for a specific compartment, consider if it can be placed in the main compartment with additional padding. Avoid overstuffing the backpack.

SPECIFICATIONS

Feature	Detail
Model Number	BRXMK2BP10
Exterior Dimensions (Approx.)	13" W x 19" H x 7" D (33 cm W x 48.26 cm H x 17.78 cm D)
Main Interior Compartment (Approx.)	16" X 10.5" X 3" (40.64 cm X 26.67 cm X 7.62 cm)
Exterior Stash Pocket (Approx.)	9" X 5" (22.86 cm X 12.7 cm)
Item Weight (Approx.)	2 lbs (0.91 kg)
Material	Durable fabric with padded interior
Color	Black

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to inquire about replacement parts, please refer to the official Odyssey website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, visit the [ODYSSEY Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B01M98ZM27>

More documents and user manuals: <https://manuals.plus/>