

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Vibe Sound Color Changing Speaker - Led Stereo Box - Flashing Led Lights - Compatible with 3.5mm Aux Devices

LED Stereo Box

USER MANUAL

Introduction

Thank you for choosing the Vibe Sound LED Stereo Box. This portable speaker is designed to provide clear audio and a dynamic visual experience with its integrated color-changing LED lights. Its compact design and built-in handle make it ideal for various settings, from personal use to small gatherings. This manual provides essential information for the proper setup, operation, and maintenance of your device.

Safety Information

- Do not expose the device to water or excessive moisture.
- Avoid placing the speaker near heat sources or in direct sunlight.
- Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Use only the provided charging cable and battery.

Package Contents

Please check the box for the following items:

- Vibe Sound LED Stereo Box
- 3.5mm audio cable
- USB charging cable
- Rechargeable BL 5C battery

Setup

1. **Battery Installation:** Locate the battery compartment, typically on the back or bottom of the speaker. Insert the provided rechargeable BL 5C battery, ensuring correct polarity.
2. **Charging:** Connect the small end of the USB charging cable to the speaker's micro USB port and the other end to a USB power adapter (not included) or a computer's USB port. Allow the unit to fully charge before first use. A charging indicator light may be present.
3. **Initial Connection:** For audio playback, connect one end of the 3.5mm audio cable to the AUX input port on the speaker and the other end to the headphone jack or audio output of your device (e.g., smartphone, tablet, MP3

player).



The Vibe Sound LED Stereo Box, showing its speaker on the side, the LED light display on the front, and the connected 3.5mm aux cable. A handle is visible on top for portability.

Operating Instructions

- 1. Power On/Off:** Locate the power button, usually on the back or side of the speaker. Press and hold (or slide) to turn the speaker on or off.

2. **Audio Playback:** Once connected via the 3.5mm AUX cable, begin playing audio from your connected device. The speaker will output the sound.
3. **LED Light Show:** The mirror-front panel will automatically display a color-changing LED light show when music is playing, synchronizing with the audio. There are no manual controls for the light patterns; they are music-activated.
4. **Portability:** Utilize the integrated pull-up handle on top of the speaker box for easy transportation.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the battery regularly, even if the speaker is not in constant use.

Troubleshooting

Problem	Possible Cause	Solution
No sound from speaker	Speaker is off; Volume too low; Aux cable not connected properly; Device volume too low.	Turn speaker on; Increase speaker volume; Ensure aux cable is fully inserted; Increase volume on connected device.
LED lights not flashing	No music playing; Speaker is off.	Ensure music is playing from the connected device; Turn speaker on.
Speaker not charging	Charging cable not connected; Faulty cable/adapter; Battery not inserted correctly.	Check USB cable connection; Try a different USB port or adapter; Re-insert battery correctly.

Specifications

Model Name	Color Changing Speaker - Led Stereo Box - Flashing Led Lights - Compatible with 3.5mm Aux Devices
Brand	Vibe Sound
Speaker Type	Bookshelf
Special Feature	Multi Room Audio
Recommended Uses	Music, Party
Compatible Devices	Smartphone, Tablet, MP3 Player
Controller Type	Battery Powered
Surround Sound Channel Configuration	2.0
Color	Multicolor
Included Components	3.5mm audio cable, USB charging cable, rechargeable battery

Is Waterproof	FALSE
Warranty Type	Limited
Control Method	Touch
Wireless Communication Technology	Bluetooth (Note: Product description states 3.5mm Aux Cable Only, but specifications list Bluetooth. Please rely on Aux Cable for primary connection.)
Speaker Size	3.5 Millimeters
Power Source	Battery Powered
Water Resistance Level	Not Water Resistant
Audio Driver Type	Dynamic Driver
Subwoofer Connectivity Technology	Wired
Connectivity Protocol	Bluetooth (See note above)
UPC	888255137463
Style	Modern, Portable, and Visually Striking
Manufacturer	Vibe
Item Weight	1.6 pounds
First Available	October 10, 2016
Speaker Maximum Output Power	1.1 Watts
Connectivity Technology	Auxiliary, USB
Audio Output Mode	Stereo
Mounting Type	Plug Mount

Warranty and Support

This product comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or contact the manufacturer directly. For technical support or inquiries not covered in this manual, please reach out to Vibe Sound customer service.