

Dupray DU050

Dupray HOME Steam Cleaner Instruction Manual

Model: DU050

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Dupray HOME Steam Cleaner. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the steam cleaner is unplugged from the electrical outlet before filling with water, cleaning, or performing maintenance.
- Do not leave the appliance unattended when plugged in.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Use only tap water. Distilled water is not required but can be used. Do not add any chemicals, detergents, or aromatic products to the water tank.
- Keep children and pets away from the appliance during operation. Steam is extremely hot and can cause severe burns.
- Never direct steam at people, animals, or electrical appliances.
- Allow the unit to cool completely before opening the water tank cap for refilling.
- Store the appliance indoors in a cool, dry place.

2. PRODUCT OVERVIEW

The Dupray HOME Steam Cleaner is a European-made, chemical-free cleaning solution designed for deep cleaning various surfaces. It utilizes superheated low-moisture steam to effectively remove dirt, grease, and stains, while sanitizing surfaces by killing 99.9% of bacteria and viruses.

Key Features:

- **Chemical-Free Cleaning:** Uses only tap water, eliminating the need for harsh chemicals.
- **High-Performance Steam:** Generates steam up to 293°F / 145°C with adjustable pressure (46 psi / 3.2 bar).

- **Extended Cleaning Time:** Up to 40 minutes of continuous cleaning per refill.
- **Versatile Accessory Kit:** Includes a 14-piece kit for various cleaning tasks.
- **Compact and Lightweight Design:** Easy to maneuver and store.

THE PERFECT HOME CLEANER.

UP TO

293°F SUPERHEATED STEAM FOR
ULTRA-POWERFUL DEEP CLEANING



Image: The Dupray HOME Steam Cleaner main unit, showcasing its compact design.

17-PIECE PREMIUM ACCESSORY KIT



Image: The comprehensive 14-piece accessory kit included with the Dupray HOME Steam Cleaner.

3. SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all accessories listed in the manual are present.
2. **Filling the Water Tank:**
 - Unscrew the safety cap on top of the unit.
 - Using the provided funnel, slowly pour up to 1 liter of tap water into the boiler. Do not overfill.
 - Securely replace the safety cap, ensuring it is tightly closed.

Your browser does not support the video tag.

Video: Demonstrates the features of the Dupray HOME Steam Cleaner, including water filling and basic assembly.

3. Connecting Accessories:

- Attach the desired cleaning accessory (e.g., floor tool, lance, brush) to the steam hose handle. Ensure it clicks securely into place.

- For floor cleaning, connect the extension tubes between the handle and the floor tool.
- If using a microfiber cloth or bonnet, secure it to the appropriate tool (e.g., floor tool, triangular tool).

Your browser does not support the video tag.

Video: Instructions on how to attach a cloth or bonnet to the triangle and mop tools.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The power indicator light will illuminate.
5. **Heating Up:** Turn on the power switch. The heating indicator light will turn on. Wait for the light to turn off, indicating the unit has reached operating temperature (approximately 8 minutes).

4. OPERATION

Once the unit is heated, you can begin cleaning. Always test steam on an inconspicuous area first to ensure compatibility with the surface.

1. **Adjusting Steam Pressure:** Use the adjustable pressure knob on the main unit to control the steam output. Turn clockwise for higher pressure, counter-clockwise for lower pressure.
2. **Releasing Steam:** Press and hold the steam trigger on the handle to release steam. Release the trigger to stop the steam flow.
3. **Continuous Steam (Steam Lock):** The Dupray HOME Steam Cleaner features a steam lock for continuous steam. Engage the lock by sliding the button on the handle forward while pressing the trigger. Disengage by sliding it back.

Your browser does not support the video tag.

Video: Demonstrates the steam lock feature on the Dupray HOME Steam Cleaner.

4. Cleaning Techniques:

- **Floors & Tiles:** Use the floor tool with a microfiber cloth. Move the tool slowly over the surface to allow steam to penetrate and lift dirt.



Image: The steam cleaner in use on various surfaces including floors, ovens, furniture, and mattresses.

- **Grout Lines:** Attach a small brush (nylon or brass, depending on surface hardness) to the lance. Apply steam directly to the grout lines, scrubbing gently.



Image: The steam cleaner in use on grout lines, car interiors, windows, and bathroom fixtures.

- **Kitchen Surfaces (Ovens, Refrigerators, Countertops):** Use the detail lance with a brush or the triangular tool with a cloth. Steam helps loosen baked-on grease and grime. Wipe with a clean cloth after steaming.



Image: Before and after comparison of an oven rack cleaned with the Dupray HOME Steam Cleaner.

- **Upholstery & Mattresses:** Use the triangular tool with a microfiber cloth. Move slowly over the fabric, ensuring not to oversaturate.
 - **Windows & Mirrors:** Use the window tool. Steam the surface, then use the squeegee blade to remove condensation and dirt.
 - **Car Interiors:** Use the detail lance with a brush or the triangular tool with a cloth for seats, dashboards, and floor mats.
 - **Grills:** Use the brass brush with the detail lance for stubborn grime on grill grates.
5. **Refilling During Operation:** If the low water indicator illuminates or steam output decreases, turn off the unit and unplug it. Allow the unit to cool for a few minutes before carefully unscrewing the safety cap and refilling.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your steam cleaner.

- **Emptying the Boiler:** After each use, ensure the unit is cool and unplugged. Carefully unscrew the safety cap and invert the unit over a sink to drain any remaining water.
- **Cleaning Accessories:** Wash microfiber cloths and bonnets after each use. Clean brushes and other tools with

water and mild soap.

- **Descaling (if necessary):** If you notice reduced steam output or mineral buildup, descaling may be required. Consult the full user manual for detailed descaling instructions.
- **Storage:** Store the steam cleaner and its accessories in a clean, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Dupray HOME Steam Cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty. Unit not heated sufficiently. Mineral buildup in boiler.	Refill water tank. Wait for the heating indicator light to turn off. Perform descaling procedure (refer to full manual).
Water leaking from accessories.	Accessories not securely attached. Unit not fully heated.	Ensure accessories are firmly connected. Wait for the heating indicator light to turn off before use.
Unit not turning on.	Not plugged in. Power switch is off.	Check power connection. Ensure power switch is in the "ON" position.

If the problem persists, please contact Dupray customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Dupray
Model Name	HOME Steam Cleaner
Model Number	DU050
Wattage	1400 watts
Voltage	230 Volts (AC)
Maximum Temperature	293°F / 145°C
Steam Pressure	46 psi / 3.2 bar
Tank Volume	1 Liters
Included Components	Nozzle, Hose, Brass Brush, Nylon Brush, Squeegee, Funnel, Extension Tube, User Manual
Item Dimensions (D x W x H)	16"D x 10"W x 10"H
Weight (Capacity)	2.1 Pounds
Color	White

Feature	Detail
---------	--------

UPC	829285000105
-----	--------------

8. WARRANTY AND SUPPORT

The Dupray HOME Steam Cleaner comes with a **3-year limited warranty on parts** and a **lifetime warranty on the stainless steel boiler**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or to purchase replacement parts and accessories, please visit the official Dupray website or contact their customer service department. Keep your proof of purchase for warranty validation.

For additional information and resources, you may visit the [Dupray Store on Amazon](#).

