Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > NEFF /
- > NEFF T58TS21N0 Ceramic Electric Hob User Manual

NEFF T58TS21N0

NEFF T58TS21N0 Ceramic Electric Hob User Manual

Model: T58TS21N0

1. Introduction

This manual provides essential information for the safe and efficient operation of your NEFF T58TS21N0 ceramic electric hob. Please read these instructions carefully before installation and use, and keep them for future reference. This appliance is designed for domestic use only.

2. SAFETY INFORMATION

- **Electrical Safety:** Ensure the appliance is correctly earthed and connected to a suitable power supply as specified in the technical data. Installation must be performed by a qualified electrician.
- Hot Surfaces: The hob surface will become hot during and after use. Avoid touching hot surfaces. Use oven mitts or pot holders.
- Children and Vulnerable Persons: This appliance can be used by children aged 8 years and above and persons
 with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given
 supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
 Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without
 supervision.
- Overheating: Do not leave cooking unattended. Overheated fats and oils can ignite.
- Foreign Objects: Do not place metallic objects such as knives, forks, spoons, and lids on the hob surface as they can get hot.
- Cleaning: Disconnect the appliance from the power supply before cleaning.

3. SETUP AND INSTALLATION

The NEFF T58TS21N0 is an independent hob with integrated controls, meaning it does not rely on a separate oven for operation. It requires its own dedicated fixed power connection.

Installation Requirements:

- Installation Size: 750 mm x 490 mm (width x depth).
- Minimum Worktop Thickness: 30 mm.

- Electrical Connection: The appliance must be connected to a fixed power supply by a qualified electrician. The connection cable (110 cm length) is included.
- Placement: As an independent hob, it can be installed in various kitchen locations, such as on a kitchen island.



An overhead view of the NEFF T58TS21N0 ceramic electric hob. The hob features a sleek black glass surface with four distinct cooking zones marked by dotted crosses. On the right side, there is a larger FlexZone area indicated by a grid of dots. At the bottom center, the unique red-ringed TwistPad Fire magnetic control knob is visible, surrounded by touch-sensitive indicators for power levels and functions. The overall design is modern and minimalist, with a stainless steel frame.

4. OPERATING INSTRUCTIONS

Controls: TwistPad Fire

The hob is controlled using the innovative TwistPad Fire, a magnetic, removable control knob. This allows for precise and intuitive adjustment of cooking zones and settings. The heating elements are operated via touch switches located on the glass ceramic surface.

Cooking Zones and Power Levels:

The hob features 5 induction cooking zones with 17 power levels, offering flexibility for various cooking needs. A digital display shows the selected power level.

- Left Rear Zone: Induction, standard zone, diameter 145 mm / 1.4 kW (max power level 2.2 kW).
- Left Front Zone: Diameter 180 mm / 1.8 kW (max power level 3.1 kW).
- Right Rear Zone: Induction, diameter 240 mm / 2.2 kW (max power level 3.7 kW).
- Right Front Zone: Induction, diameter 200 mm / 3.3 kW (max power level 3.7 kW).
- FlexZone (Right Side): Diameter 400 mm x 210 mm / 2.2 kW (max power level 3.7 kW). This zone can be used as a single large zone or two separate zones.

Additional Features:

- **Residual Heat Indicator:** A 2-level residual heat indicator is provided for each cooking zone, warning when the surface is still hot.
- Timer Function: Integrated timer with time display.
- Automatic Shut-off: For safety, the hob features an automatic shut-off function.
- Fault Detection: The system includes fault detection capabilities.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hob.

- Daily Cleaning: After each use, allow the hob to cool down, then wipe the ceramic surface with a damp cloth and a small amount of mild detergent. Dry thoroughly.
- **Stubborn Stains:** For burnt-on food or stubborn stains, use a specialized ceramic hob cleaner and a scraper designed for glass ceramic surfaces. Follow the product instructions carefully.
- Avoid Abrasives: Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage
 the hob surface.
- Control Knob: The TwistPad Fire control knob can be removed for cleaning. Wipe it with a damp cloth and dry.

6. TROUBLESHOOTING

If you encounter issues with your hob, refer to the following general troubleshooting steps. For complex problems, contact qualified service personnel.

- **Hob Not Turning On:** Check if the appliance is properly connected to the power supply. Ensure the TwistPad Fire control knob is correctly placed.
- Cooking Zone Not Heating: Verify that the correct cooking zone has been selected and the power level is set. Ensure suitable cookware is being used (for induction hobs, cookware must be magnetic).
- Error Codes: If an error code appears on the digital display, consult the full manufacturer's manual or contact customer support for specific guidance.
- Automatic Shut-off: If the hob shuts off unexpectedly, it may be due to the automatic safety shut-off function. Check for any spills or objects on the control panel.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	NEFF
Model Number	T58TS21N0
Туре	Ceramic Electric Hob (Induction)
Installation Type	Built-in / Inschuifbaar
Number of Heating Elements	5
Control Type	TwistPad Fire (Magnetic, Removable)
Power Levels	17
Connected Load	7400 W
Voltage	230 V
Dimensions (H x W x D)	51 x 826 x 546 mm
Cut-out Dimensions (W x D)	750-780 x 490 mm
Minimum Worktop Thickness	30 mm
Item Weight	10 kg
Surface Material	Glass Ceramic / Stainless Steel Frame

8. WARRANTY AND SUPPORT

For warranty information, service requests, or technical support, please refer to the warranty card included with your product or visit the official NEFF website. Keep your proof of purchase for warranty claims.

Related Documents - T58TS21N0



Neff N 70 Induction Hob 60cm Black T56FHS1L0 - Features, Specifications, and Installation

Detailed information on the Neff N 70 Induction Hob, 60 cm, Black (T56FHS1L0), including features like Twist Touch, Combi Induction, Home Connect, Smart Hood Automatic, and Hob-based Hood Control. Specifications cover dimensions, power, safety features, and installation requirements.



NEFF T5..L6E.. Induction Hob with Integrated Ventilation System: Instruction Manual

User manual for the NEFF T5..L6E.. Induction Hob with Integrated Ventilation System. Covers operation, safety, cleaning, troubleshooting, and advanced features.



Neff T48CD7AX2 N 70 Integrated Downdraft Induction Hob - 80cm

Discover the Neff T48CD7AX2, an 80cm frameless induction hob with integrated downdraft extraction. Featuring Touch Control, Combi Induction, and Power Move, it offers powerful and quiet operation for a clear view while cooking. Includes detailed specifications and installation guidance.



NEFF T68..Y4.. Induction Hob: User Manual and Information for Use

Discover how to safely and efficiently use your NEFF T68..Y4.. induction hob with this comprehensive user manual. Learn about its features, cooking recommendations, energy-saving tips, and maintenance.



Neff T26BKP6N0 Gas Hob Installation Manual

Detailed installation guide for the Neff T26BKP6N0 stainless steel gas hob, covering safety precautions, furniture preparation, gas and electrical connections, gas type conversion, and technical specifications.



Neff Induction Hob T5..HS1.. User Manual

User manual for Neff induction hob T5..HS1.. providing detailed information on safety, operation, features like PowerBoost and Home Connect, cleaning, troubleshooting, and specifications.