

[manuals.plus](#) /› [havit](#) /› [Havit HV-MS991GT Wireless Mouse User Manual](#)

## havit HV-MS991GT

# Havit HV-MS991GT Wireless Mouse

User Manual

## INTRODUCTION

Thank you for purchasing the Havit HV-MS991GT Wireless Mouse. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it carefully before use to ensure optimal performance and longevity of your mouse.

## SETUP INSTRUCTIONS

1. **Unpack the Mouse:** Carefully remove the mouse and the USB receiver from the packaging.

2. **Install Batteries:**

Locate the battery compartment on the underside of the mouse. Open the cover and insert one AA battery (not included), ensuring correct polarity (+/-). Close the battery compartment cover.



*Image: The Havit HV-MS991GT Wireless Mouse, featuring a black body with red accents and a scroll wheel. This image illustrates the overall design of the mouse.*

- Connect the USB Receiver:** Plug the mini USB receiver into an available USB port on your computer. The system will automatically detect and install the necessary drivers.
- Power On the Mouse:** Locate the power switch on the underside of the mouse and slide it to the "ON" position. The mouse is now ready for use.

## OPERATING INSTRUCTIONS

---

The Havit HV-MS991GT Wireless Mouse is designed for intuitive use with standard mouse functions.

- Basic Functions:**
  - Left Click:** Primary selection and activation.
  - Right Click:** Accesses contextual menus.
  - Scroll Wheel:** Scrolls documents and web pages vertically. The scroll wheel also functions as a middle click button.
- DPI Adjustment:** This mouse features adjustable DPI settings (1000-1600 DPI) for varying cursor speeds and precision. A dedicated DPI button, usually located near the scroll wheel, allows you to cycle through these settings. Press the button to switch between DPI levels.
- Wireless Range:** The advanced 2.4GHz wireless technology provides an effective working distance of up to 15 meters (approximately 49 feet) from the USB receiver.
- System Compatibility:** This mouse is compatible with Windows 2000, Windows XP, Windows Vista, Windows 7, and Windows 8 operating systems.

## MAINTENANCE

---

- Cleaning:** To clean the mouse, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners, as these can damage the mouse's finish.
- Battery Replacement:** When the mouse performance degrades or it stops responding, it is likely time to replace the battery. Follow the battery installation steps in the "Setup Instructions" section.
- Auto Sleep Function:** The mouse features a built-in auto sleep function to conserve battery life. If the mouse is inactive for a period, it will enter a low-power sleep mode. To wake it up, simply move the mouse or click any button.
- Receiver Storage:** The mini USB receiver can be stored inside the mouse's battery compartment when not in use, making it convenient for travel and preventing loss.

## TROUBLESHOOTING

---

Problem	Solution
Mouse is not responding.	<ul style="list-style-type: none"><li>Ensure the mouse power switch is in the "ON" position.</li><li>Check if the battery is correctly installed and has sufficient charge. Replace if necessary.</li><li>Verify that the USB receiver is securely plugged into a working USB port on your computer.</li><li>Try plugging the USB receiver into a different USB port.</li><li>Restart your computer.</li></ul>

Problem	Solution
Cursor movement is erratic or slow.	<ul style="list-style-type: none"><li>Check the mouse's DPI setting and adjust it if needed.</li><li>Ensure the mouse is used on a clean, non-reflective surface.</li><li>Replace the battery.</li><li>Ensure the mouse is within the 15-meter wireless range of the receiver and there are no significant obstructions.</li></ul>
Wireless connection is unstable.	<ul style="list-style-type: none"><li>Move the mouse closer to the USB receiver.</li><li>Avoid using the mouse near other wireless devices (e.g., Wi-Fi routers, cordless phones) that might cause interference.</li><li>Try plugging the USB receiver into a different USB port, preferably one on the front of your computer for better line of sight.</li></ul>

## SPECIFICATIONS

Feature	Detail
Brand	Havit
Model Number	HV-MS991GT
Connectivity Technology	2.4GHz Wireless
DPI Settings	1000-1600 DPI
Number of Buttons	4
Key Life	1,000,000 times
Wireless Range	Up to 15 meters
Operating System Support	Windows 2000/XP/Vista/7/8
Average Battery Life	12 Months
Batteries Included	No (Requires 1x AA battery)
Item Weight	120 g
Package Dimensions	16.2 x 10.8 x 6 cm

## WARRANTY AND SUPPORT

Specific warranty information for the Havit HV-MS991GT Wireless Mouse is not provided in this manual. Please refer to the product packaging or the manufacturer's official website for details regarding warranty coverage and customer support contact information.

