



[Manuals.plus](#) /

› [Office Star Products](#) /

› Office Star Products Space Seating 55 Series Office Chair Instruction Manual

## Office Star Products 5500-3M

# Office Star Products Space Seating 55 Series Office Chair Instruction Manual

Model: 5500-3M

## PRODUCT OVERVIEW

---

The Office Star Products Space Seating 55 Series office chair is designed for comfort and adjustability. It features a breathable Air Grid back for optimal lumbar support, 2-to-1 synchro control, and adjustable tilt tension. The chair is built with a heavy-duty angled nylon base and oversized dual-wheel carpet casters for mobility. This model is GREENGUARD certified, ensuring low chemical emissions for improved indoor air quality.



Image: The Space Seating 55 Series office chair, black mesh back and seat, positioned at a desk in an office environment.

## SETUP AND ASSEMBLY

---

This chair requires DIY assembly. Please ensure all components are present before beginning. Refer to the included assembly instructions for detailed steps. Typically, assembly involves attaching the casters to the base, connecting the gas lift cylinder, mounting the seat and backrest, and securing the armrests.

- **Unpack Components:** Carefully remove all parts from the packaging.
- **Attach Casters:** Insert the dual-wheel carpet casters into the holes on the heavy-duty nylon base.
- **Install Gas Lift:** Place the gas lift cylinder into the center hole of the base.
- **Assemble Seat and Back:** Follow the specific instructions to attach the seat and backrest to the chair mechanism.
- **Attach Armrests:** Secure the adjustable armrests to the seat base.




Image: An exploded diagram showing all individual components of the chair, including the base, casters, gas lift, seat, backrest, and armrests, for assembly reference.

## OPERATING INSTRUCTIONS

---

The Space Seating 55 Series chair offers several adjustments to customize your seating experience for optimal comfort and ergonomic support.

### 1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, lift the lever to lower the seat. To raise the seat, lift the lever while taking your weight off the seat. Release the lever at your desired height.

### 2. Armrest Height Adjustment

The armrests are height adjustable. Press the button located on the side of each armrest post. While holding the button, slide the armrest up or down to your preferred height. Release the button to lock the armrest in place.

### 3. Tilt and Tilt Tension Adjustment

The chair features a 2-to-1 synchro control and adjustable tilt tension. To enable or disable the recline

function, push the lever on the left side beneath the seat (opposite the height adjustment lever) in or out. Pushing it in locks the backrest in an upright position, while pulling it out allows for reclining. The tilt tension knob, usually located at the front center under the seat, can be rotated to increase or decrease the resistance of the recline.



Image: A side view of the chair highlighting the various adjustment levers and knobs for seat height, armrest height, and tilt control.

## MAINTENANCE

---

To ensure the longevity and appearance of your Space Seating 55 Series office chair, follow these simple maintenance guidelines:

- **Cleaning:** Spot clean the fabric and mesh surfaces as needed. Use a mild soap and water solution with a soft cloth. Avoid harsh chemicals or abrasive cleaners.
- **Caster Care:** Periodically check the dual-wheel carpet casters for any accumulated debris (hair, lint, etc.) and clean them to ensure smooth rolling.
- **Hardware Check:** Occasionally inspect all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.



Image: A detailed view of the breathable black Air Grid mesh backrest, emphasizing its texture and design.

## **TROUBLESHOOTING**

---

If you encounter any issues with your Space Seating 55 Series office chair, please refer to the following common solutions:

- **Chair Sinks or Won't Stay Up:** This usually indicates an issue with the gas lift cylinder. Contact customer support for a replacement.
- **Chair Wobbles:** Ensure all assembly bolts are securely tightened. Check the base and casters for any damage or loose connections.
- **Casters Not Rolling Smoothly:** Clean any debris from the caster wheels. If they are still stiff, they may need lubrication or replacement.
- **Backrest Not Reclining/Locking:** Verify the tilt lock lever is in the correct position (pulled out for recline, pushed in to lock). Adjust the tilt tension knob if the recline resistance is too high or low.

## SPECIFICATIONS

Feature	Detail
Brand	Office Star Products
Model Name	55 Series
Model Number	5500-3M
Color	Black Mesh
Overall Dimensions	26.5" W x 25.25" D x 38-42.25" H
Seat Dimensions	20.5" W x 19.5" D x 3.5" T
Back Dimensions	20.5" W x 18.5" H
Material	Fabric, Foam, Metal, Plastic (100% Polyester Fabric Type)
Back Style	Mesh (Air Grid)
Special Features	Adjustable Height, Arm Rest, Ergonomic, Rolling, Built-in Lumbar Support, 2-to-1 Synchro Control, Adjustable Tilt Tension
Maximum Weight Recommendation	275 Pounds
Certifications	GREENGUARD Certified, Meets or exceeds ANSI/BIFMA standards
Item Weight	33 pounds



Image: A direct front view of the office chair, showcasing the seat cushion, armrests, and mesh backrest.

## **WARRANTY AND SUPPORT**

---

For specific warranty information, please refer to the documentation included with your purchase or visit the official Office Star Products website. Additional protection plans may be available for purchase separately.

For customer support, assembly assistance, or to inquire about replacement parts, please contact Office Star Products directly. Contact details can typically be found on their official website or in your product packaging.

---

© 2024 Office Star Products. All rights reserved.