Nespresso ENV135GY

Nespresso Vertuo De'Longhi ENV135GY Coffee and Espresso Maker User Manual

Model: ENV135GY | Brand: Nespresso

Introduction | Safety Instructions | Product Overview | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides comprehensive instructions for the safe and efficient use of your Nespresso Vertuo De'Longhi ENV135GY Coffee and Espresso Maker. Please read all instructions carefully before first use and retain this manual for future reference.

The Nespresso Vertuo machine is designed to brew a variety of single-serve coffee and espresso beverages. It features a one-touch brewing system, automatic capsule ejection, and a rapid heat-up time for convenience.



Figure 1: Nespresso Vertuo De'Longhi ENV135GY Coffee and Espresso Maker.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.

WARNING: Proposition 65 Warning: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. Product Overview

The Nespresso Vertuo machine combines innovative technology with user-friendly design to deliver a premium coffee and espresso experience. Key features include:

- **One-Touch Brewing System:** Simplifies the coffee preparation process.
- **Removable Water Tank:** A 54 oz (1.6 liter) capacity water reservoir for convenience.
- **Automatic Capsule Ejection:** Used capsules are automatically ejected into a dedicated container.
- **Rapid Heat-Up:** Ready to brew in approximately 15-20 seconds.
- **Energy Saving:** Automatic shut-off after 9 minutes of inactivity.
- **Adjustable Cup Support:** Accommodates various cup sizes.



Figure 2: Ultimate Simplicity - Key features of the Nespresso Vertuo machine.

Dimensions

The compact design of the Vertuo machine ensures it fits well in various kitchen spaces.

Product Dimensions: 8.97"D x 12.22"W x 12.33"H

Item Weight: 10.96 pounds



Figure 3: Nespresso Vertuo machine dimensions.

Included Components

Your Nespresso Vertuo machine package includes:

- Nespresso Vertuo Coffee and Espresso Maker
- Welcome Set of Nespresso Vertuo capsules (12 capsules)
- User Manual and Welcome Guide



Figure 4: Package contents of the Nespresso Vertuo machine.

4. Setup

1. **Unpacking:** Carefully remove the machine and all components from the packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the machine on a clean, stable, and level surface, away from water sources and heat. Ensure adequate space around the machine for ventilation and access.
3. **Rinse Water Tank:** Remove the water tank and rinse it thoroughly with fresh drinking water.
4. **Fill Water Tank:** Fill the water tank with fresh drinking water up to the MAX level indicator. Place the water tank back onto the machine.
5. **Plug In:** Plug the power cord into a grounded electrical outlet.
6. **First Use / Rinsing:**
    - Place a container (at least 0.5 liters) under the coffee outlet.
    - Press the button to turn on the machine. The button will blink as it heats up.

- Once the button is steady, press it three times quickly to start the rinsing cycle. The machine will dispense hot water.
- Allow the cycle to complete. This cleans the internal system and prepares the machine for brewing.

5. Operating Instructions

The Nespresso Vertuo machine uses Centrifusion™ technology to brew coffee and espresso, automatically recognizing each capsule via its barcode to adjust brewing parameters.



Figure 5: Blend-Specific Brewing Technology.

Brewing a Beverage

1. **Turn On:** Ensure the machine is plugged in and the water tank is filled. Press the button to turn on the machine. Wait for the button to stop blinking (approx. 15-20 seconds).

2. **Open Head:** Lift the lever to open the machine head.
3. **Insert Capsule:** Insert a Nespresso Vertuo capsule with the dome side down.
4. **Close Head:** Close the machine head and lock it by turning the lever to the left.
5. **Place Cup:** Place your desired cup under the coffee outlet. Adjust the cup support if necessary.
6. **Start Brewing:** Press the button once. The machine will automatically read the capsule's barcode and begin brewing.
7. **Enjoy:** Once brewing is complete, the machine will automatically eject the used capsule into the capsule container.

Cup Sizes

The Vertuo machine brews various cup sizes, automatically determined by the inserted capsule:

- Espresso (Single and Double)
- Coffee (5 oz, 8 oz, and 12 oz)





Figure 6: Available Nespresso Vertuo cup sizes.

6. Maintenance

Regular cleaning and maintenance ensure optimal performance and longevity of your Nespresso Vertuo machine.

Daily Cleaning

- **Water Tank:** Empty and rinse the water tank daily. Refill with fresh water.
- **Drip Tray & Capsule Container:** Empty and clean the drip tray and used capsule container daily. Wash with warm soapy water and rinse thoroughly.
- **Coffee Outlet:** Wipe the coffee outlet with a damp cloth.

Descaling

Descaling is crucial to remove mineral deposits that can affect machine performance and coffee taste. The frequency depends on water hardness and usage. Refer to the Nespresso website or your machine's specific descaling instructions for the recommended procedure and descaling solution.
Note: Only use Nespresso descaling kits to avoid damaging the machine.

7. Troubleshooting

If you encounter issues with your Nespresso Vertuo machine, consult the following table for common problems and solutions. If the problem persists, contact Nespresso Customer Service.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No coffee flow.	Water tank empty; machine not descaled; air bubble in system.	Fill water tank; perform descaling; run a rinsing cycle without a capsule.
Coffee is not hot enough.	Cup not preheated; machine needs descaling.	Preheat cup with hot water; perform descaling.
Machine leaks water.	Water tank not correctly positioned; damaged water tank.	Ensure water tank is securely in place; inspect water tank for cracks and replace if damaged.
Button blinking red.	Error or descaling alert.	Refer to the Nespresso app or website for specific error codes, or perform descaling.

8. Specifications

Feature	Detail
Brand	Nespresso
Model Name	ENV135GY
Manufacturer	De'Longhi
Color	Graphite Metal
Product Dimensions	8.97"D x 12.22"W x 12.33"H
Item Weight	10.96 pounds
Special Feature	Programmable
Coffee Maker Type	Espresso Machine
Style	Machine Only
Specific Uses For Product	Espresso
Included Components	Capsules
Operation Mode	Fully Automatic
Voltage	120 Volts
Number of Items	1
Human Interface Input	Buttons
UPC	044387001359
Date First Available	February 1, 2017

9. Warranty and Support

Nespresso provides a limited warranty for its machines. For detailed warranty information, including terms, conditions, and duration, please refer to the warranty card included with your machine or visit the official Nespresso website.
For technical assistance, troubleshooting beyond this manual, or to order Nespresso Vertuo capsules, please contact Nespresso Customer Service or visit their official website:

- **Nespresso Official Website:** www.nespresso.com
- **Nespresso Store on Amazon:** Visit the Nespresso Store

When contacting support, please have your machine's model number (ENV135GY) and serial number ready. The serial number is typically located on a sticker under the machine or behind the water tank.

© 2024 Nespresso. All rights reserved. Nespresso Vertuo De'Longhi ENV135GY User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question