

[Manuals.plus](#) /

> [Ameriwood Home](#) /

> Ameriwood Home Overland Corner Fireplace TV Stand User Manual

Ameriwood Home 1805096COM

Ameriwood Home Overland Corner Fireplace TV Stand User Manual

Model: 1805096COM

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Ameriwood Home Overland Corner Fireplace TV Stand. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Ameriwood Home Overland Corner Fireplace TV Stand in Espresso finish, featuring a realistic electric fireplace insert and open shelving.

This image displays the complete Ameriwood Home Overland Corner Fireplace TV Stand, highlighting its design and integrated electric fireplace.

IMPORTANT SAFETY INFORMATION

- **Electrical Safety:** For unit longevity and safe operation, plug the electric heater into a dedicated 120V outlet alone. Do not overload circuits.
- **Carbon Monoxide:** The AltraFlame electric heater is eco-friendly and produces no carbon monoxide.
- **Placement:** Ensure the TV stand is placed on a stable, level surface. Avoid placing near flammable materials.
- **Ventilation:** Do not block the heater's air vents. Maintain clear space around the unit for proper airflow.
- **Assembly:** Assembly requires two adults. Follow all assembly instructions carefully to prevent injury or damage.




Image: Illustration of proper electrical outlet usage for safety.

This image illustrates the best practice for plugging in the electric fireplace heater into a dedicated 120V outlet to ensure safety and optimal performance.

SETUP AND ASSEMBLY

Your Ameriwood Home Overland Corner Fireplace TV Stand ships in one box and requires assembly. Two adults are recommended for assembly to ensure safety and ease of construction.

Before You Begin:

- Clear a spacious area for assembly.
- Verify all parts and hardware are present against the included parts list.
- Gather necessary tools (e.g., Phillips head screwdriver).

Assembly Steps:

1. Follow the step-by-step instructions provided in the packaging. Ensure each piece is correctly oriented as depicted in the diagrams.
2. Secure all fasteners tightly, but do not overtighten to avoid damaging the material.
3. Carefully insert the 23-inch electric fireplace insert into the designated opening.
4. Position the assembled TV stand in a corner to maximize space.



Image: Technical diagram illustrating the overall product dimensions and maximum weight capacities for the TV stand and shelves.

This diagram provides detailed measurements and weight limits for the TV stand. The top surface supports TVs up to 50 inches wide or 60 lbs. Side shelves each support up to 8 lbs, and the large top shelf supports up to 25 lbs.

OPERATING INSTRUCTIONS

The electric fireplace insert features a user-friendly control panel and an infrared remote control for convenient operation.

Fireplace Controls:

- **Power On/Off:** Use the power button on the control panel or remote to turn the unit on or off.
- **Flame Effect:** The realistic LED flame effect can be operated independently of the heat function. Adjust flame brightness with the remote or control panel. There are 4 brightness levels.
- **Heat Function:** Activate the heater to warm rooms up to 400 square feet. The heater offers 11 heat settings.
- **Timer Function:** Set a timer for automatic shut-off, useful for energy saving or when heat is not continuously needed.
- **Remote Control:** An infrared remote control with AAA batteries is included for ease of use. Ensure the remote has fresh batteries for optimal performance.




Image: Detailed view of the electric fireplace insert, showcasing the realistic log and flame effect.

This image highlights the realistic LED flame effect and log set within the fireplace insert, which can be enjoyed with or without the heating function.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your fireplace TV stand.

- **Cleaning:** Dust the unit regularly with a soft, dry cloth. For the fireplace insert glass, use a non-abrasive glass cleaner.
- **Ventilation:** Periodically check and clean the heater's air vents to prevent dust buildup, which can impede airflow and reduce efficiency.

- **Electrical Cord:** Inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, remote batteries dead, or unit is off.	Check power connection, replace remote batteries, ensure unit is switched on.
No heat output.	Heat function is off, or thermostat setting is too low.	Activate heat function, increase thermostat setting.
Flame effect is not visible.	Flame effect is off, or brightness is set to minimum.	Turn on flame effect, increase brightness level.

SPECIFICATIONS

Brand: Ameriwood Home

Model Name: Overland 50" Electric Fireplace Corner TV Stand

Model Number: 1805096COM

Product Dimensions: 19.7"D x 29.7"W x 47.6"H

Material: Wood (Laminated MDF and particleboard)

Color: Espresso

Power Source: Corded Electric

Heat Output: 4700 British Thermal Units

Heating Coverage: Up to 400 square feet

TV Size Accommodation: Up to 50 inches wide

Maximum Recommended Load (Top): 60 lbs

Maximum Recommended Load (Side Shelves): 8 lbs each

Maximum Recommended Load (Large Top Shelf): 25 lbs

Number of Shelves: 5

Fireplace Insert Size: 23 inches (Chamber Width)

Special Features: Realistic LED flame effect, 11 heat levels, 4 brightness levels, timer function, remote control.

UPC: 029986180506

WARRANTY INFORMATION

This Ameriwood Home product is covered by a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by improper assembly, misuse, abuse, accident, or normal wear and tear. For warranty claims, please retain your proof of purchase.

CUSTOMER SUPPORT

For assistance with assembly, missing parts, troubleshooting, or warranty inquiries, please contact Ameriwood Home customer support.

Website: Visit the [Ameriwood Home Store on Amazon](#) for more information and support resources.

Online Support: Refer to the official Ameriwood Home website for contact details and FAQs.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01MDTN6O1>

More documents and user manuals: <https://manuals.plus/>