

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lighting EVER](#) /
- › [Lighting EVER LE LED Flashlight User Manual \(Model: 1200012-2-a\)](#)

Lighting EVER 1200012-2-a

Lighting EVER LE LED Flashlight User Manual

Model: 1200012-2-a | Brand: Lighting EVER

1. INTRODUCTION

Thank you for choosing the Lighting EVER LE LED Flashlight. This compact, high-lumen, and durable flashlight is designed for reliability in various situations, including outdoor activities, emergencies, and general household use. Its adjustable focus and water-resistant design make it a versatile tool for your lighting needs. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image 1.1: The Lighting EVER LE LED Flashlight provides a powerful beam for various applications.

2. SAFETY INFORMATION

- **Eye Safety:** Do not look directly into the LED light or shine it directly into the eyes of others. The high-intensity light can cause temporary vision impairment or eye damage.
- **Battery Handling:** Use only the specified AAA batteries. Do not mix old and new batteries, or different types of batteries. Ensure correct polarity when inserting batteries. Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- **Children:** Keep out of reach of children. This product is not a toy.
- **Heat:** The flashlight head may become warm during prolonged use. This is normal.
- **Disassembly:** Do not attempt to disassemble or modify the flashlight. This will void the warranty and

may cause damage or injury.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Lighting EVER LE LED Flashlight (x2)
- AAA Batteries (x6)
- Instruction Manual (this document)



Image 3.1: Contents of the Lighting EVER LE LED Flashlight 2-pack.

4. PRODUCT FEATURES

- **Compact and Portable:** Small size (Length: 4.2 inches, Diameter: 1.2 inches; Weight: 128g) fits easily in hand or pocket.
- **High Brightness:** Equipped with an LED, providing approximately 140 lumens of light.
- **Long Beam Distance:** Illuminates up to 492 feet (150 meters).

- **Adjustable Focus (Zoomable):** Easily switch between a narrow spot beam and a wide flood beam by extending or retracting the flashlight head.
- **Durable Construction:** Made from premium aluminum casing, resistant to impact, rust, and corrosion.
- **Water Resistant:** IPX4 rated, protecting against splashing water from any direction.
- **Anti-Slip Design:** Textured surface for a secure grip.
- **Simple Operation:** Single button control for power.

Pocket Size



Image 4.1: Compact size for easy portability.



Image 4.2: IPX4 water-resistant design.

High Lumen Flashlight

The Beam Distance up to 150 meters (500ft)



Image 4.3: High lumen output with a long beam distance.

5. SETUP: BATTERY INSTALLATION


The Lighting EVER LE LED Flashlight requires three (3) AAA batteries for operation. Batteries are included in the package.

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert the three AAA batteries into the battery holder, ensuring correct polarity (+/-) as indicated on the holder.
3. Place the battery holder into the flashlight body, making sure the arrow on the holder points towards the flashlight head.
4. Screw the tail cap back on clockwise until it is securely tightened.

Mighty in Pocket Size



Solid State



3x AAA



IP44



Anti-slip



140lm



Image 5.1: Battery installation diagram.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

To turn the flashlight on or off, press the rubber button located on the tail cap. This flashlight features a single light mode (on/off).

6.2 Adjusting Focus (Zoom Function)

The flashlight features an adjustable focus mechanism to change the beam from a narrow spot to a wide flood.

- To achieve a **narrow spot beam** for long-distance illumination, gently pull the head of the flashlight forward (extend it).
- To achieve a **wide flood beam** for broader area illumination, gently push the head of the flashlight backward (retract it).




Image 6.1: Adjusting the flashlight's focus.

7. MAINTENANCE

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents. Keep the lens clean for optimal light output.
- **Battery Replacement:** Replace all three AAA batteries when the light becomes dim or stops working. Always replace with a fresh set of high-quality AAA batteries.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight. If storing for an extended period (more than a month), remove the batteries to prevent leakage and potential damage to the flashlight.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace with new AAA batteries.

Problem	Possible Cause	Solution
Light is dim.	Low battery power.	Replace with new AAA batteries.
Beam is inconsistent or flickers.	Loose battery connection or dirty contacts.	Ensure tail cap is tightened. Clean battery contacts with a dry cloth. Replace batteries.
Focus mechanism is stiff.	Dirt or debris in the sliding mechanism.	Gently clean the exterior of the sliding head. Avoid forcing the mechanism.

9. SPECIFICATIONS

Model Number	1200012-2-a
Brand	Lighting EVER
Light Source Type	LED
Brightness	140 Lumens
Power Source	Battery Powered
Battery Type	3 x AAA (Alkaline)
Material	Aluminum
Color	Black
Water Resistance Level	IPX4 (Water Resistant)
Product Dimensions	1.34"D x 1.34"W x 4.29"H (3.15"D x 1.46"W x 4.53"H also listed, using more common)
Item Weight	4.5 ounces (128 Grams)
Special Features	Adjustable focus, portable, non-slip grip, durable

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Lighting EVER website. Keep your proof of purchase for any warranty claims.

EU spare part availability duration: 1 Year.