

[Manuals.plus](#) /

› [LASER X](#) /

› Laser X Two Player Laser Gaming Set Instruction Manual

LASER X 88016

Laser X Two Player Laser Gaming Set Instruction Manual

Model: 88016

INTRODUCTION

Welcome to the world of Laser X! This real-life laser gaming experience set includes everything you need for two players to engage in exciting laser tag battles. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure an optimal gaming experience.



Image: Overview of the Laser X Two Player Gaming Set, showing two blasters and two receiver vests.

WHAT'S IN THE BOX

Your Laser X Two Player Laser Gaming Set includes the following components:

- 2 Laser X Blasters
- 2 Receiver Vests

Note: 6 AAA batteries are required for operation and are not included in the set.

SAFETY INFORMATION

WARNING: This product contains small parts and is not intended for children under 3 years of age. Adult supervision is recommended during play.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of each Laser X Blaster and Receiver Vest.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 AAA batteries into each blaster and 3 AAA batteries into each receiver vest, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

2. Wearing the Gear

- Attach the receiver vest to your chest using the adjustable strap. Ensure it is snug but comfortable. The vest is designed to receive laser blasts.
- Hold the Laser X Blaster firmly in your hand.




Image: Two individuals demonstrating how to wear the Laser X receiver vests and hold the blasters.

OPERATING INSTRUCTIONS

1. Power On

Press the power button on both the blaster and the receiver vest to turn them on. The blaster and vest will light up,

indicating they are ready for play.

2. Team Selection

The receiver vest allows you to select a team (Red, Blue, or Neutral). Follow the voice prompts or refer to the vest's indicator lights to choose your team before starting a game.

3. Gameplay

- Aim your blaster at an opponent's receiver vest and press the trigger to fire.
- The blaster has a range of up to 200 feet.
- Full-color lighting effects on the blaster and vest indicate shots fired and hits received.
- An interactive voice coach provides tips and feedback during the game.
- You can plug in headphones (not included) to hear the Laser X soundtrack and sound effects privately.
- The blaster features a blast power indicator to show how many shots remain.
- When hit, your vest will flash and vibrate, and the voice coach will announce the hit.
- To reload your blaster, press the reload button.



Image: Multiple children actively playing Laser X, with their blasters and vests emitting light, indicating gameplay.

4. Game Modes

Laser X supports both team play and individual play. You can play with all other Laser X sets for expanded gameplay.



Image: Four players in action during a Laser X game, demonstrating aiming and interaction.

MAINTENANCE

- **Cleaning:** Wipe down the blasters and vests with a dry, soft cloth after each use. Do not submerge in water or use harsh chemicals.
- **Storage:** Store the Laser X set in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries from the blasters and vests if the product will not be used for an extended period to prevent battery leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blaster/Vest not turning on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AAA batteries.

Problem	Possible Cause	Solution
Blaster not firing or hits not registering.	Out of range, obstructed sensor, or low battery.	Ensure you are within 200 feet of the target. Clear any obstructions from the vest sensor. Replace batteries.
Voice coach or sound effects are not audible.	Volume too low or headphones not properly connected.	Adjust volume settings. Ensure headphones are fully plugged in if used.

SPECIFICATIONS

Model Number: 88016

Product Dimensions: 11.42 x 1.34 x 6.3 inches

Item Weight: 1 pound

Recommended Age: 6 - 15 years

Batteries Required: 6 AAA batteries (3 per blaster, 3 per vest)

Range: Up to 200 feet

Country of Origin: China

Manufacturer: NSI

Release Date: December 12, 2016

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for warranty claims.

© 2024 LASER X. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question