

[Manuals.plus](#) /

> [it luggage](#) /

> it luggage Megalite 3pc Spinner Set with Expander Instruction Manual

it luggage 12094204A-UEB3N-S817

it luggage Megalite 3pc Spinner Set with Expander Instruction Manual

Model: 12094204A-UEB3N-S817

1. PRODUCT OVERVIEW

The it luggage Megalite 3pc Spinner Set is designed for lightweight travel and ease of use. This set includes three spinner suitcases, each equipped with features to enhance your travel experience.

1.1 Components

- **Main Compartment:** Primary storage area for clothing and larger items.
- **Front Zip Pocket:** External pocket for quick access to travel documents or small items.
- **Telescopic Handle:** Retractable handle for easy maneuvering.
- **Spinner Wheels:** Four wheels per suitcase for 360-degree rotation and smooth gliding.
- **Expander Zipper:** Allows for increased packing capacity.
- **Fully Lined Interior:** Protects contents and includes organizational features.
- **Tie-Down Straps:** Internal straps to secure packed items.
- **Mesh Zip Pocket:** Internal pocket for smaller accessories.

1.2 Key Features

- Front zip pocket for easy access to travel documents or on-the-go items.
- Fully lined interior features 2 tie-down straps to hold items in place, a mesh zip pocket to help keep this organized.
- Semi-expander for up to 25% extra packing capacity - plenty of room for souvenirs on the trip home.

1.3 Product Images



Figure 1: Front view of the 3-piece Megalite spinner set, showcasing the vibrant fiery red color and front pockets.



Figure 2: Side profile of a Megalite suitcase, highlighting the expander zipper and the durable side carry handle.



Figure 3: Rear view of the 3-piece Megalite spinner set, showing the back panel and telescopic handle housing.



Figure 4: Interior view of an open Megalite suitcase, revealing the fully lined compartment with tie-down straps and a mesh zippered pocket for organization.

2. SETUP

Upon receiving your luggage Megalite spinner set, follow these steps for initial setup:

1. **Unpack:** Carefully remove all suitcases from their packaging. Inspect each piece for any signs of damage during transit.
2. **Extend Handle:** Locate the button on the top of the telescopic handle. Press the button and pull the handle upwards until it locks into place at your desired height. Ensure it extends and retracts smoothly.
3. **Check Wheels:** Verify that all four spinner wheels on each suitcase rotate freely and smoothly in all directions.
4. **Inspect Zippers:** Open and close all main and expander zippers to ensure they operate without snagging.

3. OPERATING INSTRUCTIONS

3.1 Extending and Retracting the Handle

To extend the telescopic handle, press the release button located on the top of the handle grip and pull the handle upwards. It will lock into position at various heights. To retract, press the button again and push the handle down until it is fully nested within the suitcase.

3.2 Using the Spinner Wheels

The Megalite suitcases are equipped with four spinner wheels, allowing for 360-degree maneuverability. For optimal control, push the suitcase alongside you on all four wheels. For uneven surfaces, tilt the suitcase and pull it on two wheels.

3.3 Packing the Luggage

Open the main compartment zipper. Place heavier items at the bottom near the wheels for better balance. Utilize the internal tie-down straps to secure your belongings and prevent shifting during transit. The mesh zip pocket is ideal for smaller items like toiletries or electronics.

3.4 Utilizing the Expander Feature

If you require additional packing space, locate the expander zipper running along the perimeter of the suitcase. Unzip this section to increase the depth of the main compartment by up to 25%. This is particularly useful for souvenirs or extra clothing on your return journey.

3.5 Using the Front Zip Pocket

The front zip pocket provides convenient access to items you may need quickly, such as travel documents, boarding passes, or a small book. Ensure valuable items are securely stored.

4. MAINTENANCE

4.1 Cleaning

- **Exterior:** For general cleaning, wipe the exterior fabric with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Interior:** The interior lining can be spot cleaned with a damp cloth. Allow to air dry completely before closing.

4.2 Storage

When not in use, store the luggage in a cool, dry place away from direct sunlight. It is recommended to store the smaller suitcases inside the larger ones to save space.

4.3 Wheel and Handle Care

Periodically check the wheels for any debris or hair that might impede their movement. Clean as necessary. Ensure the telescopic handle mechanism remains free of dirt to ensure smooth operation.

5. TROUBLESHOOTING

Problem	Solution
Telescopic handle sticks or won't extend/retract.	Ensure the release button is fully depressed. Check for any obstructions or debris in the handle mechanism. Do not force the handle.
Wheels are not rolling smoothly.	Inspect wheels for tangled hair, lint, or debris. Clean the wheel axles if necessary. Ensure the suitcase is not overloaded beyond its capacity.

Problem	Solution
Zipper is difficult to open/close.	Check for fabric caught in the zipper teeth. Gently pull the fabric away. If the zipper is stiff, apply a small amount of zipper lubricant or wax.
Luggage appears dented or misshapen.	The soft-sided construction allows for flexibility. Minor indentations are often temporary and can be pushed out from the inside. This does not typically affect durability.

6. SPECIFICATIONS

Attribute	Value
Product Dimensions (Largest Piece)	11.2 x 19.5 x 31.3 inches
Item Weight (Total Set)	17.63 pounds
Model Number	12094204A-UEB3N-S817
Manufacturer	IT Luggage
Department	Unisex-Adult

7. WARRANTY & SUPPORT

it luggage products are designed for durability and performance. For specific warranty information regarding your Megalite 3pc Spinner Set, please refer to the warranty card included with your purchase or visit the official it luggage website. Warranty terms typically cover manufacturing defects.

For customer support, inquiries, or to make a warranty claim, please contact it luggage directly through their official website or customer service channels. Ensure you have your model number (12094204A-UEB3N-S817) and proof of purchase available when contacting support.

Website: www.itluggage.com