

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Logitech](#) /
- › [Logitech M331 SILENT PLUS Wireless Mouse User Manual](#)

Logitech M331

Logitech M331 SILENT PLUS Wireless Mouse User Manual

Model: M331 (910-004914)

INTRODUCTION

Thank you for choosing the Logitech M331 SILENT PLUS Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your new mouse. The M331 SILENT PLUS is designed for quiet operation and comfortable use, featuring advanced optical tracking and a long-lasting battery.





Figure 1: Logitech M331 SILENT PLUS Wireless Mouse (Black)

PACKAGE CONTENTS

Ensure all items are present in the package:

- Logitech M331 SILENT PLUS Wireless Mouse
- Nano Receiver
- 1 AA Battery (pre-installed)
- User Documentation

SETUP GUIDE

1. Battery Installation

The Logitech M331 SILENT PLUS mouse comes with one AA battery pre-installed. To activate the mouse, simply remove the battery pull tab if present. If you need to replace the battery:

1. Locate the battery compartment cover on the underside of the mouse.
2. Slide the cover open.
3. Insert one AA battery, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Connecting the Nano Receiver

The Nano Receiver provides a reliable 2.4GHz wireless connection.

1. Remove the Nano Receiver from its storage slot inside the mouse's battery compartment.
2. Plug the Nano Receiver into an available USB port on your computer.
3. Turn on the mouse using the On/Off switch located on the underside of the mouse.
4. Your computer should automatically detect and install the necessary drivers. The mouse is ready for use.

System Requirements:

Windows 10 or later, Windows 8, Windows RT, Windows 7

Mac OS X 10.5 or later

Chrome OS

Linux Kernel 2.6+2

Available USB port

OPERATING YOUR MOUSE

Silent Clicks and Quiet Scrolling

The M331 SILENT PLUS features over 90% noise reduction on click sounds, providing a quiet experience. The rubber scroll wheel also ensures quiet and smooth scrolling.

90% noise reduction



Less noise. Full focus

Figure 2: The M331 SILENT PLUS mouse offers significant noise reduction for a quieter workspace.

Smooth navigation and precise scrolling



Figure 3: Experience smooth navigation and precise scrolling with the M331.

Ergonomic Design

The mouse is crafted with curved lines and contoured side grips, providing a comfortable fit for your right hand and improving control during extended use.

Crafted for your right hand



Contoured side grips

Figure 4: The M331's ergonomic design is crafted for comfortable right-hand use.

Advanced Optical Tracking

Equipped with Logitech Advanced Optical Tracking, the mouse provides precise cursor control on various surfaces. The sensor resolution is 1000 dpi.

Silent Clicks

Wide rubber wheel

Contoured grips



High precision tracking

Unifying receiver stored in mouse

10m range wireless



Figure 5: Key features of the Logitech M331 SILENT PLUS mouse, including its high precision tracking and wireless range.

MAINTENANCE

Battery Life

The M331 SILENT PLUS boasts an impressive battery life of up to 24 months, thanks to its energy-efficient engineering. Battery life may vary based on user and computing conditions.

Quality & durability



Figure 6: The M331 is built for quality and durability, offering extended battery life. (Note: Image shows 18 months, product specifications state up to 24 months.)

Cleaning

To clean your mouse, use a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the mouse is turned on using the On/Off switch.
 - Check if the Nano Receiver is securely plugged into a working USB port. Try a different USB port.
 - Replace the AA battery.
 - Move the mouse closer to the Nano Receiver to ensure it's within the 10-meter wireless range.
- **Erratic cursor movement:**
 - Clean the optical sensor on the underside of the mouse.
 - Ensure you are using the mouse on a suitable surface. Avoid highly reflective or transparent surfaces.
- **Connection issues:**

- If you experience interference, try moving the mouse and receiver away from other wireless devices or large metal objects.

SPECIFICATIONS

Dimensions (Mouse)	105.4 mm (height) x 67.9 mm (width) x 38.4 mm (depth)
Weight (Mouse)	91.0 g
Dimensions (Nano Receiver)	14.4 mm (height) x 18.7 mm (width) x 6.1 mm (depth)
Weight (Nano Receiver)	1.8 g
Connection Type	2.4GHz wireless connection
Wireless Range	10 meters (33 feet)
Battery Type	1 x AA battery
Battery Life	Up to 24 months
Sensor Technology	Logitech Advanced Optical Tracking
Sensor Resolution	1000 dpi
Scroll Wheel	Yes, 2D, optical
Number of Buttons	3 (Left, Right, Middle click)
On/Off Switch	Yes
Model Number	910-004914



Figure 7: Detailed dimensions and weight of the Logitech M331 SILENT PLUS mouse.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Logitech website or the user documentation included in your package. You can also visit the Logitech store on Amazon for additional resources and product information.

Logitech Store: [Visit the Logitech Store on Amazon.sg](https://www.amazon.com/logitech)

