Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 43235-19477

JustFine Replacement Remote Control User Manual

For Sony STR-DH520, RMAAU104, 148934311, RM-AAU105 Audio/Video AV Receivers

1. Introduction

This document provides essential instructions for the proper use and maintenance of your JustFine replacement remote control. This remote is designed to be compatible with Sony STR-DH520, RMAAU104, 148934311, and RM-AAU105 Audio/Video AV Receiver Home Theater Systems.
The remote control is pre-programmed and requires no additional setup or programming. Simply insert batteries to begin operation.

2. Setup: Battery Installation

To power your remote control, you will need to install two AA or AAA batteries (not included). Follow these steps:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AA or AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image 1: Rear view of the remote control, highlighting the battery compartment cover and the battery disposal symbol.

Note: Ensure batteries are inserted with the correct polarity. Incorrect installation can prevent the remote from functioning or cause damage.

3. Operating Instructions

This replacement remote control is pre-programmed to work with compatible Sony Audio/Video AV Receivers. No additional programming steps are required.

- **Compatibility:** The remote is compatible with Sony STR-DH520, RMAAU104, 148934311, and RM-AAU105 models.
- **Usage:** Point the remote control directly at your Sony AV Receiver and press the desired function buttons.
- **Functionality:** All standard functions of the original remote, such as power, volume, input selection, and menu navigation, should operate as expected.

4. Maintenance and Care

Proper care will extend the life of your remote control:

- **Cleaning:** Use a soft, dry cloth to clean the remote. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance diminishes. Always replace both batteries at the same time.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in general household waste.

5. Troubleshooting

If your remote control is not functioning correctly, consider the following:

- **No Response:**
  - Check if the batteries are inserted correctly with the proper polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the AV Receiver's infrared sensor.
  - Confirm you are within the effective operating range (up to 10 meters).
- **Intermittent Functionality:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure the remote's infrared emitter is clean and unobstructed.
- **Specific Buttons Not Working:**
  - Check for any physical damage or debris under the button.
  - If only certain buttons fail, and others work, it might indicate a more specific internal issue.

If troubleshooting steps do not resolve the issue, please refer to the "Warranty and Support" section for assistance.

6. Specifications

Brand	JustFine
Model Number	43235-19477

Compatible Devices	Sony STR-DH520, RMAAU104, 148934311, RM-AAU105 Audio/Video AV Receiver Home Theater System
Connectivity Technology	Infrared
Maximum Range	10 Meters
Battery Type	AA or AAA batteries (not included)
Controller Type	Button Control
Button Quantity	40
Item Weight	0.17 Pounds (approximately 77 grams)

7. Warranty and Support

Your JustFine replacement remote control comes with a quality warranty and support:

- **Quality Warranty:** A 30-day quality warranty is provided from the date of purchase.
- **Money-Back Guarantee:** The product is sold with a money-back guarantee for your satisfaction.
- **Hassle-Free Return:** Enjoy a hassle-free return process if you encounter any issues.
- **Customer Support:** For any problems, questions, or assistance, please contact us via email. Refer to your purchase documentation for contact details.

© 2023 JustFine. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MQ2GG54

More documents and user manuals: **https://manuals.plus/**