Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JustFine 4330960594

JustFine Replacement Remote Control User Manual

For Sony Audio/Video AV Receiver Home Theater Systems

Compatible Models: STR-KS370, RMAAU073, HTC-T350HP, HTSS370, HT-CT350HP

Introduction

This manual provides instructions for the JustFine replacement remote control, designed for use with various Sony Audio/Video AV Receiver Home Theater Systems. This remote is pre-programmed and requires no additional setup beyond battery installation.

Package Contents

- 1 x JustFine Replacement Remote Control
- (Batteries and instruction manual are not included in the package)

Setup: Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA batteries (not included), ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.



Image: Rear view of the remote control, highlighting the battery cover.

Operating Instructions

This replacement remote control is pre-programmed to function with the specified Sony AV Receiver Home Theater Systems. No additional programming is required.

Basic Functions

- **Power On/Off:** Press the **I/O** button (usually green) to turn the system on or off.
- **Input Selection:** Use the dedicated input buttons (e.g.,**BD**, **DVD**, **TV**, **VIDEO**, **SAT/CATV**, **CD**) to select the desired

audio/video source.

- **Volume Control:** Use the **VOL +** and **VOL -** buttons to adjust the master volume.
- **Mute:** Press the **MUTING** button to temporarily silence the audio. Press again to restore sound.
- **Navigation:** Use the directional arrow buttons (**Up, Down, Left, Right**) and the **ENTER** button for menu navigation.
- **Menu Access:** Press the **HOME** or **MENU** button to access the system's main menu.



Image: Front view of the remote control, displaying all function buttons.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote's performance degrades, replace the batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Troubleshooting

Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity. Replace with fresh batteries if necessary.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the AV receiver. Obstructions can block the infrared signal.
- **Remote Sensor:** Verify that the infrared sensor on your AV receiver is not obstructed or dirty.

Limited Functionality (e.g., HDMI inputs not working)

- This replacement remote is designed to replicate the primary functions of the original. Some advanced or specific functions, particularly those related to customizable HDMI input labels on certain Sony models, may not be fully supported or may require direct interaction with the receiver's front panel. Refer to your Sony AV receiver's original manual for specific functions not covered by this remote.

Specifications

- **Brand:** JustFine
- **Model Number:** 4330960594
- **Compatible Devices:** Sony STR-KS370, RMAAU073, HTC-T350HP, HTSS370, HT-CT350HP Audio/Video AV Receiver Home Theater Systems
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** 4.53 x 1.57 x 1.38 inches (approximately)
- **Item Weight:** 0.32 ounces (approximately)
- **Special Feature:** Ergonomic design

Warranty and Support

This product comes with a 30-day quality warranty.

For any issues or inquiries, please contact the seller directly.

© 2023 JustFine. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01MQ2LQFX

More documents and user manuals: **https://manuals.plus/**